

MOTA®



JETJAT® ULTRA™

Owner's Manual

Ages

8+

For Owner's Manual updates, warranty information, and support, please visit: <https://www.mota.com/ultra>

Please read this manual carefully before flying! It has valuable safety information and tips on fun and efficient flight. Please keep this manual in a safe place.



[mota.com/ultra](https://www.mota.com/ultra)

FlySafely!

Drones are sophisticated precision devices capable of complex aerial maneuvers. Please read these safety instructions before using your drone. Failure to operate your drone safely could degrade its performance and cause harm to people, animals, or property.

Please do not fly:

- Near or around obstacles such as birds or pets, aircraft, helicopters, other drones, antennas or overhead lines, or airborne toys like kites.
- In or near airports or restricted areas.
- In adverse conditions such as strong winds, rain, hail, snow or sleet.
- If you are impaired, tired, or distracted.

Please do:

- Know and comply with laws and regulations respecting drone use in your area.
- Keep hands away from rotors when drone is switched on.
- Fly within controller range.

SAVE-A-DRONE: FLIGHT SAFETY MCO TA

PREFLIGHT YOUR DRONE
Verify you're in the proper airspace. Be sure you understand. Check you've gotten the hang of flying the drone, and to yourself, avoid the risk.

HEADS UP!
Be wary of people and objects nearby to prevent collisions or accidents.

CHECK FOR NO FLY ZONES
Avoid locations such as airports that are prohibited drone operations. Be mindful of your surroundings when in flight.

PROPER HANDLING
When operating a drone, make sure you're getting the best out of the drone. Be sure to follow the rules.

Fly Safely!

Find Out How:



OWNER'S MANUAL

TABLE OF CONTENTS

IN THE BOX	5
JETJAT ULTRA	7
FLIGHT PREPARATION	7
CONTROLLER BATTERY INSTALLATION	7
CHARGING YOUR JETJAT ULTRA	8
SAFE DISTANCE	10
PAIRING YOUR JETJAT ULTRA	11
APP INSTALLATION	12
WI-FI CONNECTION (IOS)	13
WI-FI CONNECTION (ANDROID)	15
USING THE JETJAT ULTRA APP	16
ACCESSING THE APP INTERFACE	17
APP CONTROL INTERFACE	18

OWNER'S MANUAL

TABLE OF CONTENTS

FLIGHT SETTINGS	19
ONE-TOUCH TAKE OFF / ONE-TOUCH LANDING	20
ONE-TOUCH 360° FLIPS / ONE-TOUCH CALIBRATION	21
TAKE PHOTOS AND VIDEOS	22
RESPONSIVENESS MODES	23
FLIGHT CONTROL	24
THROTTLE CONTROL	24
DIRECTIONAL CONTROL (ROLL LEFT / ROLL RIGHT)	24
PITCH CONTROL (FLY FORWARD / FLY BACKWARD)	25
ROTATION CONTROL (ROTATE LEFT / ROTATE RIGHT)	26
TRIM SETTINGS	27
MOTION SENSOR MODE	28
AILERON CONTROL (ROLL LEFT / ROLL RIGHT)	28

OWNER'S MANUAL

TABLE OF CONTENTS


PITCH CONTROL (FLY FORWARD / FLY BACKWARD)	29
FLIGHT CONTROL SUMMARY	30
AILERON CONTROL (LEFT / RIGHT)	31
MODE 1 / MODE 2 SWITCHING	31
MOTION SENSOR MODE	32
SPEED SELECTION	32
360° FLIPS	33
TROUBLESHOOTING	35
ACCELEROMETER CALIBRATION	34
LOW BATTERY INDICATION	34
LOSS OF WI-FI COMMUNICATION	35
FAULTY TAKE OFF	35
FAQ	36




IN THE BOX

JETJAT ULTRA

POWER SWITCH



PROPELLERS



BUMPER GUARD



USB CHARGING CABLE



IN THE BOX

JETJAT ULTRA

CONTROLLER

MODE 1/ MODE 2
SELECTION

THROTTLE
FLIGHT STICK
ROTATION CONTROL
(LEFT/RIGHT)

THROTTLE CONTROL
(ASCEND/DESCEND)

POWER SWITCH

ADJUSTABLE PHONE HOLDER

ONE-TOUCH TAKE-OFF/
ONE-TOUCH LANDING

DIRECTIONAL
FLIGHT STICK
AILERON CONTROL
(LEFT/RIGHT)

PITCH CONTROL
(FORWARD/
BACKWARD)

LINKING INDICATOR



EXPANDABLE CONTROL GRIPS


Please note: Throttle and directional controls depicted here are using Mode 2.

FLIGHT PREPARATION


Controller Battery Installation

1


① OPEN THE BATTERY COVER ON THE CONTROLLER.



② INSTALL 2 AAA BATTERIES (NOT INCLUDED).



③ CLOSE THE BATTERY COVER.




FLIGHT PREPARATION

Charging Your JETJAT ULTRA

2 Charging Your JETJAT ULTRA

Connect the drone to the charging cable, then insert the charging cable into the port of a USB charger. When the USB indicator is ON, the battery is charging. When the indicator is OFF, the battery is fully charged. The USB charging cable is compatible with a computer USB port, an Apple charger, or any other USB charging device, including portable USB chargers and USB car chargers.



FLIGHT PREPARATION

Charging Your JETJAT ULTRA

3

CAUTION

Battery life: Flight time is 4 – 5 minutes when battery is charged and with minimal wind resistance.* Land your JETJAT ULTRA immediately when the battery is low and recharge.

Controller range: The effective range between controller and drone is approximately 80 feet.* Flying outside of the recommended range may cause a crash or loss of the drone.

Warning: Do not fly in moderate or high winds, as the drone may be carried away or crash. While flying, do not throttle down quickly as this may cause the drone to lose altitude uncontrollably.

*Flight time and controller range depend on battery status and condition, flight conditions, and drone operation.

FLIGHT PREPARATION

Safe Distance

1


While flying, do not quickly throttle down as this may cause the drone to plummet and result in damage.

2

Fly your drone at least 3 feet above the ground.

3


Be aware of your drone's surroundings and avoid flying near obstacles.



FLIGHT PREPARATION

Pairing JETJAT ULTRA with Controller

4



- 1 Switch the drone and the controller ON. The controller will beep once.
- 2 Push the **Throttle Flight Stick** on the left to the full upward position. The controller will beep once.



- 3 Pull the **Throttle Flight Stick** to the full downward position. The controller will beep once more, indicating successful linking.
- 4 Your JETJAT ULTRA is now ready for flight.

FLIGHT PREPARATION

App Installation

5


Download and Install the App

1

Install the App by following one of the methods below

- a) Please visit <http://go.mota.com/30>.
- b) Follow the QRC, below.
- c) Once the page loads, follow the link to download the MOTA JETJAT ULTRA app from the Apple App Store (for iOS) or Google Play (for Android).
- d) Search for JETJAT ULTRA in iTunes in the Apple App Store (for iOS) or Google Play (for Android).

NOTE: To maximize the reception of Wi-Fi video streaming during operation, point the antenna downward.



ANTENNA



FLIGHT PREPARATION

Wi-Fi Connection (iOS)



CAUTION

When flying keep as much distance as possible from other Wi-Fi signals in order to avoid potential interference.

Turn off Wi-Fi and reconnect if there is no Wi-Fi signal found.

Completely exit the app when you need to recharge the ULTRA's battery.

Do not launch the app until a Wi-Fi connection to the drone is restored.


Wi-Fi range is approximately 80 feet. To ensure normal flight behavior, do not exceed this range.

.....

2

Wi-Fi Connection Steps (iOS)


- With the battery inserted into and connected to the drone, turn ON the power switch, and the power indicator will begin to flash rapidly.
- Go to the Settings menu of your iPhone or iPad.



- Select Wi-Fi to access the available Wi-Fi networks.

FLIGHT PREPARATION

Conection Steps (iOS)



d) Connect to the network.

e) Navigate to the MOTA JETJAT Ultra app on your device and tap the icon to display the Home Screen.


FLIGHT PREPARATION

Wi-Fi Connection (Android)


1

Wi-Fi Connection Steps (Android)

- With the battery inserted into and connected to the drone, turn the power switch ON. The power indicator will begin to flash rapidly.
- Go to the Settings menu of your Android device.



- Select Wi-Fi to see available Wi-Fi networks.



- Connect to the network.
- Navigate to the MOTA JETJAT Ultra app on your mobile device and tap the icon to display the Home Screen.

USING THE JETJAT ULTRA APP


Accessing the App Interface

1

Accessing the App Interface

1. Navigate to the MOTA JETJAT ULTRA app on your mobile device and tap the icon to display the Home Screen.
2. Tap "Play" to enter the Control Screen.
3. You will see the drone's flight controls overlaid on the streaming video from the drone's camera.


HOME SCREEN




USING THE JETJAT ULTRA APP

Accessing the App Interface

CONTROL SCREEN ON



CONTROL SCREEN OFF




Note: When using the controller to guide the drone, please first link the drone with the controller prior to connecting to Wi-Fi. Turn off the phone's own control interface when using the controller for an unobstructed view of the controls while streaming video.

USING THE JETJAT ULTRA APP

App Control Interface

2




USING THE JETJAT ULTRA APP

Flight Settings


3

HOME SCREEN



Click the Play button
to enter Flight Settings

SETTINGS



Advanced Setting (Default)

Advanced Setting (Default) Left and Right
throttle. (to turn ON swipe left;
to turn OFF swipe right)


USING THE JETJAT ULTRA APP

One-Touch Take Off / One-Touch Landing

One-Touch Take Off


4

Place the drone on a flat level surface and tap the one-touch take-off icon. After taking off, the drone will hover and maintain height at about 5 feet above the ground.



One-Touch Landing

After tapping the one-touch landing icon, the drone will descend and land automatically.



USING THE JETJAT ULTRA APP

One-Touch 360° Flip / One-Touch Calibration

One-Touch 360° Flips

While hovering in the air, tapping on the One-Touch Flips and Rolls icon will cause the drone to flip or roll.



One-Touch Calibration

If the drone begins to exhibit unstable flight, place the drone on a flat, level surface and tap the one-touch calibration icon. The LED indicators on the drone will flash rapidly while calibration is taking place.



USING THE JETJAT ULTRA APP

Take Photos and Videos

- 5** The JETJAT ULTRA features a high-quality 640 x 480 SD resolution camera that livestreams video directly to your smartphone. There is no need to switch the camera ON or OFF.

- 1** **Snap a Photo:** Tap the Photo icon. The photo will be saved in the photo album on your phone.



- 2** **Start / Stop Video Capture:** Tap the Video icon to begin and end recording. The elapsed time will be displayed, confirming you are recording. The video will be saved in the video album on your phone.

NOTE: If you don't see the Video icon, check the Wi-Fi connection between your phone and the ULTRA.



You cannot take a photo and record video at the same time.

USING THE JETJAT ULTRA APP

Responsiveness Modes

Responsiveness Modes

- There are three levels of responsiveness:
- The default mode is Easy Mode (30%).
- Tapping the Responsiveness icon once from Easy Mode will cause the drone to enter Intermediate Mode (60%).
- Tapping the Responsiveness icon once from Medium Mode will cause the drone to enter Fast Mode (100%).
- Tapping the icon again will cause the drone to revert back to Easy Mode. The higher the setting, the more quickly the drone will respond. The lower the setting, the more slowly the drone will respond.





Easy > Medium > Fast
30% 60% 100%

FLIGHT CONTROL

Throttle Control

- 1 Tap and hold the **Throttle Control** disc. Dragging the disc up will cause the propellers to rotate. The speed of rotation increases with how far you drag the disc, resulting in vertical lift. Dragging the disc down will cause the speed of the propellers to slow, resulting in a loss of altitude.




- 2 **Directional Control (Roll Left/Roll Right)**

Tap and hold the **Directional Control** disc. Dragging the disc left will cause the drone to fly to the left, and dragging the disc to the right will cause the drone to fly to the right.

FLIGHT CONTROL

Directional Control (Roll Left/Roll Right)

Tap and hold the **Directional Control** disc. Dragging the disc left will cause the drone to fly to the left, and dragging the disc to the right will cause the drone to fly to the right.




3

Pitch Control (Fly Forward / Fly Backward)

Tap and hold the **Directional Control** disc. Dragging the disc up will cause the drone to fly forward, and dragging the disc down will cause the drone to fly backward.

FLIGHT CONTROL

Directional Control (Roll Left/Roll Right)




4

Rotation Control (Rotate Left / Rotate Right)

Tap and hold the **Directional Control** disc. Dragging the disc left will cause the drone to rotate to the left, and dragging the disc right will cause the drone to rotate to the right.



TRIM SETTINGS



Note: Move the black bar in the opposite direction of drift

1) Forward / Backward Trim

If the drone drifts forward or backward while hovering, adjust the trim setting until hovering is stable.

2) Left / Right Drift Trim

If the drone drifts left or right while hovering, adjust the trim setting until hovering is stable.

3) Rotational Trim

If the drone rotates to the left or to the right while hovering, adjust the trim setting until rotation ceases.

MOTION SENSOR MODE

The **Motion Sensor** control is set to OFF by default. To switch it ON, tap the icon. The icon will glow to show that Motion Sensor control is ON.




When the **Motion Sensor** control is ON, the pitch and aileron controls will be linked. This means that you can use the movement of your phone to direct left/right, forward/backward directional control of the drone. **Please note, you**

must still use the throttle icon in the app to control height and rotation. In this mode, one-hand flight operation is possible. Mobile device motion control is as follows:

1 Aileron Control [Roll Left / Roll Right]

Tilting your mobile device to the left or right will cause the **Aileron Control** disc to move to the left and right respectively, causing the drone to fly left or right.



MOTION SENSOR MODE

2 Pitch Control (Fly Forward / Fly Backward)

Tilting your mobile device forward or backward will cause the **Pitch Control** disc to move up and down respectively, causing the drone to fly forward and backward.



FLIGHT CONTROL SUMMARY

ASCEND



When pushing the **Throttle Flight Stick** upward, the propellers' rotation will accelerate and the drone will ascend.



DESCEND



When pulling the **Throttle Flight Stick** downward, the Propellers' rotation will decelerate and the drone will descend.



ROTATE LEFT



When pushing the **Throttle Flight Stick** to the left, the nose of the drone will rotate left.



ROTATE RIGHT



When pushing the **Throttle Flight Stick** to the right, the nose of the drone will rotate right.



FORWARD



When pushing the **Directional Flight Stick** upward, the drone will move forward.



BACKWARD




When pushing the **Directional Flight Stick** downward, the drone will move backward.




FLIGHT CONTROL SUMMARY

Aileron Control (Left/Right)

AILERON CONTROL (LEFT)




AILERON CONTROL (RIGHT)



Mode 1 / Mode 2 Switching

With the controller ON, click the switch on the left side of the controller to enter Mode 1.

Mode 2 is the default setting, which most prefer. If you prefer to control the Flight Sticks with your other hand, you may want switch to Mode 1.




FLIGHT CONTROL

Speed Selection


EASY

Gently press the **Throttle Flight Stick**. If the controller beeps once, it indicates easy mode.




MEDIUM

Gently press the **Throttle Flight Stick**. If the controller beeps twice, it indicates medium mode.



FAST


Gently press the **Throttle Flight Stick**. If the controller beeps three times, it indicates fast mode.



FLIGHT CONTROL

360° Flips

Gently press the **Directional Flight Stick**. When it beeps 3 times, this indicates the ULTRA has entered 360° Flip mode. From here, push the **Directional Flight Stick** in the direction you would like to flip and roll your drone.





TROUBLESHOOTING

Accelerometer Calibration

If your drone becomes unstable in flight or drifts in one direction, you should calibrate the accelerometer.

- 1 Place the drone on a flat, level surface.
- 2 After successful pairing, pull both the **Throttle Flight Stick** and the **Directional Flight Stick** to their bottom-right corners simultaneously. The indicator lights on the drone will flash. When the indicator lights are steadily lit without interruption, calibration is successful.



I TROUBLESHOOTING

Low Battery Indication

The drone's blue-and-red LED lights blink rapidly. Please land immediately and recharge.

Loss of Wi-Fi Communication

If the blue Wi-Fi indicator light on the bottom of the drone is not lit, the drone's Wi-Fi communication with your phone is outside of specification. This could degrade the video. Please check that the batteries in the drone, the controller, and your phone are fully charged.

Faulty Take Off

If the drone is not lifting off and flipping over before takeoff please make sure that the blade arrangement is correct. Please refer to "blade arrangement diagram" on Page (5).

FAQ

Q. How high can it fly?

A. The ULTRA can fly up to 25 meters (about 80 feet) in any direction before it loses the controller signal. If that happens, it will crash so always keep it in range and in sight.

Q. Does it come with propeller guards?

A. As a matter of fact it does! Inside the box you'll find easy-to-install propeller guards, a quick and easy installation.

Q. How long does it take to charge? And how do you charge it?

A. From 0% to 100%, the estimated charging time is 20 minutes. That will

vary over time, as new batteries, even ones with advanced li-ion chemistry like in the ULTRA, charge quicker than older ones.

Q. Can it be used on iOS and Androids?

A. Yes, both phones compatible. Note: tablets and larger phones like the iPhone 6 Plus and Samsung Galaxy edge S7 may not fit on the controller if the phone is in a case of any kind.

Q. There was no SD card in the drone, how do I record or store my videos or photos?

A. The JETJAT ULTRA is smartphone compatible. With the push of a button you will be able to take photos and record videos straight to your phone without any additional products like an SD card.



FAQ

Q. I'm new at this, how do I fly the drone?

A. Find any information you need to learn how to fly on our website, www.mota.com. There is also an owner's manual in the package contents that give you step by step instructions on how to fly, as well as detailed information about the product itself and its capabilities and functions.

Q. I'd like to provide feedback, where do I go?

A. All MOTA Customers have a direct line to our customer support. You can

reach us directly at product-feedback@mota.com, and for any issues regarding the product itself like shipping or usabilitys issues do not hesitate to issue a ticket with our support team on www.mota.com for assistance.

Lithium Battery Safety Guide



WARNING:

If the device is not operating, charging the lithium battery may cause fire, injury, or loss of property. The user should be aware of the risks while using the product. The manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended. Please carefully read these safety guidelines and charging instructions before use.

Lithium Battery Guarantee

Mota Group, Inc. guarantees quality materials and workmanship for this product. Under no circumstances will Mota Group, Inc. compensate an amount higher than the valued retail price.

Your drone uses an internal high-performance non-removable lithium battery. The controller uses 3 AAA replaceable batteries. Please store the drone and batteries in a cool, dry environment away from children and pets.

1. Do not disassemble, pierce, cut, or distort the drone or its batteries. Doing so is a safety hazard and violates the warranty.
2. Please use the only USB charger cable included with the drone.
3. When charging, ensure the drone is in a ventilated area, on a hard surface and uncovered, and do not leave it unattended more than a few minutes. The drone automatically stops charging after the battery is full (you will see the red light on the USB connector turn OFF) but is recommended you disconnect the power source once your drone is charged.
4. Do not fly or store the drone in very high temperature or near any heat source, open flame, or flammable materials.
5. Metal objects may cause a short in the battery if they touch its positive (“+”) and/or negative (“-”) terminals. Please do not store or transport the drone and transmitter with metallic objects or any kind such as coins, keys, thumb drives, etc.
6. In the unlikely event the drone or transmitter’s batteries emit an odor, smoke or liquid, or if you notice any other abnormal condition, immediately disconnect the drone from the charging device (if connected) and take the drone transmitter ON or OFF. Do not touch any liquids as it may irritate the skin. If irritation persists, seek medical attention.
7. When the batteries reach the end of their useful life, please dispose of the drone and transmitter batteries at an authorized recycling center or organization.

