

Solid-State Memory Camcorder

Operating Instructions

PXW-X400 / PXW-X400KC / PXW-X400KF





Table of Contents

1. Overview	
Name and Function of Parts	3
Screen Display	13
2. Preparation	
Preparing a Power Supply	22
Attaching a Viewfinder	23
Using the Camcorder for the First Time	25
Mounting and Adjusting the Lens	26
Preparing the Audio Input System	28
Attaching and Adjusting Peripheral Devices	29
Handling SxS Memory Cards	30
Handling SD Cards for Saving Configuration Data	32
Using a Media Adaptor	33
3. Settings and Adjustments	
Format Settings	34
Adjusting the Black Balance and White Balance	37
Setting the Electronic Shutter	39
Setting Auto Iris	40
Adjusting the Focus	42
Adjusting the Audio Level	43
Setting Time Data	45
4. Shooting	
Basic Operations	47
Advanced Operations	49
Proxy Data	53
Planning Metadata	55
Obtaining Location Information (GPS)	57
5. Network Configuration	
Network Functions Supported by the Camcorder	58
Connecting Devices using Wireless LAN	59
Connecting to the Internet	63
Transferring Files	66
Transmitting Streaming Video and Audio	68
Streaming High Quality Video	69
Using Wi-Fi Remote Control	70
Configuring from the Web Menu	72
Supported Network Functions and Operating Limitations	77
6. Clip Operations	
Clip Operations on the Thumbnail Screen	78
7. Menu Display and Settings	
Setup Menu Organization	84
Basic Setup Menu Operations	86
Editing the User Menu	88
Menu List	90
Assigning Functions to Assignable Switches	114
8. Saving and Loading User Configuration Data	
User Configuration Data	117
User Files	118
ALL Files	119
Scene Files	120
Reference Files	121
Lens Files	122
Gamma Files	123
9. Connecting External Devices	
Connecting a Remote Control Unit	124
Connecting an External Monitor	126
Managing/Editing Clips with a Computer	127
Configuring a Shooting and Recording System	129
Recording External Input Signals	131
10. Maintenance and Inspection	
Maintenance	132
Error/Warning System	133
11. Appendix	
Messages Displayed During Operation	136
Usage Precautions	142
Specifications	144

Name and Function of Parts

Power Supply



1. LIGHT (video light) switch

Determines how a video light connected to the LIGHT connector (page 4) is turned on and off.
AUTO: When the POWER switch of the video light is in the on position, the video light is turned on automatically while the camcorder is recording.
MANUAL: You can turn the video light on or off manually, using its own switch.

[Note]

When the camcorder is set for recording in Picture Cache mode, it is not possible to turn on the light before operation to start recording is carried out (or while data is being stored in memory).

2. POWER switch

Turns the main power supply on (I) and off (O).

3. DC IN (DC power input) connector (XLR type, 4-pin, male)

4. DC OUT 12V (DC power output) connector (4-pin, female)

Supplies power for an optional WRR-8555/860C/861/862 UHF Synthesizer Diversity Tuner or HDVF-L750 Viewfinder (maximum 1.8 A).

[Note]

Do not connect any equipment other than the UHF synthesized diversity tuner.

5. Battery attachment shoe

Attach a BP-FLX75 Battery Pack. Alternatively, you can attach an AC-DN2B/DN10 AC Adaptor to operate the camcorder from an AC power supply.

**Preparing a Power Supply" (page 22)*

**Attaching a Wireless Receiver" (page 28)*


[Note]

For your safety, and to ensure proper operation of the camcorder, Sony recommends the use of the BP-FLX75 Battery Pack.

6. Camera adaptor connector

Enables connection of a CA-TX70/FB70 HD Camera Adaptor. To connect an adaptor, remove the cover.

Accessory Attachments



8. Lens mount securing rubber

After locking the lens in position using the lens locking lever, fit this rubber over the lower of the two projections. This fixes the lens mount, preventing it from coming loose.

9. Viewfinder front-to-back positioning knob (page 23)

10. Attachment for optional microphone holder (page 28)

11. LIGHT (video light) connector (2-pin, female) (page 29)

12. Shoulder pad (page 29)

13. Lens cable clamp
Clamps the lens cable.

14. MIC IN (microphone input) (+48 V) connector (XLR type, 5-pin, female)
Connect a stereo microphone to this connector. The power (+48 V) is supplied via this connector.

15. LENS connector (12-pin) (page 26)

[Note]
When connecting or disconnecting the lens cable to this connector, power off the camcorder first.


16. Tripod mount
When using the camcorder on a tripod, attach the tripod adaptor (optional).

17. Lens mount (special bayonet mount) (page 26)

18. Lens locking lever (page 26)

19. Lens mount cap
Remove by pushing the lens locking lever up. When no lens is mounted, keep this cap fitted for protection from dust.

Controls Near the Lens



1. REC START (recording start) button

Press to start recording. Press it again to stop recording. The operation is the same as that of the VTR button on the lens.

2. SHUTTER switch

Set to ON to use the electronic shutter. Push to SELECT to switch the shutter speed or shutter mode setting. When this switch is operated, the new setting appears on the viewfinder screen for about three seconds.

"Setting the Electronic Shutter" (page 39)

1. Wireless receiver insertion slot
2. Shoulder strap fitting (page 29)
3. Accessory shoe (page 29)
4. Viewfinder front-to-back positioning lever (page 24)
5. Viewfinder left-to-right positioning ring (page 23)
6. Viewfinder attachment shoe (page 23)

7. VF (viewfinder) connectors (26-pin, rectangular and 20-pin, round)
The analog interface connector (20-pin) is for connection of an HDVF series viewfinder, and the digital interface connector (26-pin) is for connection of a CBK-VF02 HD viewfinder. Connect a viewfinder connection cable to the connector compatible with the viewfinder being used.


[Note]
Do not connect viewfinders to both connectors at the same time.

[Note]

If Flash Band Reduce is on, setting the SHUTTER switch to ON turns off the Flash Band Reduce function and the FBR indicator disappears from the viewfinder screen. Subsequently, setting the SHUTTER switch to OFF turns on the Flash Band Reduce function and the FBR indicator reappears on the viewfinder screen.

3. FILTER knob

Switches between four ND filters built into this camcorder.



When this selector is used, the new setting appears on the viewfinder screen for about three seconds.

setting	ND filter
1	CLEAR
2	1/4 ND (attenuates light to approximately 1/4)
3	1/16 ND (attenuates light to approximately 1/16)
4	1/64 ND (attenuates light to approximately 1/64)

You can change a Maintenance menu setting so that different white balance settings can be stored for different FILTER knob positions. This allows you to automatically obtain optimum white balance for the current shooting conditions in linkage with the filter selection.

**Adjusting the White Balance* (page 37)*

4. MENU knob (page 86)

5. AUTO W/B BAL (automatic white/black balance adjustment) switch

Activates the automatic white/black balance adjustment functions.

WHITE: Adjust the white balance automatically.

If the WHITE BAL switch (page 6) is set

to A or B, the white balance setting is stored in the corresponding memory. If the WHITE

BAL switch is set to PRST, the automatic white balance adjustment function does not operate.

BLACK: Adjust the black set and black balance automatically.


You can use the AUTO W/B BAL switch even when the ATW (Auto Tracing White Balance) function is operating.

If you push the switch to the WHITE side once more during the automatic white balance adjustment, the adjustment is canceled and the white balance setting returns to the original setting.

If you push the switch to the BLACK side once more during the automatic black balance adjustment, the adjustment is canceled and the black balance setting returns to the original setting.

6. MIC (microphone) LEVEL knob (page 43)

LCD Monitor Side (1)



1. ASSIGN (assignable) 1/2/3 switches

You can assign a function using Operation >Assignable Switch in the setup menu (page 114).
The ASSIGN. 1/3 switches are provided with an indicator to show whether a function is assigned to the switch (ON) or not (OFF).

2. ONLINE button

When network client mode or the streaming function is assigned to this button, press and hold until the indicator is lit orange. Then, press the button again, turning the indicator blue, to enable network client mode or the streaming function. To exit the enabled function, press and hold the button until the indicator turns off.
The button can also be used as an assignable switch when assigned with functions other than those above (page 115).

3. ALARM (alarm tone volume adjustment) knob

Controls the volume of the warning tone that is output via the built-in speaker or optional earphones. When the knob is turned to the minimum position, no sound can be heard. However, if Maintenance >Audio >Min Alarm Volume in the setup menu is set to [Set], the alarm tone is audible even when this volume control is at the minimum position.



4. MONITOR (monitor volume adjustment) knob

Controls the volume of the sound other than the warning tone that is output via the built-in speaker or earphones. When the knob is turned to the minimum position, no sound can be heard.

5. MONITOR (audio monitor selection) switches

By means of combinations of the two switches, you can select audio that you want to hear through the built-in speaker or earphones.

When the lower switch is set to CH-1/2

Upper switch	Audio output
CH-1/CH-3	Channel 1 audio
MIX	Channels 1 and 2 mixed audio (stereo) ^{a)}
CH-2/CH-4	Channel 2 audio
When the lower switch is set to CH-3/4	
Upper switch	Audio output
CH-1/CH-3	Channel 3 audio
MIX	Channels 3 and 4 mixed audio (stereo) ^{a)}
CH-2/CH-4	Channel 4 audio

a) By connecting stereo headphones to the EARPHONE Jack, you can hear the audio in stereo. (Maintenance >Audio >Headphone Out in the setup menu must be set to Stereo)

6. ASSIGN (assignable) 0 switch

You can assign a function using Operation >Assignable Switch in the setup menu (page 114).
Off is assigned to these switches when the camcorder is shipped from the factory.
This is a momentary type switch. Each press of the switch turns the function assigned to this switch on or off.

7. GAIN switch

Switches the gain of the video amplifier to match the lighting conditions during shooting. The gain values corresponding to the L, M, and H settings can be selected using Operation >Gain Switch in the setup menu (page 94) (factory settings are L=0 dB, M=6 dB, and H=12 dB).

When this switch is adjusted, the new setting appears on the viewfinder screen for about three seconds.

8. OUTPUT/DCC (output signal/dynamic contrast control) switch

Switches the video signal output from the camera module, between the following two.
BAR: Output the color bar signal.

CAM: Output the video signal being shot. When this is selected, you can switch DCC¹⁾ on and off.

- 1) DCC (Dynamic Contrast Control): Against a very bright background with the iris opening adjusted to the subject, objects in the background will be lost in the glare. The DCC function will suppress the high intensity and restore much of the lost detail. It is particularly effective for shooting in the following cases.
- Shooting people in the shade on a sunny day
 - Shooting a subject indoors, against a background through a window
 - Any high contrast scene

9. WHITE BAL (white balance memory) switch

Control's adjustment of the white balance.

PRST: Adjust the color temperature to the preset value (the factory default setting: 3200K). Use this setting when you have no time to adjust the white balance.

A or B: Recall the white balance adjustment settings already stored in A or B. Push the AUTO W/B BAL switch (page 5) to the WHITE position to automatically adjust the white balance and save the adjustment settings in memory A or memory B.

B (ATW¹⁾): When this switch is set to B and Operation >White Setting >White Switch is set to [ATW] in the setup menu, ATW is activated.

You can use the AUTO W/B BAL switch even when ATW is in use.
When this switch is adjusted, the new setting appears on the viewfinder screen for about three seconds.

1) ATW (Auto Tracing White balance): The white balance of the picture being shot is adjusted automatically for varying lighting conditions.

[Note]
It may not be possible to adjust to the appropriate colors using ATW, depending on the lighting and subject conditions.

- Examples:
- When a single color dominates the subject, such as sky, sea, ground, or flowers.
 - When the subject is under a light source of extremely high or extremely low color temperature.

If execution of automatic tracing by the ATW function takes an unacceptably long time or only results in an inadequate effect, then execute the AWB function.

10. Switch cover

Open this cover to use the MENU ON/OFF switch or the MENU CANCEL/PRST/ESCAPE switch.

11. MENU ON/OFF switch

To use the switch, open the cover.

This switch is used to display the menu on the viewfinder screen or the test signal screen. Each time the switch is pushed down, the menu screen is turned on and off.

The function of this switch is the same as that of the MENU button in the thumbnail screen operations section.

[Note]
It is not possible to turn off the menu screen by closing the cover.

12. MENU CANCEL/PRST (preset) /ESCAPE switch

To use the switch, open the cover.
This switch has different functions depending on whether or not a menu is displayed.

Use the switch in the following way when the menu is displayed.

CANCEL/PRST: Pushing this switch up to this position after a setting is changed in the setup menu displays the message to confirm whether the previous settings are canceled. Pushing this switch up to this position again cancels the previous settings.

Pushing this switch up to this position before a setting is changed in the setup menu or after a setting change is canceled in the setup menu displays the message to confirm whether the setting is reset to the initial value. Pushing

this switch up to this position again resets the settings to the initial value.

ESCAPE: Use this switch when the menu page, which has a hierarchical structure, is opened. Each time the switch is pushed to this position, the page returns to one stage higher in the hierarchy.

Use the switch in the following way when the menu is not displayed.


CANCEL/PRST: Each time this switch is pushed upward, a window to confirm the menu settings and status of the camcorder appears on the viewfinder screen (page 13). The window consists of several pages, which are switched each time the switch is pushed upward.

ESCAPE: To clear the page, push this switch down to the OFF position.

13. **UTILITY SD card slot**
Insert an SD card for saving camcorder settings.

14. **ACCESS indicator**
Lights up orange when the SD card is being accessed.

LCD Monitor Side (2)



1. **Built-in speaker**

The speaker can be used to monitor E-E¹⁾ sound during recording, and playback sound during playback. The speaker also sounds alarms to reinforce visual warnings (page 133).


If you connect earphones to the EARPHONE jack, the speaker output is suppressed automatically.

1) E-E: Abbreviation of "Electric-to-Electric." In E-E mode, video and audio signals input to the camcorder are output after passing through internal electric circuits only. This can be used to check input signals.

2. **LCD monitor**

Displays remaining battery capacity, remaining media capacity, audio levels, time data, and so on. It also allows you to check camera and playback pictures (page 13).

You can adjust the position and angle of the LCD monitor.



3. **WARNING indicator**

Lights up or flashes when an abnormality occurs (page 133).

4. **ACCESS indicator**

Lights up in blue when data is written to or read from the recording media.

5. **Audio control section (page 9)**

6. **Thumbnail screen operation section (page 9)**

7. **F REV (fast reverse) button and indicator**

This plays back at high speed in the reverse direction. The playback speed changes in the order x4 → x1.5 → x2.4 with each press of the button. The indicator lights during high-speed playback in the reverse direction.

8. PLAY/PAUSE button and indicator

Press this button to view playback video images using the viewfinder screen or the LCD monitor. The indicator lights during playback. Press this button again during playback to pause, outputting a still image. At this time the indicator flashes at a rate of once per second. Pressing the F REV or F FWD button during playback or pause starts high speed playback in the forward or reverse direction.

9. F FWD (fast forward) button and indicator

This plays back at high speed in the forward direction. The playback speed changes in the order $\times 4 \rightarrow \times 15 \rightarrow \times 24$ with each press of the button. The indicator lights during high-speed playback in the forward direction.

10. PREV (previous) button

This jumps to the first frame of the current clip. If you press this together with the F REV button, the jump is to the first frame of the first recorded clip on the recording media. If you press this button twice in rapid succession, the jump is to the first frame of the preceding clip (or the first frame of the current clip when no preceding clips exist).

11. STOP button

Press this button to stop playback.

12. NEXT button

This jumps to the first frame of the next clip. If you press this together with the F FWD button, the jump is to the last frame of the last recorded clip on the recording media.

13. DISP SEL (display selection)/EXPAND (expand function) button

With each press of this button, the display in the LCD monitor changes as follows.

Display indication	Description
Video with superimposed information (CHAR)	The LCD monitor displays the same text information as the viewfinder.

Display indication	Description
Video without superimposed information (MONI)	Only the video appears.
Status display (STATUS)	Counter indications, warnings, audio levels, and similar information appear. No video image appears.

The EXPAND button function will be supported in a future upgrade.

14. HOLD (display hold) button

Pressing this button instantly freezes the time data displayed in the LCD monitor. (The timecode generator continues running.) Pressing this button again releases the hold.

For details about the time data display, see page 13.

15. RESET/RETURN button

Resets the value shown in the time data display in the LCD monitor. According to the settings of the PRESET/REGEN/CLOCK switch (page 9) and the F-RUN/SET/R-RUN switch (page 9), this button resets the display as follows.

Switch settings	RESET/RETURN button operation
DISPLAY switch: COUNTER	Reset counter to 00:00:00:00.
DISPLAY switch: TC	Reset timecode to 00:00:00:00.
PRESET/REGEN/ CLOCK switch: PRESET	F-RUN/SET/R-RUN switch:
F-RUN/SET/R-RUN switch: SET	

Switch settings	RESET/RETURN button operation
-----------------	-------------------------------

DISPLAY switch: U-BIT	Reset user bits data ^{a)} to 00:00:00:00.
PRESET/REGEN/ CLOCK switch: PRESET	
F-RUN/SET/R-RUN switch: SET	

a) Of the timecode bits for every frame recorded on the media, those bits which can be used to record useful information for the user such as scene number, shooting place, etc.

^{a)}Setting Time Data' (page 45)

This button returns to the previous screen when pressed during thumbnail screen display or essence mark thumbnail screen display.

16. DISPLAY switch

This cycles the data displayed in the time data display in the LCD monitor through the sequence COUNTER, TC, and U-BIT (page 13). COUNTER: Display recording/playback duration counter.

TC: Display timecode.


U-BIT: Display user bits data.

17. BRIGHT (brightness) button

Switches the brightness of the LCD monitor backlight. Each press of the button selects the next setting in the order shown in the following table. If you press the button with the LCD monitor off, the LCD backlight comes on in the H state.

Setting	LCD monitor backlight
H	High (select this to view the LCD monitor outdoors in the daytime)
M	Brightness between H and L
L	Low (select this to view the LCD monitor indoors or outdoors at night)
OFF	Off (the display is also off)

Thumbnail screen operations section and audio control section



1. THUMBAIL indicator

This lights when the thumbnail screen is displayed.

2. THUMBAIL button

Press this button to display the thumbnail screen (page 78) and to carry out a thumbnail operation.

Press once more to return to the original display.

3. SET button and arrow buttons

Use these buttons to make timecode and user bit settings, and for thumbnail screen operations. When the menu is displayed, press this button to select an item or to confirm the setting change.

4. MENU button

Each press of this button turns the setup menu display on and off.

The function of this button is the same as that of the MENU ON/OFF switch.

5. F-RUN/SET/R-RUN (free run/set/recording run) switch

Selects the operating mode of the internal timecode generator. The operating mode is set as explained below, depending on the position of the switch.

F-RUN: Timecode keeps advancing, regardless of whether the camcorder is recording. Use this setting when synchronizing the timecode with external timecode.

SET: Sets the timecode or user bits. R-RUN: Timecode advances only during recording. Use this setting to have a consecutive timecode on the recording media.

"Setting the Timecode" (page 45)

"Setting the User Bits" (page 45)

6. LEVEL CH1/CH2/CH3/CH4 (audio channel 1/2/3/4 recording level) knobs

Adjust the audio levels to be recorded on channels 1, 2, 3, and 4 when the AUDIO SELECT CH1/CH2 and AUDIO SELECT CH 3-4 switches are set to MANUAL.

7. AUDIO SELECT CH 3-4 (audio channel 3/4 adjustment method selection) switches

Select the audio level adjustment method for audio channels 3 and 4. AUTO: Automatic adjustment MANUAL: Manual adjustment

8. ESSENCE MARK button

By pressing this button when a thumbnail display is on the screen, you can view the following thumbnail displays of the essence-marked frames of the selected clip, depending on the item selected in a list displayed on the screen.

All: Thumbnail display of all frames marked with essence marks.

Rec Start: Thumbnail display of frames marked with Rec Start marks and of the first frames of clips (when the first frames are not marked with Rec Start marks).

Shot Mark1: Thumbnail display of the frames marked with Shot Mark 1.

Shot Mark2: Thumbnail display of the frames marked with Shot Mark 2.

You can also select Shot Mark 0 and Shot Mark 3 to Shot Mark 9.

If a clip is recorded using planning metadata that defines names for shot mark 0 to shot mark 9, the selection options in the list are displayed by the defined names.

9. SHIFT button

Use this in combination with other buttons.

10. PRESET/REGEN (regeneration)/CLOCK switch

Selects the type of timecode to record.

PRESET: Record new timecode on the media.

REGEN: Record timecode continuous with the existing timecode recorded on the media.

Regardless of the setting of the F-RUN/SET/R-RUN switch, the camcorder operates in R-RUN mode.

CLOCK: Record timecode synchronized to the internal clock. Regardless of the setting of the F-RUN/SET/R-RUN switch, the camcorder operates in F-RUN mode.

11. AUDIO SELECT CH1/CH2 (audio channel 1/2 adjustment method selection) switches

Select the audio level adjustment method for audio channels 1 and 2.

AUTO: Automatic adjustment MANUAL: Manual adjustment

12. AUDIO IN CH1/CH2/CH3/CH4 (audio channel 1/2/3/4 input selection) switches

Select the audio input signals to be recorded on audio channels 1, 2, 3 and 4.


FRONT: Audio input signals from the microphone connected to the MIC IN connector

REAR: Audio input signals from an audio device connected to the AUDIO IN CH-1/CH-2 connectors

WIRELESS: Audio input signals from the UHF portable tuner if it is attached

Handle and Memory Card Slot Side

SxS memory card slots (page 30)



1. ASSIGNABLE 4/5 switches

You can assign a function using Operation
>Assignable Switch in the setup menu
(page 115).

Off is assigned to these switches when the
camcorder is shipped from the factory.

2. GPS module

Contains a built-in GPS module.

[Note]
Do not grasp this part of the camcorder when the GPS
function is in use.

3. PC connector

Used to put this camcorder into USB connection
mode and use it as an external storage device
for a computer. When a computer is connected
to this connector, every memory card inserted
in the camcorder is recognized as a drive on the
computer.

4. External device connector

Connect to a PSZ-HA50 Portable Storage HDD
(option), PSZ-SA25 Portable Storage SSD (option),
a general-purpose external USB HDD, or USB flash
drive to copy clips from the recording media
inserted in an SxS card slot of the camcorder to
USB media.

[Note]
This connector should be used only for connecting the type
of devices above. It cannot be used for connecting a USB
hub or other devices.

5. USB wireless LAN module connector

Connect to an IFU-WLM3 USB Wireless LAN
Module (supplied), CBK-WA02 Wireless LAN
Adaptor (option), or combination of CBK-NA1
Network Adaptor Kit (option) and modem (option)
to enable communications with wireless LAN
devices and networks.

"Connecting Devices using Wireless LAN" (page 59)

"Connecting to the Internet" (page 63)

6. PROXY SD card slot (page 53)

Insert an SD card for recording proxy data.

7. (NFC) mark

A built-in NFC antenna is provided.

8. SLOT SELECT (SxS memory card select)
button

When SxS memory cards are loaded in both card
slots A and B, press this button to select the card
you want to use (page 30).

9. Network connector

Connects to a network via a wired LAN connection
using a LAN cable (sold separately).

[CAUTION]

- For safety, do not connect the connector for peripheral
device wiring that might have excessive voltage to this
port.
- Follow the instructions for this port.
- When you connect the LAN cable of the unit to peripheral
device, use a shielded-type cable to prevent malfunction
due to radiation noise.

"Connecting to the Internet" (page 63)

10. HDMI connector

Connect an HDMI device, such as a monitor or
recording unit, to output HD or SD HDMI video
and audio signals.

11. GENLOCK IN (genlock signal input)
connector (BNC type)

This connector inputs a reference signal when the
camcorder is to be genlocked or when timecode
is to be synchronized with external equipment.
The supported reference signals vary depending
on the current system frequency as shown in the
following table.

System frequency		Supported reference signals
59.94i	1080/59.94i, 480/59.94i	
59.94P	1080/59.94i, 480/59.94i	
50i	1080/50i, 576/50i	
50P	1080/50i, 576/50i	
29.97P	1080/59.94i, 480/59.94i	
25P	1080/50i, 576/50i	
23.98P	1080/23.98P5f	

12. TC IN (timecode input) connector (BNC type)

To apply an external lock to the timecode of the
camcorder, input the reference timecode.

"Setting the Timecode" (page 45)


13. VIDEO OUT connector (BNC type)

Outputs video signals for monitoring.

14. TC OUT (timecode output) connector (BNC type)

To lock the timecode of an external VTR to the timecode of this camcorder, connect this connector to the external VTR's timecode input connector.

Tally Indicator and Connector Section



1. TALLY (back tally) indicator (red)

Lights up during recording. It will not light if the TALLY switch is set to OFF. It also flashes when the WARNING indicator operates. The tally indicator on the front of the viewfinder and the REC indication on the viewfinder screen light or flash in the same manner.

"Error/Warning System" (page 133)

2. TALLY switch

Set to ON to activate the TALLY indicator function.

3. EARPHONE jack (stereo, minijack)

You can monitor the E-E sound during recording and playback sound during playback. When an alarm is indicated, you can hear the alarm sound through the earphone. Plugging an earphone into the jack automatically cuts off the built-in speaker. You can select monaural or stereo using Maintenance > Audio > Headphone Out in the setup menu.

4. AUDIO IN selector switch

Select the audio source you connect to the AUDIO IN CH1/CH2 connectors.
LINE: When connecting a stereo amplifier or other external audio signal source
AES/EBU: When connecting an external digital audio signal source
MIC: When connecting a microphone.

5. +48V/OFF (+48V external power source on/off) switch

Switch between the following settings, according to the microphone used for audio input.
+48V: Microphone requiring external power source (phantom power)
OFF: Microphone using internal power source or not requiring a power source

6. SDI IN (SDI input) connector (BNC type)

Connector used when connecting an external SDI signal source to the camcorder.

7. AUDIO IN CH-1/CH-2 (audio channel 1 and channel 2 input) connectors (XLR type, 3-pin, female)

Connect to audio equipment or a microphone.

8. Bottom cover

This is provided for protecting the cables connected to the connectors on the rear panel. By loosening the screws which retain the cover to the bottom of the camcorder, you can adjust the position of the cover depending on the size and shape of the microphone or audio cable plugs. After adjusting the position, tighten the screws to secure the cover.

9. AUDIO OUT connector (XLR type, 5-pin, male)

Outputs the audio signals recorded on audio channels 1 and 2 or audio channels 3 and 4. The audio signals are selected by the MONITOR switch.

10. REMOTE connector (8-pin)

Connect a remote control unit to control the camcorder remotely.

[Note]


Before connecting/disconnecting the Remote Control Unit to/from the camcorder, be sure to turn off the camcorder POWER switch.

11. SDI OUT 1/2 connectors (BNC type)

Outputs an HD SDI or SD SDI signal (with embedded audio). The output from this connector can be turned on/off using Operation >Input/Output >SDI Out1 Output or SDI Out2 Output in the setup menu.

Screen Display

Information Screen



1. Recording mode indicator

2. File format indicator

3. Status display

PB: Appears during media playback.

NDF: Appears when non-drop-frame timecode is selected.

EXT-LK: Appears when the internal timecode generator is locked to an external signal input to the TC IN (timecode input) connector.

HOLD: Appears when the operation mode of the internal timecode generator is set to R-RUN and stopped.

4. System frequency indicator

Indicates the system frequency of video being currently played or recorded.

5. Audio format indicator

Indicates the audio recording format or the audio format of clip being currently played.

Indicator Recording format

16bit	HD420 HQ
	DVCAM
	MPEG IMX 50

Indicator Recording format

24bit	HD422 50
	MPEG IMX 50
	XAVC Intra
	XAVC Long

6. Audio level meters

Indicates the audio recording or playback levels of channels 1 to 4.

7. Remaining battery capacity indicator

Displays the battery remaining capacity icon and the remaining recording time.

8. Remaining media capacity indicator

Shows bar segments indicating the remaining capacity of recording media in the slots.

9. Warning indicator area

Displays warnings when trouble with recording occurs.

For details, see "Error/Warning System" (page 133).

10. Clip name display

Displays the name of the clip currently recording when recording, or displays the name of the next clip to be recorded during recording standby.

11. Time data display

Switches displays of duration, timecode, and user bits data, depending on the position of the DISPLAY switch.

Displays the type of data currently shown in the time data display, as follows.

- TCG: Recorded timecode
- TCR: Playback timecode
- UBG: Recorded user bits
- UBR: Playback user bits
- CNT: Counter
- DUR: Duration
- CLK: Time display (when the PRESET/REGEN/CLOCK switch is set to CLOCK)

When the HOLD button is pressed to hold the timecode value, the timecode is displayed in the format shown below. When the HOLD button is pressed again to release the hold, the timecode is displayed in the normal format.



The three dots indicate that the timecode and counter progress are displayed in hold mode.

12. Resolution indicator

Indicates the resolution of the output video.

13. Recording format indicator

Indicates the current recording format or the recording format of clip being currently played.

Status Screens

The status screens allow you to check camcorder settings and various types of status information.

When no menu is displayed, push the MENU CANCEL/PRST/ESCAPE switch up to the CANCEL/PRST position to display the status screen. Each push selects the next status screen. The following status screens can be displayed.

Camera Status screen

Displays settings and status information related to shooting.


Camera Status			
Gain	18dB	Zebra1 On (80%)	Iris F9.6
Shutter	Off	Zebra2 On (102%)	Focal Length 75.2mm
Gamma	STD5 R709		Focus Distance 4.3m
White	Preset		Depth Of Field 2.5-5.8m
Gain Switch	L0, M9, H18		Zoom Speed 25

Display item	Description
--------------	-------------

Gain	Gain level in dB units
Shutter	Electronic shutter status
Gamma	Gamma category and curve
White	White balance mode setting
Gain Switch	GAIN switch status
Zebra	Zebra pattern status
Iris	Iris f-stop value
Focal Length	Focal length
Focus Distance	Focus distance
Depth Of Field	Depth of field
Zoom Speed	Zoom speed configured for the lens ZOOM button

Audio Status screen

Displays settings and status information related to audio input and output.



Display item	Description
CH 1/CH 2/CH 3/CH 4	Audio level, input source, reference input level, and wind noise reduction filter settings for each channel

System Status screen

Displays settings and status information related to recording.

System Status		
System Frequency	Picture Size	Gamma
23.98	1920X1080	STD
Rec Format	Rec Function	
XAVC-I	S&Q 26/24	
File System	Clip Continuous Rec	
exFAT	Off	
Simul Rec	Picture Cache Rec	Proxy Recording Mode
Off	Off	Off
Title Prefix	Number	
ABCDEFG	00017	

Display item	Description
System	System frequency
Frequency	
File System	Recording mode
Rec Format	Recording format
Clip	Clip Continuous Rec function on/off
Continuous	off setting
Rec	
Title Prefix	Clip name prefix
Picture Size	Picture size
Simul Rec	Simul Rec function on/off
Rec Function	Enabled special recording format and settings
Picture Cache	Picture cache function on/off
Rec	setting

Display item	Description
Number	Clip name suffix
Gamma	Gamma category in use
Proxy Recording	Proxy data recording function on/off setting
Mode	

Video Output Status screen

Displays settings and status information related to video output.

Video Output Status			
Picture Size	C. Space	Freq	Super
SD1 1920X1080P(Level A)	YPbPr	3G	---
SD2 1920X1080P(Level A)	YPbPr	3G	On
HDMI 1920X1080P	YPbPr	1.5G	On
Video HD Sync	YPbPr	---	On

Display item	Description
SD1	SD1 OUT connector output settings (output picture size, output form, output rate, superimposition)
HDMI	HDMI connector output settings (output picture size, output form, output rate, superimposition)
Video	VIDEO OUT connector output settings (output picture size, superimposition)

Network Status 1 screen

The Network Status 1 screen displays settings and status information related to the network.

Network Status 1			
Setting	On		
Wireless Network W-Fi AP	Wireless Network	Wired LAN	Enable
Device Name IF-U-WLM3	Wired LAN Remote	On	
IP Address(Wireless) 192.168.3.1	IP Address(Wired)	192.168.3.131	
MAC Addr (Wireless) 88:54:29:8a:4:7			

Display item	Description
Setting	Network setting status
Wireless Network	Wireless network setting status
Device Name	Name of device attached to the USB wireless LAN module connector

IP Address (Wireless)	IP address of wireless LAN connection
MAC Addr. (Wireless)	MAC address of device attached the USB wireless LAN module connector
Wired LAN	Wired LAN network connection status
Wired LAN Remote	Remote control enabled/disabled state when connected using a LAN cable
IP Address (Wired)	IP address of wired LAN connection

Network Status 2 screen

The Network Status 2 screen displays settings and status information related to streaming.

Network Status 2			
NW Client Mode Status	Streaming Type	Number of Distribution	
Off	MPEG-2 TS/UDP	1	
CCM Name	Streaming Dest. Addr.	File Transfer	
---	43.0.134.23	40%	
Streaming Status	Streaming Dest. Port	Transfer to	
Distributing	1234	Scary Cl	
Streaming Size			
1280X720			
Streaming Bit Rate			
9Mbps			

Display item	Description
NW Client Mode Status	Network client mode status
Mode Status	For details about the status, see "Network client mode status" (page 14).
CCM Name	Name of the connected CCM when using network client mode

Streaming Status	Streaming distribution status
Streaming Size	Picture size of the currently selected streaming setting
Streaming Bit Rate	Bit rate of the currently selected streaming setting
Streaming Type	Type of the currently selected streaming setting
Streaming Dest. Addr.	Streaming destination address
Streaming Dest. Port	Streaming destination port
Number of Distribution	Number of streaming distribution destinations
File Transfer	File transfer progress status
Transfer to:	Server name of file transfer destination

Network client mode status		
Status display	State	Description
Off	CCM not connected	Network client mode is off.
Connected	CCM connected	Network client mode is on, CCM is connected, and CCM control is enabled.

Status	State	Description
display		
Connecting	Connecting to CCM (disconnected)	Attempting to connect to CCM (or disconnecting). Wait until connection (disconnection) is successful. If the status does not change from “Connecting,” the CCM address setting may be incorrect. Check that the address is set correctly.
Awaiting	CCM connection standby	Network client mode is on, but the network setting is off. Enable the network setting to connect to the CCM.
Address Error	CCM address error	The host name or IP address of the CCM to connect may be incorrect. Check that the setting is correct.
Auth. Failed	CCM user name/ password error	The user name or password used to connect to the CCM may be incorrect. Check that the setting is correct.
No Inet Access	Internet connection error	Cannot connect to the network. The network settings may be incorrect. Check the network settings.

Status	State	Description
display		
Cert. not Valid	CCM certification not valid error	The CCM certificate is not valid. The date setting may be invalid. Check the date setting.

Assignable Button Status screen

Displays the names of functions assigned to assignable switches.

Assignable Button Status				
0	ATW Hold	5	Zoom Wide	
1	Zebra	Online	CC5600K	
2	Front Mic	Lens FET	Lens FET	
3	Marker			
4	Zoom Tele			

Battery Status screen

Displays the status of the battery attached to the camcorder.

Battery Status		Manufacture Date
Detected Battery	BP-GL95	Janv/18/2014
Remaining	54%	
Charge Count	52	
Capacity	1,934h	Power Source DC In
Voltage	13.2V	Supplied Voltage 12.8V

Display item	Description
--------------	-------------

Detected Battery	Detected type of the battery
Remaining	Remaining capacity (%)
Charge Count	Number of recharges
Capacity	Remaining capacity (Ah)
Voltage	Voltage
Manufacture Date	Date of battery manufacture
Power Source	Power supply source

Display item	Description
Supplied Voltage	Supplied power source voltage

Media Status screen

Displays the status of the recording media.


Media Status		
Remaining		Life
SxSA	0 50 100% 210min	100%
SxSB	0 50 100% 92min	54%
SD	0 50 100% 186min	
SD Proxy	0 50 100% 2.7GB	
SD Life	0 50 100%	

Display item	Description
SxSA	Remaining capacity (bar graph and remaining time display) and media life of media in slot A
SxSB	Remaining capacity (bar graph and remaining time display) and media life of media in slot B
SD Proxy	Remaining capacity (bar graph and remaining time display) and media life (displayed only if available) of media in PROXY SD card slot
SD Utility	Remaining capacity (bar graph and remaining capacity) and media life (displayed only if available) of media in UTILITY SD card slot

A  mark is displayed if the media is protected.

Viewfinder Screen

The viewfinder screen displays images during shooting (recording or recording standby)



and playback with camcorder information superimposed on the display.

You can toggle the display of information on/off using the DISPLAY switch.
The information to display is linked to the settings in Operation >Super Impose in the setup menu, and the settings of the corresponding switches.

- 1. Extender indicator**
Displays the status of the digital extender function and lens extender function.
EX: Appears when the lens extender function is ON
X2D: Appears when the digital extender function (X2) is ON
X3D: Appears when the digital extender function (X3) is ON
X4D: Appears when the digital extender function (X4) is ON
EX2D: Appears when both the lens extender function and digital extender function (X2) are ON
EX3D: Appears when both the lens extender function and digital extender function (X3) are ON
- 2. Zoom position indicator (with lens mounted)**
Displays the zoom position of the zoom lens in the range 0 to 99.
- 3. Color temperature indicator**
Displays the color temperature of the white balance.

4. Focus position indicator (with lens mounted)
Displays the focus position as a distance to the subject (unit: meters).

5. Iris position indicator (with lens mounted)
Displays the iris position setting.

6. Electric color temperature filter indicator
Appears when the CC5600K function is on.

7. Depth of field indicator (serial lens mounted)
Displays the depth of field using a bar. The units for display are set using Operation >Display On/Off >Lens Info in the setup menu, and can be set to meters or feet.

8. Recording mode indicator
Displays the following recording operation states of the camcorder.

Indicator	Meaning
● Rec	During recording
● Sby	Recording standby
● Cont Rec	Clip continuous recording in progress
● Cont Sby	Recording standby in clip continuous recording mode
● S&Q Rec	Recording in progress in Slow & Quick Motion mode
● S&Q Sby	Recording standby in Slow & Quick Motion mode
● Rec	Recording in picture cache mode
● Cache	Recording standby in picture cache mode
● Int Rec	Recording in progress in Interval Rec mode
● Int Sby	Recording standby in Interval Rec mode
● Int Sby	Recording paused in Interval Rec mode (during pause intervals)
● Siml Rec	Recording in progress in Simul Rec mode
● Siml Sby	Recording standby in Simul Rec mode

Indicator	Meaning
CALL	Call received from external connected device

Green tally is displayed when the camcorder is in the following states.

- Maintenance >Camera Config >HD-SDI Remote I/F is set to Green Tally in the setup menu and a recording control signal is output from the SDI OUT connector.
- Green tally signal received (when a camera adaptor is mounted on the camcorder and a camera extension unit is connected)

9. Wireless receiver function indicator
Displays "W" when a slot-in receiver is attached to the camcorder, and displays the reception level for each channel that can be used by the receiver (1ch, 2ch, or 4ch).

Normal: Displays the strength of the received signal level by the number of white segment indicators.

Analog receiver muting/Digital receiver error rate warning: Displays the strength of the received signal level by the number of gray segment indicators.

If the received level exceeds the peak: Displays "P" in place of the indicator. ¹⁾

Receiver battery is low: The corresponding channel number and indicators flash. ¹⁾

¹⁾ When using the DWR-S02D

10. S&Q Motion (Slow & Quick) frame rate indicator

Displays the shooting frame rate when the camcorder is set to Slow & Quick Motion recording mode.

11. GPS indicator (page 57)

12. Battery capacity/voltage display

Displays the following indicators according to the type of battery power source.

Battery type	Indicator
Info battery	Battery remaining capacity icon and remaining recording time
Anton/Bauer battery	Remaining battery capacity (%) indicator)
Other batteries	Input voltage

13. Recording format (picture size) indicator
Displays the picture size of clips recorded onto SXS memory cards.

14. Recording format (system frequency and scan method) indicator
Displays the currently configured camcorder system frequency and the recording format scan method.

15. Recording format (codec) indicator
Displays the format name of clips recorded onto SXS memory cards.

16. Gamma indicator
Display the gamma setting.

Menu settings				Indicator
Operation	Paint	>Gamma setting		
>Display	Gamma	Gamma	Gamma	
On/Off		Category	Select	
>Gamma				
Off	—	—	—	—

Menu settings				Indicator
Operation	Paint	>Gamma setting		
>Display	Gamma	Gamma	Gamma	
On/Off		Category	Select	
>Gamma				
On	Off	—	—	Gamma Off

On	STD	STD1 DWV	STD1
		STD2 x4.5	STD2
		STD3 x3.5	STD3
		STD4 240M	STD4
		STD5 R709	STD5
		STD6 x5.0	STD6
	HG	HG1	HG1
		3250G36	
		HG2	HG2
		4600G30	
		HG3	HG3
		3259G40	
		HG4	HG4
		4609G33	

On	On	User	User 1	User 1
			User 2	User 2
			User 3	User 3
			User 4	User 4
			User 5	User 5

17. Timecode external lock indicator
Displays timecode lock when the timecode is input from an external source.

18. Wired LAN connection status
Displays the wired LAN network setting and connection status using icons.

State	Icon
Maintenance	Network connection
>Display	>Network connection
On/Off	>Wired LAN status
>Network Condition	
Off	—
On	Disable

On	Enable	Connecting to LAN	
		Connected to LAN	
		LAN connection error	

19. Streaming indicator
Displays the status of streaming using icons.

State	Streaming state/icon
Maintenance	Maintenance
>Display	>Streaming
On/Off	>Setting
>Streaming Status	Client Mode >Setting
Off	—
On	Off

On	Off	Off	Off	Not streaming
				
				Streaming
				
				Error
				

The following icons are displayed when streaming from a CCM.

State		Streaming
Operation	Maintenance	Maintenance state/icon
>Display	>Streaming	>Network
On/Off	>Setting	Client Mode
>Streaming		>Setting
Status		

On	Off	On	Not streaming
			
			Streaming
			

[None]
Icons are not displayed before streaming starts.

20. Wireless network status indicator
Displays the network setting and connection status using icons.

State	Network connection status
Maintenance	Maintenance
>Display	>Network
On/Off	>Wireless
>Network Condition	Network
Off	—
On	—

Icon	Meaning
	Spotlight mode

33. Auto focus mode indicator (when an auto focus lens is attached only)

Displays the focus adjustment mode of the camcorder.

- AF (auto focus)
- MF (manual focus)
- MF* (manual focus with MF assist function on)
- Full MF (full manual focus)

34. ND filter indicator

Displays the position number of the currently selected ND filter (page 5).

When “Electrical CC” is assigned to an assignable switch, the position (A/B/C/D) of the electrical CC filter is displayed on the right of the ND filter indicator (1 to 4).

35. Gain indicator

Displays the gain setting (dB), set using the GAIN switch, of the video amplifier.

36. Shutter mode/shutter speed indicator/Flash Band Reduce status indicator

Displays the shutter mode or shutter speed.

“Setting the Electronic Shutter” (page 39)

If Flash Band Reduce (page 98) is set to On in the Operation menu, FBR is displayed when the shutter is in a non-operating state.

37. White balance mode indicator

Displays the currently selected white balance automatic adjustment memory.

ATW: ATW (Auto Tracing White Balance) mode

W:A: Memory A mode

W:B: Memory B mode

W:C: Memory C mode

W:P: Preset mode

3200K: Appears when an assignable switch

assigned with Color Temp SW 3200K is on

4300K: Appears when an assignable switch

assigned with Color Temp SW 4300K is on

5600K: Appears when an assignable switch



assigned with Color Temp SW 5600K is on

6300K: Appears when an assignable switch

assigned with Color Temp SW 6300K is on

Lens Supplied with the PXW-X400KC

The PXW-X400KC is supplied with a lens.



1. DIP switches (page 20)

Used for the shuttle shot function.

2. Iris gain adjustment trimmer (page 41)

3. Iris push auto switch

When the iris mode switch is in the M (manual) position, press this switch for instantaneous auto iris adjustment. The iris is automatically adjusted while the switch is held down.

4. Iris mode switch

A (auto): The iris is adjusted automatically.
M (manual): Adjust the iris with the iris ring.

5. Zoom seesaw switch

This is enabled when the zoom servo/manual knob is in the SERVO position. Set to the W (wide angle) position when you want wide-angle, and set to the T (telephoto) side when you want telephoto.

Press the switch harder for a faster zoom action, or softer for slower zoom action.

6. RET switch

While pressed, the last few seconds recorded appear on the viewfinder screen (Rec Review) (page 21).

7. F.B. lock screw / F.B. adjustment ring (page 41)

8. Positioning pin

When attaching the lens, align this pin with the recess in the top center of lens mount on the camcorder.

9. Macro button / macro ring

Press and hold the macro button and turn the macro ring to adjust the focus (minimum focus distance: 10 mm).

10. Iris ring

For manual iris adjustment, set the iris mode switch to the M (manual) position, then turn this ring.

[Note]

Always set the iris mode switch to the M (manual) position first and then adjust the iris.

11. Zoom lever / zoom ring

For manual zoom adjustment, set the zoom servo/manual switch to the MANU position, then operate the lever/ring.

12. Focus ring

Turn this ring to adjust the focus.

13. Zoom servo / manual knob

SERVO (servo): Selects power zoom. Operate the zoom with the zoom seesaw switch.

MANU (manual): Selects manual zoom. Operate the zoom with the zoom lever/zoom ring.

14. Power/iris control cable

Connect to the LENS connector on the camcorder.

15. VTR switch

Use this to start and stop recording. Press once to start recording, then press once more to stop.

16. Shtl (shuttle) switch (page 20)

Used for the shuttle shot function.

17. Zoom remote control connector

Connect to an optional zoom servo controller to enable remote control of zooming.

18. Memo switch (page 20)

Used for the shuttle shot function.

About shuttle shot

Shuttle shot is a shooting function for rapidly moving to a preset zoom position set by the user.

1 Set the DIP switch 1 to ON.


2 Set the zoom position that you want to register.

3 Press and hold the Memo switch and press the Shtl (shuttle) switch.

The zoom position is registered as the shuttle position.


To move rapidly to the shuttle position, press and hold the Shtl (shuttle) switch.

The zoom rapidly returns to the previous zoom position when the Shtl (shuttle) switch is released.



Lens Supplied with the PXW-X400KF

The PXW-X400KF is supplied with a lens.



1. PUSH AF (auto focus) button

When adjusting focus in manual mode, pressing this button enables auto focus adjustment on the subject.

Press the button to activate auto focus, and release the button when the subject is in focus.

2. FOCUS (adjustment mode) switch


A (Auto): Activates the normal auto focus function. You can also adjust the focus manually using the focus ring, even when the switch is in the "A" position.

M (manual): Selects manual mode for focus adjustment with the focus ring.

In manual mode, auto focus adjustment is also possible, by pressing the PUSH AF button.

3. MACRO switch

When this switch is in the ON position, macro mode is enabled, allowing focusing over the



whole range (5 cm ¹⁾ to ∞) including the macro range (from 5 cm ¹⁾ to 80 cm from the front of the lens).

This operation is independent of whether the focus adjustment mode is auto or manual.

¹⁾ At the wide-angle setting

4. Iris ring

For manual iris adjustment, set the IRIS switch to the M (manual) position, then turn this ring.

5. Zoom ring

For manual zoom adjustment, set the ZOOM switch to the MANUAL position, then turn this ring.

6. Focus ring

Turn this ring to adjust the focus.

When the ring is set to AF/MF mode, the faster you turn ring the faster the focusing mechanism

operates, minimizing the amount of turning required for focusing.

When you slide the focus ring back (toward the camcorder), the focus mode is set to Full MF mode, in which all focus adjustments are manual (page 42).

7. Flange focal length adjustment button

Press this to adjust the flange focal length (the distance from the lens mounting flange plane to the focusing plane) (page 26).

8. Zoom control connector (8-pin)

Connect to an optional zoom servo controller to enable remote control of zooming.

9. ZOOM switch

SERVO: Selects power zoom. Operate the zoom with the power zoom lever.

MANUAL: (manual): Selects manual zoom. Operate the zoom with the zoom ring.

10. PUSH AUTO (instant auto iris) button

When the IRIIS switch is in the M position for manual adjustment, press this button for instantaneous auto adjustment. The iris is automatically adjusted while the button is held down.

11. IRIIS (adjustment mode) switch

A (auto): The iris is adjusted automatically.

M (manual): Adjust the iris with the iris ring.

12. Power zoom lever

This is enabled when the ZOOM switch is in the SERVO position. Set to the W (wide angle) position when you want wide-angle, and set to the T (telephoto) side when you want telephoto. Press the lever harder for a faster zoom action, or softer for slower zoom action.

Notes about auto focus

- It may be difficult to focus on the subject in the following cases. If this does happen, use manual focusing.
 - If the subject has no contrast
 - If the subject is moving rapidly

- When shooting point light sources, under street lighting or at night

- When there are very bright objects close to the subject

- When shooting through a glass window

- If there are a number of objects within the screen at close and far range, the focus may not be on the intended subject. In this case, with the subject on which you want to focus in the center of the screen, press the PUSH AF button.
- After focusing with the PUSH AF button, if you operate the zoom or adjust the iris, the depth of field may become shallower, losing crisp focus. In such cases, press the PUSH AF button once more.

- If you focus at wide-angle then zoom to telephoto, the subject may no longer be in focus.

- It may take time until the image is in focus while using the slow shutter mode.

13. RET (return video) button

You can assign a function and use this as an assignable switch (page 114).


When "Lens RET" is assigned to this button (factory default setting), press this after recording stops to review the last few seconds recorded on the viewfinder screen (Rec Review) (page 47).

Press this button (single click) during recording or playback to record a Shot Mark 1 mark, or double-click to record a Shot Mark 2 mark (page 49).

14. VTR button

Use this to start and stop recording. Press once to start recording, then press once more to stop.

Viewfinder



8. Tally indicator

Lights up when recording is started by a press of the REC START button on this camcorder, the VTR button on the lens, or the START/STOP button on the remote control unit.

When an abnormality occurs, the tally indicator flashes to indicate a warning.

9. PEAKING knob

Turning this knob clockwise adjusts the picture sharpness, and makes focusing easier. This control has no effect on the output signals of the camcorder.

10. CONTRAST knob

Adjusts the contrast of the screen. This control has no effect on the output signals of the camcorder.

11. BRIGHT knob

Adjusts the brightness of the screen. This control has no effect on the output signals of the camcorder.

12. TALLY switch

Controls the tally indicator located on the front of the viewfinder.

HIGH: The tally indicator brightness is set to high.

OFF: The tally indicator is disabled.

LOW: The tally indicator brightness is set to low.

13. ZEBRA (zebra pattern) switch

Controls the zebra pattern display.

ON: Display a zebra pattern.

OFF: Do not display a zebra pattern.

14. DISPLAY switch

ON: Display text information.

OFF: Do not display text information.

15. MIRROR switch

The image display on the monitor screen becomes reversed horizontally or vertically when the viewfinder barrel is raised up or rotated.

L/R: Reverse the image horizontally.

OFF: Do not reverse the image.

B/T: Reverse the image vertically.

16. Microphone holder

1. Connector

Connect to the VF connector (26-pin) on the camcorder.

2. Viewfinder cable

Slide stopper

Prevents the viewfinder from coming off the camcorder when it is slid from side to side.

4. Eyecup

5. Diopter adjustment ring

Turn this ring to adjust the image until it is in sharpest focus.

6. Eyepiece

You can raise this up when required by the situation.

7. Viewfinder barrel

You can raise this up or rotate when required by the situation.

Preparing a Power Supply

For safety, use only the Sony battery packs and AC adaptors listed below.

- BP-FLX75 Lithium-ion Battery Pack

[CAUTION]

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer.

When you dispose of the battery, you must obey the law in the relative area or country.

For details on the battery charging procedure, refer to the battery charger operation manual.

Note on using the battery pack

A warm battery pack may not be able to be fully recharged.

Using a Battery Pack

Press the battery pack against the back of the camcorder, aligning the line on the side of the battery pack with the line on the camcorder. Then slide the battery pack down until its "LOCK" arrow aligns with the line on the camcorder.

To detach the battery pack, pull the battery pack up by holding the release button in.

[Notes]

- If the battery pack is not attached correctly, the terminals may become damaged.
- During recording and playback (while the ACCESS lamp on the right-side panel is lit in blue and the ACCESS lamp in the card slot section is lit in orange), be careful never to remove the battery pack.
Doing so may corrupt the data recorded on the card.
- Make sure to power the camcorder off before replacing the battery pack.

When a BP-FLX75 Battery Pack is used, the camcorder will operate continuously for approximately 170 minutes.

[WARNING]

Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

[Note]

The battery pack operating time depends on the frequency of use of the battery pack, and the ambient temperature when used.

Before use, charge the battery pack with a charger suitable for each battery.

Using AC Power

Mount an AC-DN2B/DN10 on the camcorder in the same way as a battery pack, then connect to the AC power supply.

Attaching a Viewfinder

This section describes the viewfinder supplied with the PXW-X400KC/PXW-X400KF models.

[CAUTION]

When the viewfinder is attached, do not leave the camcorder with the eyepiece lens facing the sun. Direct sunlight can enter through the lens, be focused in the viewfinder and cause fire.

[Note]

A viewfinder is supplied with the PXW-X400KC/PXW-X400KF models. A viewfinder for the PXW-X400 is available separately.


Attaching the Supplied Viewfinder

[Note]


When attaching a viewfinder, take note of the following points.

- Be sure to the power off the camcorder before coupling the viewfinder connector to the camcorder's VF connector (26-pin). If you make this connection when the camcorder power is on, the viewfinder may not function properly.
- Couple the viewfinder connector firmly to the camcorder's VF connector (26-pin). If the coupling is loose, noise may appear on the video or the tally light may not operate properly.

- 1 Loosen the viewfinder left-to-right positioning ring, [2] attach the viewfinder to the viewfinder fitting shoe, and [3] tighten the viewfinder left-to-right positioning ring.




- 2 Couple the viewfinder connector to the VF connector (26-pin).



You can detach the viewfinder by following the attaching procedure in reverse order. But, when detaching the viewfinder from the attachment shoe, pull up the stopper.


Adjusting the Viewfinder Position

To adjust the viewfinder left-right position, loosen the left-right positioning ring, and to adjust the front-back position, loosen the front-to-back positioning knob.



Adjusting the Viewfinder Angle

You can adjust the angle of the viewfinder.



Reversing the Display (image/text indication) Vertically

The viewfinder can be rotated as much as 180 degrees toward the direction facing the subject. When you do this, the picture and other information displayed in the viewfinder appear upside down.


To restore the normal display, set the MIRROR switch on the rear panel of the viewfinder to B/T.

Lifting Up the Viewfinder Barrel and Eyepiece

You can view the LCD screen inside the viewfinder or its mirrored image by lifting up the viewfinder barrel or the eyepiece.

- 1 Push the clip on the bottom to release and flip up the viewfinder barrel.


- 2 It locks at the 120-degree position.



Normally use it in the locked position. Although you can open it farther from the lock position, you must return it to the closed position to lock it at the 120-degree position again.


Detaching the Viewfinder Barrel

- 1 Push the clip on the bottom to release.
- 2 Flip up the viewfinder barrel.
- 3 Slide the knob on the top to the opposite side of the viewfinder barrel.
- 4 Detach the viewfinder barrel by horizontally sliding it.




Reversing the Display (image/text indication) Horizontally

By setting the MIRROR switch on the rear panel of the viewfinder to L/R, you can reverse the picture and other information displayed in the viewfinder horizontally.



Adjusting the Diopter

Turn the diopter adjustment ring until the viewfinder image is sharpest.



You can also attach a commercially available protection filter, close-up lens, etc. that is 52 mm in diameter.


Adjusting the Screen

Adjust the brightness, contrast, and peaking of the viewfinder screen with the controls shown below. Outlines: Adjust using the PEAKING knob. Contrast: Adjust using the CONTRAST knob. Brightness: Adjust using the BRIGHT knob.


Attaching the BKW-401 Viewfinder Rotation Bracket

By fitting an optional BKW-401 Viewfinder Rotation Bracket, you can rotate the viewfinder out of the way so that your right leg does not hit the viewfinder while you are carrying the camcorder.


- 1 Loosen the front-to-back viewfinder positioning levers and the front-to-back viewfinder positioning knobs, and then pull the viewfinder slide assembly forward.




- 2 Using a 2.5 mm diameter hexagonal wrench, detach the viewfinder slide assembly.



- 3 Attach the BKW-401 with the supplied bolts. Bolts supplied with the BKW-401



- 4 Adjust the front-to-back position so that the arm of the BKW-401 does not touch the handle when it is raised. Adjust position so that arm does not touch handle



Using the Camcorder for the First Time

When using the camcorder for the first time, configure the following settings in the menu.

For details about menu operations, see "Basic Setup Menu Operations" (page 86).

Setting the Time Zone


Set the time zone for the region of use. The default value is "UTC Greenwich."

- 1 Select Operation > Time Zone > Time Zone in the setup menu.
- 2 Select the time zone to use.

Setting the Date and Time of the Internal Clock

Set the year, month, day, and day-of-week of the internal clock.

- 1 Select Maintenance > Clock Set > Date in the setup menu.
The Date screen appears.




- 2 Turn the MENU knob to select the year, month, or day, and then press the knob.
The selected year, month, or day becomes editable.

- 3 Turn the MENU knob to set the year, month, or day, and then press the knob.

- 4 Repeat steps 2 and 3 to set the remaining digits.

- 5 Press the SET button.
The internal clock is set to the date set in steps 2 to 4.
Next, set the time.

- 6 Select Maintenance > Clock Set > Time in the setup menu.
The Time screen appears.



- 7 Set the time in the same way as when setting the date.

- 8 Press the SET button.
The time is registered in the internal clock.
To cancel the setting, press the Cancel button.

Mounting and Adjusting the Lens


[Note]

When connecting or disconnecting the lens cable to this connector, power off the camcorder first.

Attaching a lens

This section describes how to attach the lens supplied with the PXW-X400KF as an example.


- 1 Push the lens locking lever up and remove the lens mount cap from the lens mount.
- 2 Align the center pin on the lens with the center slot in the lens mount, and insert the lens into the mount.



- 3 Holding the lens in place, push the lens locking lever down to lock the lens.

[Caution]

If the lens is not firmly locked, it may come off while the camcorder is being used. This could cause a serious accident. Make sure the lens is firmly locked. It is recommended that the lens mount securing rubber be put on the lens locking lever as illustrated below.



- 4 Connect the lens cable to the LENS connector.
- 5 Secure the lens cable with the cable clamp.

If an aberration correction lens is attached

The aberration correction function is activated automatically. 1) Starting the camcorder with an aberration correction lens may require more time than normal because of data loading at start-up. The lens supplied with the PXW-X400 is an aberration correction lens. Contact a Sony sales or service representative for information about other aberration correction lenses.


- 1) The aberration correction function does not operate if Maintenance > Camera Config > ALAC in the setup menu is set to Off.

Adjusting the Flange Focal Length

If the lens does not stay in focus properly as you zoom from telephoto to wide angle, adjust the flange focal length (the distance from the plane of the lens mounting flange to the imaging plane, also called flange-back).

Make this adjustment just one time after mounting or changing the lens.

When carrying out the adjustment, use a flange focal length adjustment chart as the subject.



[Notes]

- If you use a subject with insufficient contrast, or move the camcorder or subject during adjustment, this will cause an adjustment error.
- Place the subject (the flange focal length adjustment chart) so that it appears at the center of the screen at the telephoto end. Arrange it so that no nearby object (no object closer to the camera than the chart) enters the screen at the wide-angle end.

Adjusting the flange focal length on the lens supplied with the PXW-X400KC

- 1 Place a subject (Siemens star chart, for example) 3 m (10 ft) in front of the camera.
- 2 Open the iris.
The depth-of-field is reduced when the iris is open, making adjustment easier.
- 3 Set the lens zoom to T (telephoto).
- 4 Adjust the focus on the subject.
- 5 Set the lens zoom to W (wide angle).
- 6 Loosen the F.B. lock screw on the lens, and turn the F.B. adjustment ring to adjust the focus.

- 7 Repeat steps 3 to 6 until the proper focus is achieved at both ends of the zoom ring.

- 8 When the optimum position of the F.B. adjustment ring is achieved, tighten the F.B. lock screw.

Adjusting the flange focal length on the lens supplied with the PXW-X400KF

With an auto focus lens, zoom and focus operations automatically adjust the flange focal length.

- 1 Place the supplied focal length adjustment chart about 3m (10 ft) in front of the camera.
- 2 Open the iris.
The depth-of-field is reduced when the iris is open, making adjustment easier.

- 3 Set the ZOOM switch to SERVO (power zoom mode).

- 4 Hold down the flange focal length adjustment button for 3 seconds.
The following message appears on the viewfinder screen.
Auto FB Adjust
Executing...

After successful adjustment, the message on the viewfinder screen changes to the following.

Auto FB Adjust
OK

If the flange focal length adjustment is not successful

Check the subject and lighting conditions, and repeat the adjustment.

Adjusting the flange focal length on manual lenses other than the PXW-X400KC/PXW-X400KF

- 1 Set the iris to manual.
- 2 Place the supplied flange focal length adjustment chart about 3m (10 ft) in front of the camera.
- 3 Open the iris.
The depth-of-field is reduced when the iris is open, making adjustment easier.
- 4 Loosen the fixing screws on the F.f or F.B ring (flange focal length adjustment ring).
- 5 Use manual or power zoom to set the lens to telephoto.
- 6 Point the camcorder at the chart by turning the focus ring and focus on it.
- 7 Set the zoom ring to wide angle.
- 8 Turn the F.f or F.B ring until the chart is in focus, being careful not to disturb the focus ring.
- 9 Repeat steps 5 to 8 until the chart stays in focus all the way from wide angle to telephoto.
- 10 Tighten the F.f or F.B ring fixing screws.


Preparing the Audio Input System

Connecting a Microphone to the MIC IN Connector

Attach the supplied microphone to the microphone holder of the supplied viewfinder.


- 1 Loosen the screw and open the microphone holder clamp.

Microphone holder clamp




- 2 Place the microphone in the microphone holder.

- [1] Place the microphone in the holder so that "UP" is at the top.
- [2] Close the microphone holder.
- [3] Tighten the screw.



manual for the microphone.

- 3 Plug the microphone cable into the MIC IN connector, then set the AUDIO IN switch for the channel on which you want to record the audio from this microphone to FRONT.



- 4 Secure the microphone cable with the cable clamp.

Connecting Microphones to the AUDIO IN Connectors

You can connect up to two monaural microphones to the AUDIO IN CH-1/CH-2 connectors, using an optional CAC-12 Microphone Holder.
Supported microphones: ECM-67/4/6/7/8 electret condenser microphone

For details about attaching the microphone holder and microphone, refer to the instruction manual of each product.

Attaching a Wireless Receiver

To use a Sony wireless microphone system, power the camcorder off and then attach a wireless receiver.

- DWR-S02D Digital Wireless Receiver
- WRR-855S, URX-S03D UHF Synthesized Tuner Unit

For details about attaching a wireless receiver, refer to the instruction manual of each product.

Connecting Line Input Audio Equipment


- 1 Connect the audio output connector of the audio equipment that supplies the line input signal to the AUDIO IN CH-1 or CH-2 connector.

- 2 Set the AUDIO IN selector for the channel to which the audio signal source is connected to LINE.

XLR connection automatic detect function

- With the XLR connection automatic detection function switched off (the factory default setting): Set the AUDIO IN CH1/CH2 switch to REAR for the channels to which the audio equipment is connected.
- With the XLR connection automatic detection function switched on: When a cable is connected to the AUDIO IN CH-1 or CH-2 connector, the input from that connector is automatically selected for audio recording, regardless of the setting of the AUDIO IN CH1/CH2 switch.

The XLR connection automatic detection function can be switched on/off using Maintenance > Audio > Rear XLR Auto in the setup menu.



- [1] Place the microphone in the holder so that "UP" is at the top.
- [2] Close the microphone holder.
- [3] Tighten the screw.


On how to attach the microphone, refer to the operation

Attaching and Adjusting Peripheral Devices

Mounting on a Tripod

- 1 Attach the optional VCT-14/U14 Tripod Adaptor to the tripod.


- 2 Mount the camcorder on the tripod adaptor.



Slide the camcorder forward along the groove in the adaptor until it clicks.

- 3 Make sure that the camcorder is securely attached by moving it back and forth.

To remove the camcorder from the tripod attachment, hold down the red button and pull the lever in the direction of the arrow.



[Note]

The tripod adaptor pin may remain in the engaged position even after the camcorder is removed. If this happens, press the red button and move the lever as shown above until the pin returns to the stowed position. If the pin remains in the engaged position, you will not be able to mount the camcorder on the tripod adaptor.

Connecting a Video Light

With this camcorder, you can use the Anton Bauer Ultralight 2 or equivalent video light (powered by 12 V with maximum power consumption of 50 W).

- If you connect the video light to the LiGHT connector on the camcorder and set the LiGHT switch to AUTO, you can turn the light on and off automatically as you start and stop recording on this camcorder.
- The output of the LiGHT connector on the camcorder is regulated to 12 V even when the camcorder is supplied with over 12 V power (through the DC IN connector or battery pack). The brightness or color temperature of the light will not change in response to voltage increase.

[Notes]

- Do not connect video lights with power consumption of 50 W or greater.
- The brightness or color temperature of the light will change when the voltage (supplied through the DC IN connector or from the battery pack) is less than 12 V.


To attach a video light, fit the video light to the accessory shoe on the camcorder grip, and connect the video light cable to the LiGHT connector.

[Note]

The accessory shoe on the camcorder is of the 1/4-inch tapped hole type. If you want to replace this with a slide-type shoe, use the supplied cold shoe kit.


Attaching the Shoulder Strap

- 1 Fit one of the clips to a shoulder strap fitting. Pull up the strap to lock the fitting.




- 2 Fit the other clip to the shoulder strap fitting on the other side of the grip in the same way.

To remove the shoulder strap, refer to the following diagram. Press here and pull in the direction shown by the arrow to release.




Adjusting the Shoulder Pad Position

You can slide the shoulder pad back and forth within a 40 mm range. This adjustment helps you get the best balance for shooting with the camcorder on your shoulder.



- 1 Raise the lever in the center of the shoulder pad to unlock the shoulder pad.
- 2 Slide the shoulder pad backward or forward until it is in the most convenient position.
- 3 Bring down the lever to lock the shoulder pad in the selected position.



Handling SxS Memory Cards

This camcorder records video and audio on SxS memory cards (not supplied) loaded into one or both of its memory card slots.

You can use the camcorder with the following devices to make recordings.

- MEAD-SD02 Media Adaptor (SDXC only supported) or QDA-EX1 XQD ExpressCard Adaptor

About SxS Memory Cards

SxS memory cards

Use Sony SxS memory cards (SxS PRO+, SxS PRO, or SxS-1) with this camcorder.


SxS PRO+ series
SxS PRO series
SxS-1 series

The memory cards listed above comply with the ExpressCard memory card standard.

- SxS, SxS PRO+, SxS PRO, and SxS-1 are trademarks of Sony Corporation.
- The ExpressCard label and logo are the property of the Personal Computer Memory Card International Association (PCMCIA) and are licensed to Sony Corporation. All other trademarks and trade names are the property of their respective owners.

Inserting SxS Memory Cards

- 1 Slide the cover to the left to open.
- 2 Insert an SxS memory card into a card slot.



[Note]


Make sure to insert the SxS card in the correct orientation. Hold the card with the arrow on one side facing the direction shown in the diagram, and then insert the card.

The ACCESS indicator lights in orange, and then lights in green to indicate that the memory card is usable.

- 3 Close the cover.

ACCESS indicator status

Card slots A and B each have an ACCESS indicator that indicate the slot status.




Indicator	Slot status
Lights in orange	Accessing the SxS memory card (lights during data reading and writing)

Indicator	Slot status
Lights in green	Standby (the loaded SxS memory card is ready for recording or playback)
Not lit	No SxS memory card is loaded. An unusable card is loaded. An SxS memory card is loaded, but the other slot is selected.

Ejecting SxS Memory Cards

- 1 Open the cover, and then press the EJECT button to release the lock and extract the button.




Press the button once to release the lock.

- 2 Press the EJECT button again to eject the card.

[Note]

When you press the EJECT button, take care not to impede the SxS memory card. If the movement of the SxS memory card is impeded, the lock may fail to release.



[Note]

Data integrity cannot be guaranteed if you power the camcorder off or remove a memory card while the card is being accessed. All data recorded on the card may be discarded. Always make sure that the ACCESS indicator is lit green or not lit before you power the camcorder off or remove a memory card.

Selecting the SxS Memory Card to Use

When SxS memory cards are loaded in both slot A and slot B, you can press the SLOT SELECT button to select the SxS memory card to use.

When the remaining recording time on the recording SxS memory card falls below 60 seconds, the remaining capacity indicator for the corresponding media slot flashes on the viewfinder screen to indicate that the camcorder will switch SxS memory cards soon.

Subsequently, the camcorder switches automatically to the other card when the selected card becomes full, and recording continues.

[Note]
The SLOT SELECT button is disabled during playback. The memory cards are not switched even if you press the button. Button operations are enabled when a thumbnail screen (page 78) is displayed.

Formatting (Initializing) SxS Memory Cards

When an unformatted SxS memory card or an SxS memory card formatted in another specification is inserted, a message notifying you that the media has a different file system appears. In this case, format the memory card in the following way. SxS memory cards are formatted in exFAT or FAT by factory default.

[Note]
SxS memory cards must be formatted on an XDCAM device that supports the exFAT or UDF file system or on this camcorder. Cards in other formats cannot be used.

- 1 Select Operation →Format Media in the setup menu.
- 2 Select Media(A) (slot A) or Media(B) (slot B).
- 3 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen prompting whether to format the card appears.
- 4 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.
Formatting begins.
During formatting, a message is displayed, and the ACCESS indicator is lit orange.
When formatting ends, a completion message appears. Press the MENU knob to dismiss the message.

If formatting fails

A format operation may fail because the SxS memory card is write protected, or because it is not the type of card specified for use with this camcorder.

In this case, an error message appears. Follow the instructions in the error message and exchange the card for an SxS memory card that can be used with this camcorder.

- [Notes]**
- Formatting a memory card erases all data, including recorded video data and setup files.
 - Use the format function of this camcorder to format SxS memory cards for use on this camcorder. The formats of cards formatted on other devices are not recognized as valid formats, making it necessary to format them again on this camcorder.

Checking the Remaining Recording Time

You can check the remaining capacity of the SxS memory cards loaded in the two slots by checking the recording media remaining capacity indicator in the viewfinder.

The remaining recording time is calculated from the remaining capacity of the media in each slot and the current video format (recording bit rate), and is displayed in units of minutes.

You can check the remaining capacity on a bar graph by displaying the Media Status screen (page 15).

[Note]
A  mark appears when a memory card is write protected.

When to exchange SxS memory cards

- The warning message “Media Near Full” appears, the WARNING indicator and the REC indication on the viewfinder screen flash, and the buzzer sounds when the total remaining recording

time of the two memory cards falls to five minutes during recording.

Exchange one of the cards for media with available recording capacity.

- If you continue recording, the message “Media Full” appears and recording stops when the total remaining recording time falls to 0.

[Note]
About up to 600 clips can be recorded on one SxS memory card.
The display of remaining recording time changes to “0” and the message “Media Full” appears when the clip limit is reached.

Restoring SxS Memory Cards

If for any reason an error should occur in a memory card, the card must be restored before use. When you load an SxS memory card that needs to be restored, a message appears in the viewfinder to ask whether you want to restore it.

To execute the restore, turn the MENU knob to select [Execute], and then press the knob. The restoration starts.

During restoration, a message is displayed, and the ACCESS indicator is lit orange.

When restoration ends, a completion message appears. Press the MENU knob to dismiss the message.

If restoration fails

- Write protected SxS memory cards and cards on which memory errors have occurred cannot be restored. A warning message appears for such cards. Follow the instructions in the message and unprotect the card or replace it with another card.
- SxS memory cards on which memory errors have occurred may become usable if they are reformatted.

- In some cases, some clips can be restored while others cannot. The restored clips can be played normally.
- If the message “Could not Restore Some Clips” keeps appearing after repeated attempts at restoration, it may be possible to restore the SxS memory card with the following procedure.
 - [1] Use the application software (page 147) to copy the required clips to another SxS memory card.
 - [2] Format the unusable SxS memory card on the camcorder.
 - [3] Copy the required clips back to the newly formatted SxS memory card.

Handling SD Cards for Saving Configuration Data

The following SD cards can be used for saving configuration data.

SDHC memory cards* (Speed Class: 4 to 10, non-UHS, Capacity: 4 to 32 GB)

* Referred to as "SD cards" in this manual.

Formatting (Initializing) SD Cards

SD cards must be formatted the first time they are used in the camcorder.

SD cards for use in the camcorder should be formatted using the format function of the camcorder. If a message appears when the SD card is inserted into the camcorder, format the SD card.

- 1 Select Operation >Format Media >SD Card (Utility) in the setup menu.
A confirmation screen prompting whether to format the card appears.

- 2 Turn the MENU knob to select [Execute], then press the knob.
Formatting begins.
During formatting, a message is displayed, and the ACCESS indicator is lit orange.
When formatting ends, a completion message appears. Press the MENU knob to dismiss the message.

[Note]

Formatting an SD card erases all data on the card. The card cannot be restored.

Checking the Remaining Capacity

You can check the remaining capacity on an SD card on the Media Status screen (page 15).

To use an SD card formatted on the camcorder in the slot of another device, make a backup of the card, then reformat the card in the device to be used.

Using a Media Adaptor

[Notes]

- For professional applications, the use of other media will not provide the same high reliability and durability that is obtained using SxS memory cards.
- Not all memory cards are guaranteed to work with this camcorder. For compatible memory cards, contact your Sony dealer.

XQD Memory Cards

By using an optional QDA-EX1 XQD ExpressCard Adaptor, you can insert an XQD memory card into the SxS memory card slot and use it instead of an SxS memory card.

For details about using a QDA-EX1 XQD ExpressCard Adaptor, refer to the instruction manual supplied with the adaptor.

[Notes]

- High-speed playback may not be properly achieved with an XQD memory card.
- Slow motion recording using the Slow & Quick Motion recording function cannot be used with an XQD memory card.

Formatting (initializing)

XQD memory cards must be formatted the first time they are used in the camcorder.

XQD memory cards for use in the camcorder should be formatted using the format function of the camcorder. If a message appears when the XQD memory card is inserted into the camcorder, format the XQD memory card.

If an unformatted XQD memory card or an XQD memory card that was formatted in a different specification is inserted, a message asking for confirmation to format media or a message notifying you that the media has a different file system appears.

- 1 Select Operation >Format Media in the setup menu.
- 2 Select Media(A) (slot A) or Media(B) (slot B).

- 3 Turn the MENU knob to select [Execute], then press the knob.

A confirmation screen prompting whether to format the card appears.

- 4 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Formatting begins.
During formatting, a message is displayed, and the ACCESS indicator is lit orange.

When formatting ends, a completion message appears. Press the MENU knob to dismiss the message.

[Note]

Formatting an XQD memory card erases all data on the card, including protected video. The data cannot be restored.

Connection between the camcorder and a computer

Insert the recorded XQD memory card into a slot in the camcorder, and connect the camcorder to a computer using a USB cable.

To use a memory card formatted on the camcorder in the slot of another device

First, make a backup of the card, then reformat the card in the device to be used.

SDXC Cards

By using an optional MEAD-SD02 Media Adaptor, you can insert an SDXC card into an SxS memory card slot and use it for recording and playback.

[Note]

Do not use SDXC cards at the same time as other memory cards. If a mix of cards are used at the same time, the camcorder cannot switch cards when the media becomes full.

The following SDXC cards are supported.

SDXC memory cards (SD speed class: Class 10)

For details about using an MEAD-SD02 Media Adaptor, refer to the instruction manual supplied with the adaptor.

[Notes]

- High-speed playback may not be properly achieved with an SDXC card.
- Slow motion recording using the Slow & Quick Motion recording function cannot be used with an SDXC card.
- Recording and playback using SDXC cards is not guaranteed when shooting in XAVC intra format.

Formatting (initializing)

SDXC cards must be formatted the first time they are used in the camcorder.

SDXC cards for use in the camcorder should be formatted using the format function of the camcorder. If a message appears when the SDXC card is inserted into the camcorder, format the SDXC card.

If an unformatted SDXC card or an SDXC card that was formatted in a different specification is inserted, a message asking for confirmation to format media or a message notifying you that the media has a different file system appears. Format the card using the following procedure.

- 1 Select Operation >Format Media in the setup menu.
- 2 Select Media(A) (slot A) or Media(B) (slot B).
- 3 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen prompting whether to format the card appears.
- 4 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.
Formatting begins.
During formatting, a message is displayed, and the ACCESS indicator is lit orange.

When formatting ends, a completion message appears. Press the MENU knob to dismiss the message.

[Notes]

- Formatting an SDXC card erases all data on the card, including protected video. The data cannot be restored.
- An SDXC card cannot be formatted in UDF mode.

Connection between the camcorder and a computer

Insert the recorded SDXC card into a slot in the camcorder, and connect the camcorder to a computer using a USB cable.

To use a memory card formatted on the camcorder in the slot of another device

First, make a backup of the card, then reformat the card in the device to be used.

XQD is a registered trademark of Sony Corporation.

Format Settings

You can set the recording mode, system frequency, and video format using Operation >Format in the setup menu.

For details about menu operations, see “Basic Setup Menu Operations” (page 86).

Selecting the Recording Mode

You can select exFAT or UDF recording mode.

- 1 Select Operation >Format >File System in the setup menu.
- 2 Turn the MENU knob to select exFAT or UDF, and press the knob.
A confirmation screen appears.

- 3 Select [Execute] to execute, or select [Cancel] to cancel, and then press the MENU knob.
The camcorder will reboot automatically after executing [Execute].

[Note]

The recording mode cannot be changed during recording/playback or while the thumbnail screen is displayed.

Switching the System Frequency

You can switch the system frequency as required.

[Notes]

- The system frequency cannot be changed during recording/playback or while the thumbnail screen is displayed.
- After switching between 29.97 and 59.94 or between 25 and 40, the camcorder does not reboot automatically.

- 1 Select Operation >Format >Frequency in the setup menu.
- 2 Turn the MENU knob to select the system frequency, and press the knob.
A confirmation screen appears.
- 3 Select [Execute] to execute, or select [Cancel] to cancel, and then press the MENU knob.
The camcorder will reboot automatically after executing [Execute].

Switching the Video Format

Refer to “Video Formats” (page 34) as required when switching the video format.

- 1 Select Operation >Format >Rec Format in the setup menu.
- 2 Turn the MENU knob to change the video format, and press the knob.
A confirmation screen appears.
- 3 Select [Execute] to execute, or select [Cancel] to cancel, and then press the MENU knob.

Video Formats

The following recording formats can be selected for different combinations of video resolution and system frequency.

System frequency	Video format (Operation >Format >Rec Format in setup menu)	Picture size
59.94/50	XAVC-I 1920×1080P	1920×1080
	XAVC-I 1920×1080i	
	XAVC-I 1280×720P	1280×720
	XAVC-L 50 1920×1080P	1920×1080
	XAVC-L 50 1920×1080i	1920×1080
	XAVC-L 50 1280×720P	1280×720
	XAVC-L 35 1080P	1920×1080
	XAVC-L 35 1080i	
	XAVC-L 25 1080i	
	HD422 50 1080i ^{a)}	1920×1080
	HD422 50 720P ^{a)}	1280×720
	HQ 1920×1080i ^{a)}	1920×1080
	HQ 1440×1080i ^{a)}	1440×1080
	HQ 1280×720P ^{a)}	1280×720
	MPEG IMX 50 ^{a)}	720×486/720×576
	DVCAM ^{a)}	720×480/720×576

System frequency	Video format (Operation >Format >Rec Format in setup menu)	Picture size
29.97/25/23.98	XAVC-I 1920×1080P	1920×1080
	XAVC-L 50 1920×1080P	
	XAVC-L 35 1080P	
	HD422 50 1080P ^{a)}	
	HD422 50 720P ^{a)}	
	HQ 1920×1080P ^{a)}	1920×1080

a) exFAT and UDF files systems are supported. Only exFAT is supported for other options.

SDI OUT Connector and HDMI Output Connector Output Formats

The signals that can be output from the SDI OUT connector and HDMI output connector are shown in the following table according to the Operation >Format setting in the setup menu.

Operation menu			
Format	Input/Output		
Frequency	Rec Format (codec omitted)	Output Format	HDMI
59.94	1920×1080P	1920×1080P (Level A)	1920×1080P
		1920×1080P (Level B)	No signal
		1920×1080i	1920×1080i
		720×486i	720×480i
		1920×1080i	1920×1080i
	1440×1080i	1920×1080i	1920×1080i
		720×486i ^{a)}	720×480i ^{a)}
		1280×720P	1280×720P
		720×486i	720×480i
		720×480i	720×480i
29.97	1920×1080P	No signal	720×480P
		1920×1080P5F	1920×1080i
		720×486i	720×480i
	1280×720P	1280×720P	1280×720P
		720×486i	720×480i
		720×480i	720×480i

Operation menu			
Format	Input/Output		
Frequency	Rec Format (codec omitted)	Output Format	HDMI
23.98	1920×1080P	1920×1080P5F	No signal
		1920×1080i (2-3PD)	1920×1080i (2-3PD)
		720×486i (2-3PD)	720×480i (2-3PD)
		1280×720P (2-3PD)	1280×720P (2-3PD)
		720×486i (2-3PD)	720×480i (2-3PD)
	1280×720P	1920×1080P (Level A)	1920×1080P
		1920×1080P (Level B)	No signal
		1920×1080i	1920×1080i
		720×576i	720×576i
		1920×1080i	1920×1080i
25	1920×1080P	1920×1080P5F	1920×1080i
		720×576i	720×576i
		1280×720P	1280×720P
		720×576i	720×576i
		1280×720P	1280×720P
	1280×720P	1920×1080P5F	1920×1080i
		720×576i	720×576i
		1280×720P	1280×720P
		720×576i	720×576i
		1280×720P	1280×720P

a) Switches to 1920×1080i when proxy recording or wireless LAN connection function is on.

VIDEO Connector Output Formats

The signals that can be output from the VIDEO connector are shown in the following table according to the Operation >Format setting in the setup menu.

Operation menu		VIDEO OUT signal format	
Format		Proxy recording/Wireless LAN connection function	
Frequency	Rec Format (codec omitted)	OFF	ON
59.94	1920×1080P	HD Y	HD Y
		HD Y	HD Y
		HD Y	HD Y
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
	1920×1080i	HD Y	HD Y
		Composite	Composite ^{c)}
	1440×1080i	HD Y	HD Y
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
29.97	1280×720P	HD Sync ^{a)}	HD Sync ^{a)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
	1920×1080P	HD Y	HD Y
		Composite	Composite ^{c)}
	1280×720P	HD Y ^{b)}	HD Y ^{b)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
23.98	1920×1080P	HD Y	HD Y
		HD Y/HD Sync	HD Y
		Composite	Composite ^{c)}
	1280×720P	HD Y ^{b)}	HD Y ^{b)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}

Operation menu		VIDEO OUT signal format	
Format		Proxy recording/Wireless LAN connection function	
Frequency	Rec Format (codec omitted)	OFF	ON
50	1920×1080P	HD Y	HD Y
		HD Y	HD Y
		HD Y	HD Y
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
	1920×1080i	HD Y	HD Y
		Composite	Composite ^{c)}
	1440×1080i	HD Y	HD Y
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
25	1280×720P	HD Sync ^{a)}	HD Sync ^{a)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}
	1920×1080P	HD Y	HD Y
		Composite	Composite ^{c)}
	1280×720P	HD Y ^{b)}	HD Y ^{b)}
		Composite	Composite ^{c)}
		Composite	Composite ^{c)}

a) 1080i sync signal output.
b) 1080PSF sync signal output.
c) Character information (superimposed) turns on/off in sync with the SDI OUT2/HDMI character information display switching.

Adjusting the Black Balance and White Balance

To ensure excellent image quality when using this camcorder, conditions may require that both the black balance and the white balance be adjusted. Black balance and white balance adjustment values that are automatically set by the camcorder and the various settings are stored in the camcorder memory and retained even when the power is turned off.

Adjusting the Black Balance

The black balance will require adjustment in the following cases.

- When the camcorder is used for the first time
 - When the camcorder has not been used for a long time
 - When the camcorder is used under conditions in which the surrounding temperature has changed greatly
 - When the GAIN selector (L/M/H/Turbo) values have been changed with Operation >Gain Switch in the setup menu.
- It is not usually necessary to adjust the black balance when using the camcorder after it has been off.

In automatic black balance mode, adjustments are performed in the following order: black set and black balance. Manual black balance adjustment can be selected from the setup menu.

Automatic black balance adjustment is disabled in the following cases.

- During recording
- During special recording modes
- When the shutter mode is SLS

- 1 Set the OUTPUT/DCC switch to CAM.

- 2 Push the AUTO W/B BAL switch to BLACK and release the switch.

The message “Executing...” appears during execution, and changes to “OK” when the adjustment finishes. Adjustment values are saved to memory automatically.

[Notes]

- During the black balance adjustment, the iris is automatically closed.
- During the black balance adjustment, the gain selection circuit is automatically activated so you may see flickering on the viewfinder screen, but this is not a fault.

If automatic black balance adjustment cannot be made

If the black balance adjustment cannot be completed normally, an error message will appear for about three seconds on the viewfinder screen.

Error message	Meaning
NG: Iris not Closed	The lens iris did not close; adjustment was impossible.
NG: Timeout	Adjustment could not be completed within the standard number of attempts.

If any of the above error messages is displayed, retry the black balance adjustment.

If the error message occurs again, an internal check is necessary.

For information about this internal check, refer to the Maintenance Manual.

[Note]

If the lens cable is not firmly connected to the LENS connector, it may not be possible to adjust the lens iris. If this happens, the black balance will be incorrect.

Adjusting the White Balance

Always readjust the white balance when the lighting conditions change.

- 1 Set the switches and selectors as shown below.


- GAIN switch: L (set to a gain value that is as small as possible)
 - OUTPUT/DCC switch: CAM
 - WHITE BAL switch: A or B¹⁾
- 1) Adjustment values are saved to memory B only when Operation >White Setting >White Switch in the setup menu is set to Memory.

- 2 Set the FILTER knob to suit the lighting conditions as follows.

- 3 Place a white test card under the same lighting conditions as the subject to be shot and zoom in on it.

Alternatively, any white object such as a cloth or a wall can be used. The absolute minimum white area is as follows.

Rectangle centered on the screen
The lengths of the sides are 70% of the length and width of the screen. 10% or more of the surface area of the image within the rectangular area must be white.



[Note]

Make sure there are no bright spots in the rectangle.

- 4 Adjust the lens iris.
Iris is adjusted manually. Set the iris to an appropriate setting.

Iris adjusted using auto iris: Set the automatic/manual switch on the lens to automatic.

- 5 Push the AUTO W/B BAL switch to WHITE and then release the switch.

The message “Executing...” appears during execution, and changes to “OK: (color temperature of subject)” when the adjustment finishes.

The adjustment values are saved automatically in the memory selected in step 1 (A or B).

[Note]

The iris may hunt¹⁾ during the adjustment. To prevent this, adjust the iris gain knob (indicated as Ig, Is, or S) on the lens.

- 1) Hunting: Repeated brightening and darkening of the image, resulting from repeated response to automatic iris control.

For details, refer to the lens operation manual.

If the automatic white balance adjustment cannot be made

If the white balance adjustment cannot be completed normally, an error message will appear for about three seconds on the viewfinder screen.

Error message	Meaning
NG: Low Light	The white video level is too low. Either open the lens iris or increase the gain.
NG: High Light	The white video level is too high. Either stop down the lens iris or change the ND filter.
NG: Color Temp. High	The color temperature of the subject lighting is too high, and could not be adjusted. Adjust the color temperature of the lighting, then update memory.

Error message	Meaning
NG: Color Temp. Low	The color temperature of the subject lighting is too low, and could not be adjusted. Adjust the color temperature of the lighting, then update memory.
NG: Out of Range	Value could not be adjusted because the difference between the current value and reference value exceeds the adjustment range.
NG: Poor White Area	The white surface of the subject is too narrow, and could not be adjusted.
NG: Timeout	Adjustment could not be completed within the standard number of attempts. Adjustment could not be completed within the specified time.

If any of the above error messages is displayed, retry the white balance adjustment. If the error message occurs again, an internal check is necessary.

For information about this internal check, refer to the Maintenance Manual.

If you have no time to adjust the white balance

Set the WHITE BAL switch to PRST.

Changing the color temperature when the ND filter is switched

You can assign electrical CC (color correction) filters to ND filters (page 5) allowing you to change the color temperature automatically when the ND filter is switched.

- 1 Set Maintenance >White Filter >ND Filter C. Temp to On in the setup menu (page 107).

- 2 To assign an electrical CC filter to FILTER knob position number 1, select [ND FLT C. Temp<1>]. To assign it to positions 2 to 4, select [ND FLT C.Temp<2-4>].

- 3 Turn the MENU knob to select the desired color temperature.

- 4 Repeat steps 2 and 3 as required.

Switching electrical CC filters with an assignable switch

You can assign the function that switches between electrical CC filters to an assignable switch. This allows you to switch between color temperatures (3200K/4300K/5600K/6300K) that have been assigned using up to four positions (A to D) with each press of the assignable switch.

Regardless of assignments to assignable switches, you can also switch between the color temperatures assigned to each position from a RM-B170/B750 Remote Control Unit.

- 1 Select Maintenance >White Filter in the setup menu.

- 2 Select the position to which to assign a CC filter by selecting one of [Electrical CC<A>] to [Electrical CC <D>], and then turn the MENU knob to select the desired color temperature. Select "-----" with Electrical CC <C> or <D> selected.

When the assignable switch is pressed, the setting for that position is not displayed. For example, if "-----" is set for one position, then switching between the remaining three positions is carried out.

- 3 Repeat step 2 as required.

- 4 Assign the electrical CC filter switching function (ELECTRICAL CC) to an assignable switch (page 115).

White balance memory

Values stored in memory are held until the white balance is next adjusted, even if the camcorder power is turned off.

The camcorder has two white balance memories, A and B. You can automatically save adjustment values for each ND filter in the memory that corresponds to the WHITE BAL switch setting (A or B). The camcorder has four built-in ND filters, allowing you to save a total of eight adjustment values (4x2). However, the contents of the memories are not linked to ND filter settings in the following cases.

- When the number of memories allocated to each of A and B is limited to one by setting Operation >White Setting >Filter White Memory in the setup menu to Off.

- When the electrical CC filter switching function has been assigned to an assignable switch, or when a remote control unit has been connected. (In these cases, the contents of white balance memory are linked to electrical CC filter positions (A to D).)

Also, when Operation >White Setting >White Switch in the setup menu is set to [ATW (Auto Tracing White Balance)], and the WHITE BAL switch is set to B, the ATW function is activated to automatically adjust the white balance of the picture being shot for varying lighting conditions.

Setting the Electronic Shutter

Shutter Modes

The shutter modes that can be used with the electronic shutter and the shutter speeds that can be selected are listed below.

[Note]

When a remote control unit, such as the RM-B170, is connected, only standard mode (Speed) can be selected.

Standard mode

Select this mode for shooting fast-moving subjects with little blurring.

You can set the shutter speed in one of two shutter modes: Speed mode, in which the speed is set in seconds, and Angle mode, in which the speed is set in degrees.

Speed mode

System frequency	Shutter speed (unit: seconds)
59.94i	1/60, 1/100, 1/120, 1/125, 1/250, 1/500,
59.94P	1/1000, 1/2000
50i	
50P	
29.97P	1/40 ^{a)} , 1/50 ^{a)} , 1/60, 1/100, 1/120, 1/125, 1/250, 1/500, 1/1000, 1/2000
25P	1/33 ^{a)} , 1/50 ^{a)} , 1/60, 1/100, 1/120, 1/125, 1/250, 1/500, 1/1000, 1/2000
23.98P	1/32 ^{a)} , 1/48 ^{a)} , 1/50 ^{a)} , 1/60, 1/96, 1/100, 1/120, 1/125, 1/250, 1/500, 1/1000, 1/2000

a) This speed cannot be selected when the camcorder is in Slow & Quick Motion mode and Operation >Rec Function >Frame Rate in the setup menu is set to a value that is greater than the system frequency.

Angle mode

180°, 90°, 45°, 22.5°, 11.25°

ECS (Extended Clear Scan) mode

Select this mode for obtaining images with no horizontal bands of noise when shooting subjects such as monitor screens.

As shown in the following tables, the range of shutter speeds that can be set varies depending on whether the Slow & Quick Motion (S&Q) function is on or off.

System frequency	Shutter speed (unit: Hz)	S&Q: Off	S&Q: On
59.94i	60.00 to 7000	—	—
59.94P	60.00 to 8000	60.00 to 8000	—
29.97P	30.00 to 8000	30.00 to 8000	—
23.98P	23.99 to 6000	30.03 to 6000	—
50i	50.00 to 7000	—	—
50P	50.00 to 7000	50.00 to 7000	—
25P	25.02 to 7000	30.00 to 7000	—

SLS (slow speed shutter) mode

This mode is used to shoot subjects with low illumination. The number of accumulated frames shot when using the slow speed shutter function can be set to 2, 3, 4, 5, 6, 7, 8, 16 using Operation >Slow Shutter >Number of Frames in the setup menu.

- SLS mode cannot be used when the camcorder is in Slow & Quick Motion mode.
- It is not possible to turn the SLS mode on or off, or change the number of accumulated frames when recording.

Setting the Shutter Mode and Shutter Speed

- The selectable shutter speeds vary depending on the current system frequency.

Switching between Speed mode and Angle mode

- 1 Select Operation >Shutter >Mode in the setup menu.
- 2 Turn the MENU knob to select [Speed] or [Angle], and then press the knob.

Setting the shutter mode and shutter speed (standard mode)

Once the shutter speed is selected, it is retained even when the camcorder power is turned off.

- 1 Push the SHUTTER switch from ON to SELECT. The current shutter setting indication appears in the viewfinder for about three seconds.

Setting the shutter speed (ECS mode)

- 1 Set the shutter mode to ECS (see the previous item).
- 2 Turn the MENU knob to select the desired frequency or number of frames.

Setting the shutter speed (SLS mode)

- 1 Select Operation >Slow Shutter >Setting in the setup menu and set the shutter mode to On.
- 2 Select Operation >Slow Shutter >Number of Frames in the setup menu and select the desired number of frames.

- 2 Before the shutter setting in step 1 disappears, push the SHUTTER switch down to SELECT again. Repeat this step until the desired mode or speed appears.

When all modes and speeds are displayed, the display changes in the following order.

Speed Mode (with system frequency 59.94i)



[Note] Depending on the frame rate setting (page 50), some shutter speeds cannot be selected in Slow & Quick Motion mode. These speeds are replaced by the slowest selectable shutter speed.

Example when shooting in XAVC-I 1080P/29.97P, frame rate of 60, and Slow & Quick Motion:

- Slow & Quick Motion mode: Off
1/40→1/50→1/60→1/100→...
- Slow & Quick Motion mode: On
1/60→1/100→...

- [Notes] When the automatic iris is used, the iris opens wider as the shutter speed increases, thus reducing the depth of field.

Setting Auto Iris

The reference value for automatic iris adjustment can be changed to aid the shooting of clear pictures of back-lit subjects, or to prevent blown-out highlights.

Setting the Auto Iris Operating Mode

Set the operating mode used when adjusting levels using auto iris.

- 1 Select Operation >Auto Iris >Mode in the setup menu.
- 2 Turn the MENU knob to select the operating mode, then press the knob.

Operating mode	Description
Backlight	Mode for shooting in backlight conditions
Standard	Standard mode
Spotlight	Mode for reducing blown out highlights when there are spotlights centered on a subject.

Set the target convergence level for auto iris

- 1 Select Operation >Auto Iris >Level in the setup menu.
- 2 Turn the MENU knob to select the level in the range -99 to +99, then press the knob.

Convergence level	Description
-99	Sets the iris 2 f-stops or more darker
±0	Reference level
+99	Sets the iris 2 f-stops or more lighter

Setting the auto iris speed

Set the operating speed when adjusting levels using auto iris.

- 1 Select Operation >Auto Iris >Speed in the setup menu.
- 2 Turn the MENU knob to select the speed in the range -99 (slowest) to +99 (fastest), then press the knob.

Changing the Reference Value of the Lens Iris

The reference value for the lens iris can be set within the following range with respect to the standard value.

- +0.25 to +1 (increments of 0.25): About 0.25 to 1 stop further open
- -0.25 to -1 (increments of 0.25): About 0.25 to 1 stop further closed

Also you can set the area where light detection occurs.

- 1 Set Operation >Auto Iris >Iris Override in the setup menu to On.
- 2 Set the MENU ON/OFF switch to OFF.

- 3 Turn the MENU knob to change the reference value.

[Note]
Be sure to confirm that the current shutter mode is not ECS.

The current reference value is shown by the iris position indicator (page 16) on the viewfinder screen.


- To open the iris slightly, turn the MENU knob counterclockwise as seen from the front of the camcorder.
- Select one of +0.25, +0.5, +0.75, or +1.
- To close the iris slightly, turn the MENU knob clockwise as seen from the front of the camcorder.
- Select one of -0.25, -0.5, -0.75, or -1.

The changed reference value is retained until the power of the camcorder is turned off. Even if the reference value is changed, it reverts to the standard value every time the power is turned on.

Setting the Auto Iris Detection Window

- 1 Set Operation >Auto Iris >Detect Window Indication in the setup menu to On.
The current automatic iris window appears on the viewfinder screen.
If it is not necessary to display the auto iris window on the screen, set to Off.

- 2 Select Operation >Auto Iris >Detect Window in the setup menu.
- 3 Turn the MENU knob until the desired auto iris window appears, and then press the knob.



The shaded parts indicate the area of light detection.

If you select Var, the following items become effective and you can set the window of the desired size. Set Operation >Auto Iris >Iris Var Width, Iris Var Height, Iris Var, Iris Var H Position, and Iris Var V Position in the setup menu.

Item	setting
Iris Var Width	The width of the window
Iris Var Height	The height of the window
Iris Var H Position	The position of the window in the horizontal direction
Iris Var V Position	The position of the window in the vertical direction.

When you exit the menu, the auto iris window selected in step 3 appears.
Unless you need to keep this window displayed, set Operation >Auto Iris >Detect Window Indication in the setup menu to Off.

Reducing the Effect of Bright Highlights

If the subject is too bright, the iris may close too much, leaving the overall image dark, a condition known as clipped blacks. In such cases, switching the clip highlight function on will clip the signal above a certain level, reducing the effects of the auto iris.

Set Operation >Auto Iris >Clip High Light in the setup menu to On.

Adjusting the Iris Gain on the Lens Supplied with the PXW-X400K

- 1 Set the iris mode switch to the A (auto) position.
- 2 Flip off the rubber cap of the iris gain adjustment trimmer.
- 3 Turn the iris gain adjustment trimmer using a screwdriver, or similar object, to adjust the gain.
Turn clockwise to increase the gain. Turn counterclockwise to decrease the gain.
Adjust while watching the iris ring on the lens body.
- 4 Reattach the rubber cap.

Adjusting the Focus

This section describes the focus adjustment when using the lens supplied with the PXW-X400KF.

[Note]

The lens is designed with an extra margin at the infinity position (∞), to compensate for focus drifting due to variations in temperature. When shooting a subject at infinity in MF or Full MF mode, check the picture in the viewfinder as you focus.

One-push Auto Focus

Press the PUSH AF button. The auto focus activates temporarily.

The one-push auto focus stops when the subject comes into focus.

Adjusting in Full MF Mode

When you slide the focus ring back (toward the camcorder), the focus mode is set to Full MF mode for full manual focus adjustment.

[Note]

When you slide the focus ring back, the focus instantly moves to the marker position.

Focus by turning the focus ring while viewing the viewfinder.

The distance indications on the ring are valid in Full MF mode. The distances where the picture is in focus correspond to absolute positions of the focus ring.

Peaking

You can turn the PEAKING knob on the viewfinder to use the peaking function. Edges are emphasized in the monitor picture, which facilitates manual focusing.

The recorded video signals are not affected.

Using the Focus Ring

Adjust the focus by turning the focus ring while viewing the viewfinder.

The distance indications on the ring are invalid in MF mode.

MF Assist Function

When the MF assist function is on (page 115), auto focus is activated after you stop focusing using the focus ring and provides fine control adjustment of the focus of the subject in the center of the display (focus tracking).

When fine adjustment stops, the MF assist auto focus operation ends.

Adjusting in AF Mode

When you slide the focus ring forward and set the FOCUS switch to A (auto), the focus mode becomes AF mode, in which auto focus is available continuously.

The distance indications on the ring are invalid in AF mode.

Using Macro Mode

When the focus mode is MF or AF, set the MACRO switch to the ON position to enable macro mode.

Macro mode allows you to adjust the focus over a range that includes the macro area.

Macro mode is disabled in Full MF mode.


Adjusting the Audio Level

When you set the AUDIO SELECT switch to AUTO, the input levels of analog audio signals recorded on each channel are adjusted automatically. You can also make manual adjustments.

[Note]
Even if you set the AUDIO SELECT switch to AUTO, the input levels of digital audio signals are not adjusted automatically.

Target Audio Level for Manual Adjustment

Make adjustment using -20 dB as the target level. If the audio level meter shows a maximum level of 0 dB, then it indicates that the input audio level is excessive.



Manually Adjusting the Audio Levels of the Audio Inputs from the AUDIO IN CH-1/CH-2 Connectors

- 1 To adjust the signal input to the AUDIO IN CH-1 or CH-2 connector, set the AUDIO IN CH1 or CH2 switch to REAR.
To adjust both input signals, set both switches to REAR.

- 2 Set the AUDIO SELECT switch(es) corresponding to the channel(s) selected in step 1 to MANUAL.
- 3 With the LEVEL knob(s) for the channel(s) selected in step 1, adjust so that the audio level meter shows up to -20 dB for a normal input volume.

Selecting the knob used for adjusting the recording level

In Maintenance > Audio in the setup menu, you can select which audio level control controls the audio recording level of the input to each of the AUDIO IN CH-1/CH-2 connectors. The correspondences between the settings of the menu items and the controls are as follows.

[Note]
If an AES/EBU digital audio signal is input, the recording level cannot be adjusted using the camcorder.

Rear1/WRR Level: Channel 1 recording level

Setting	Knob
Side1	LEVEL (CH1) knob
Front	MIC LEVEL knob
Front+Side1	LEVEL (CH1) knob and MIC LEVEL knob (linked operation)
Rear2/WRR Level: Channel 2 recording level	
Setting	Knob
Side2	LEVEL (CH2) knob
Front	MIC LEVEL knob
Front+Side2	LEVEL (CH2) knob and MIC LEVEL knob (linked operation)

[Note]
When you have operation of the LEVEL (CH1/CH2) knobs and MIC LEVEL knob linked together, if the MIC LEVEL knob is set to 0, the audio signals on channels 1 and 2 cannot be recorded. Check the position of the MIC LEVEL knob before adjusting the LEVEL (CH1/CH2) knobs.

Manually Adjusting the Audio Level of the MIC IN Connector

- 1 Set either or both of the AUDIO IN switch(es) to FRONT.
- 2 Set the AUDIO SELECT switch(es) for the desired channel(s) selected in step 1 to MANUAL.
- 3 Turn the MIC LEVEL knob, and adjust so that the audio level meter shows up to -20 dB for a normal input volume.

Selecting the knob used for adjusting the recording level

In Maintenance > Audio in the setup menu, you can select which audio level control controls the audio recording level of the front microphone input. The correspondences between the settings of the menu items and the controls are as follows.

MIC CH1 Level: Channel 1 recording level	
Setting	Knob
Side1	LEVEL (CH1) knob
Front	MIC LEVEL knob
Front+Side1	LEVEL (CH1) knob and MIC LEVEL knob (linked operation)
MIC CH2 Level: Channel 2 recording level	
Setting	Knob
Side2	LEVEL (CH2) knob
Front	MIC LEVEL knob
Front+Side2	LEVEL (CH2) knob and MIC LEVEL knob (linked operation)

[Note]
When you have operation of the MIC LEVEL knob and LEVEL (CH1/CH2) knobs linked together, if the LEVEL (CH1/CH2) knobs are set to 0, the audio signals on channels 1 and 2 cannot be recorded. Check the position of the LEVEL (CH1/CH2) knobs before adjusting the MIC LEVEL knob.

Recording Audio on Channels 3 and 4

- 1 Select the audio recorded on audio channels 3 and 4 with the AUDIO IN CH3/CH4 switches.

CH3 switch	Channel 3 recording target
FRONT	Front microphone audio
REAR	Audio signal input to AUDIO IN CH1 connector
WIRELESS	Wireless microphone audio
CH4 switch	Channel 4 recording target
FRONT	Front microphone audio
REAR	Audio signal input to AUDIO IN CH2 connector
WIRELESS	Wireless microphone audio

- 2 To adjust automatically, set the AUDIO SELECT CH 3-4 switch to AUTO.
To adjust manually, set the AUDIO SELECT CH 3-4 switch to MANUAL.
- 3 Select the knobs that adjust the audio levels with the Audio CH3 Level and Audio CH4 Level items under Maintenance > Audio in the setup menu.

Audio CH3 Level: Channel 3 recording level	
Setting	Knob
Side3	LEVEL (CH3) knob
Front	MIC LEVEL knob

Setting	Knob
Front+Side3	LEVEL (CH3) knob and MIC LEVEL knob (linked operation)

Audio CH4 Level: Channel 4 recording level

Setting	Knob
Side4	LEVEL (CH4) knob
Front	MIC LEVEL knob
Front+Side4	LEVEL (CH4) knob and MIC LEVEL knob (linked operation)

You can now adjust the levels of audio channels 3 and 4 with the knobs selected here.

Setting Time Data

Setting the Timecode

The timecode setting range is from 00:00:00:00 to 23:59:59:29 (hours:minutes:seconds:frames).

- 1 Press the DISP SEL/EXPAND button to switch the display in the LCD monitor to status display.
- 2 Set the DISPLAY switch to TC.
- 3 Set the PRESET/REGEN/CLOCK switch to PRESET.
- 4 Set the F-RUN/SET/R-RUN switch to SET. The first (leftmost) digit of the timecode flashes.
- 5 Use the up and down arrow buttons to change values, and use the left and right arrow buttons to move the flashing digit. Repeat until all digits are set. To reset the value to 00:00:00:00, press the RESET/RETURN button.

- 6 Set the F-RUN/SET/R-RUN switch to F-RUN or R-RUN.
F-RUN: Free run (timecode generator keeps running)
R-RUN: Recording run (timecode generator runs only while recording)

[Note]

When picture cache mode is active, time data cannot be set by switching the F-RUN/SET/R-RUN switch to SET. To set time data, turn picture cache mode off.

Switching between Df and NDF

You can select the drop frame (Df) mode or non-drop frame (NDF) mode using Maintenance > Timecode > Df/NDF in the setup menu.

To make the timecode consecutive

When the F-RUN/SET/R-RUN switch is set to R-RUN, recording a number of scenes on the media normally produces consecutive timecode. However, once you remove the media and record on another media, the timecode will no longer be consecutive when you use the original media again for recording.

In this case, to make the timecode consecutive, set the PRESET/REGEN/CLOCK switch to REGEN.

Saving the real time in the timecode

Setting the PRESET/REGEN/CLOCK switch to CLOCK saves the real time in the timecode. The time of the camcorder internal clock is applied as the real time.

For details about adjusting the internal clock, see "Setting the Date and Time of the Internal Clock" (page 25).

Setting the User Bits

By setting the user bits (up to 8 hexadecimal digits), you can record user information such as the date, time, or scene number on the timecode track.

- 1 Press the DISP SEL/EXPAND button to switch the display in the LCD monitor to status display.
- 2 Set the DISPLAY switch to U-BIT.
- 3 Set the F-RUN/SET/R-RUN switch to SET. The first (leftmost) digit flashes.
- 4 Use the up and down arrow buttons to change values, and use the left and right arrow buttons to move the flashing digit. Repeat until all digits are set.

To reset the value to 00 00 00 00, press the RESET/RETURN button.

- 5 Set the F-RUN/SET/R-RUN switch to F-RUN or R-RUN, corresponding to the desired operating mode for the timecode generator.


User bit memory function

The user bit setting (apart from the real time) is automatically retained in memory even when the power is turned off.

Synchronizing the Timecode to an External Source


You can synchronize the internal timecode generator of this camcorder with an external generator. You can also synchronize the timecode generators of other camcorders/VTRs with the internal generator of this camcorder.

- 1 Connect both the reference video signal and the external timecode as illustrated below. Example 1: Synchronizing with an external signal



- [1] GENLOCK IN connector
- [2] TC IN connector

Example 2: Interconnecting a number of camcorders with one camcorder as reference



- [1] VIDEO OUT connector
- [2] TC OUT connector
- [3] TC IN connector
- [4] GENLOCK IN connector

To next camcorder

- 2 Turn on the POWER switch.
- 3 Set the PRESET/REGEN/CLOCK switch to PRESET.
- 4 Set the F-RUN/SET/R-RUN switch to F-RUN.
- 5 Set the DISPLAY switch to TC.
- 6 Supply a timecode signal and a reference video signal, complying with the SMPTE standard and in proper phase relationship, to the TC IN connector and to the GENLOCK IN connector, respectively. This operation synchronizes the internal

timecode generator with the external timecode. Once about ten seconds have elapsed after the timecode locks, the external lock state is maintained even if the external timecode source is disconnected.

To release the external synchronization, first stop the external timecode input, then set the F-RUN/SET/R-RUN switch to R-RUN.

[Notes]

- When you finish the above procedure, the internal timecode is immediately synchronized with the external timecode and the time data display will show the value of the external timecode. However, wait for a few seconds until the sync generator stabilizes before recording.
- If the frequency of the reference video signal is not the same as the system frequency of the camcorder, the camcorder cannot be correctly genlocked. If this occurs, the timecode will not acquire successful lock with the external timecode.

User bit settings during synchronization

When the timecode is synchronized to an external signal, only the time data is synchronized with the external timecode value.

Note on changing the power supply from the battery pack to an external power supply during external synchronization

To maintain a continuous power supply, connect the external power supply to the DC IN connector before removing the battery pack. You may lose timecode external synchronization if you remove the battery pack first.

Camcorder genlock during external synchronization

During external synchronization, the camcorder is genlocked to the reference video signal input from the GENLOCK IN connector.

Basic Operations

This section explains the basic shooting and recording procedures.

Before starting to shoot, inspect the camera system to verify that it is operating properly.

1 Attach a fully charged battery pack (page 22).

2 Load one or two SxS memory cards (page 30).

If you load two cards, the camcorder switches automatically to the second card when the first card becomes full.

3 Set the camcorder's POWER switch (page 3) to ON.

4 Make the following settings.
Marker display: On (page 93)
Irs: Auto (page 40)
Zoom: Auto

Camera output: Select the picture currently being shot (camera picture), and turn the DCC function on (page 6)
Timecode advance mode: F-RUN (Free Run) or R-RUN (Rec Run) (page 45)
Audio input channel selection: Auto (page 9)

5 Push the AUTO W/B BAL switch to the BLACK position to adjust the black balance (page 37).

6 Select a filter according to the lighting conditions, and adjust the white balance (page 37).

7 Point the camcorder at the subject, and adjust the focus and zoom.

8 If you are using the electronic shutter, select an appropriate shutter mode and speed (page 39).

9 Do one of the following to start recording.

- Press the REC START button (page 4).
- Press the VTR button on the lens.
- Turn on the assignable switch to which the Rec function has been assigned (page 114).

During recording, the TALLY indicators, the tally indicator on the front panel of the viewfinder, and the REC indicator on the viewfinder screen light. Adjust the zoom and focus as required.

[Notes]

- Never remove the battery pack while the camcorder is recording (while the ACCESS indicator on the right-side panel is lit in blue and the ACCESS indicator in the card slot section is lit in orange). Doing so risks the loss of several seconds of data before the recording was interrupted, because internal processing will not end normally.
- The playback control buttons (EJECT, F REV, F FWD, NEXT, PREV, PLAY/PAUSE, STOP) do not function during recording.

10 To stop recording, perform one of the operations listed in step 9.

The TALLY indicators, the tally indicator on the front panel of the viewfinder, and the REC indicator on the viewfinder screen go out, and camcorder enters recording standby (Stby) mode.

A clip is created from the video and audio data and the metadata recorded between steps 9 and 10.


To review the recording (rec review)

With the camcorder in recording standby mode, press an assignable switch assigned with the Rec Review function to play back the last two seconds of the clip at normal speed. Press and hold an assignable switch assigned with the Rec Review function for one second or longer to start play back from the frame two seconds prior to the last frame at four times speed in the reverse direction. Then, release

the button to play the clip from that point at normal speed. The clip is played to the end, then Rec Review ends and the camcorder returns to Stby mode.

When the Rec Review function is assigned to the RET button on the lens, you can also conduct a review by using the RET button.

11 Repeat steps 9 and 10 to continue recording. With each repetition, another clip is created on the memory card.



[Notes]

- You cannot resume recording for about one second after stopping recording.
- The maximum number of clips that can be recorded on one memory card is 600. Even if the memory card has enough free capacity to record more clips, when 600 clips have been recorded, no further recording is possible.

Clip names

Eight-character clip names (consisting of a four-character prefix and a four-digit number) are generated automatically for clips recorded by this camcorder.

Example: ABCD0001

You can also use Operation >Clip >Title Prefix in the setup menu to set the clip name prefix to a user-specified string of characters (four to 46 characters in length). (A user-specified prefix cannot be changed after recording)

The four-digit number at the end of clip names is generated automatically, incrementing as clips are recorded.

Playing Recorded Clips

When the camcorder is in standby (Stby) mode, you can play all or part of the most recently recorded clip (page 47).

1 Insert the SxS memory card to play (page 30).

2 Press the PREV button (page 8) or the F REV button (page 7) to cue up the clip to play.

3 Press the PLAY/PAUSE button. The PLAY/PAUSE indicator lights, and the playback picture appears in the viewfinder.

Pausing playback

Press the PLAY/PAUSE button. The PLAY/PAUSE indicator flashes while play is paused. Press the button again to return to play mode.

High-speed playback

Press the F FWD button (page 8) or the F REV button (page 7). To return to normal playback, press the PLAY/PAUSE button.

Stopping playback

Press the STOP button: Playback stops, and the camcorder enters E-E mode. Press the THUMB/NAL button: Playback stops and the thumbnail screen (page 78) appears in the viewfinder.

Playback also stops and the timecode screen appears in the viewfinder when you start recording during playback, and when you eject an SxS memory card.

Switching between memory cards

When two memory cards are loaded, press the SLOT SELECT button (page 30) to select the active slot.

It is not possible to switch between memory cards during playback.

Advanced Operations

Recording Shot Marks

On this camcorder, two types of shot marks are available. You can record them at user-specified positions to make it easier for editors to cue up those positions.

The maximum number of shot marks per clip is 999.

You can also use the Thumbnail menu to add and delete shot marks in clips. For details, see "Adding/Deleting Essence Marks on Clips" (page 82).

To record shot marks, turn on an assignable switch assigned with the Shot Mark 1 or Shot Mark 2 function.

When a shot mark is recorded, a "Shot Mark 1" or "Shot Mark 2" indication appears in the viewfinder for about three seconds near the timecode indicator.

[Note]
An SDXC card inserted in an SxS card slot using the MEAD-SD02 Media Adaptor (option) cannot be used for recording.

Setting Clip Flags

To make it easier for editors to select good clips, you can set clip flags in recorded clips.

Clip flags are set in the Thumbnail menu. For details, see "Adding Clip Flags to Clips" (page 81) and "Deleting a Clip Flag" (page 82).

[Note]
An SDXC card inserted in an SxS card slot using the MEAD-SD02 Media Adaptor (option) cannot be used for recording.

Recording Retroactive Images (Picture Cache Rec Function)

The camcorder always maintains a cache of video and audio data for a set interval (maximum of 15 seconds) in internal storage memory when shooting, allowing you to record several seconds of footage before the start of recording.

This function is enabled when the camcorder is set to any of the following video formats (page 34).

- XAVC-I
- XAVC-L
- MPEG HD 422
- MPEG HD 420
- MPEG IMX 50

To start recording in picture cache mode, picture cache mode and the storage time of images in memory (picture cache time) must be set beforehand in the Operation menu.

When recording is started, the duration of footage that can be recorded retroactively is determined by the picture cache time. The duration that can be recorded retroactively may be reduced in some circumstances, as described in **[Notes]** below.

- [Notes]**
 - The storage of video in memory starts when picture cache mode is selected. However, if recording is started immediately after selecting this mode, a portion of the images shot immediately prior to selecting picture cache mode will not be recorded.
 - Images are not stored in memory during playback, recording review, or thumbnail display, so picture cache recording of images during these periods is not supported.

Setting the picture cache time

- 1 Select Operation >Rec Function >Picture Cache Rec in the setup menu.
- 2 Turn the MENU knob to select [On], then press the knob.

- 3 Select Operation >Rec Function > Cache Rec Time in the setup menu.

- 4 Turn the MENU knob to select the picture cache time setting, then press the knob.
0 to 2, 2 to 4, 4 to 6, 6 to 8, 8 to 10, 10 to 12, 12 to 14, or 13 to 15 seconds can be selected.

Once picture cache mode is selected, it is maintained until the settings are changed.

Alternatively, instead of performing steps 1 and 2, you can also select picture cache mode using an assignable switch (page 114) which has been assigned with the Picture Cache function.

- [Notes]**
 - Only one special recording function, such as picture cache recording, can be used at any one time.
If another special recording mode is enabled while picture cache recording is in use, picture cache recording is automatically released.
 - Changing system settings, such as the video format, clears all images stored in memory. Consequently, images shot just before changing settings cannot be recorded, if recording is started immediately after changing settings. Picture cache mode is automatically released.
 - The picture cache time cannot be set during recording.

Starting picture cache recording

Shoot as described in "Basic Operations" (page 47).

When recording starts, the "Cache" indication in the viewfinder changes to the "Rec" indication. The TALLY indicators and the tally indicator on the front panel of the viewfinder light as they do during normal recording.

To exit, stop the recording.

Canceled picture cache mode

In recording standby mode, set Operation >Rec Function >Picture Cache Rec in the setup menu to Off.

Device operation when recording in picture cache mode

The recording procedure is essentially the same, except for the following points where operation varies from normal.

- If recording is started while accessing media, the actual start point of recording may be delayed even longer than the set picture cache time. The delay increases with the number of recorded clips, so stopping recording and quickly restarting recording should be avoided in picture cache mode.
- Regardless of the setting of the F-RUN/SET/R-RUN switch, the camcorder operates in F-RUN mode.
- In picture cache mode, time data cannot be set by switching the F-RUN/SET/R-RUN switch to SET.

To set time data, first stop picture cache mode.

- If the remaining recording time of the media in the currently selected slot is shorter than the picture cache time, images are recorded to the media (if there is sufficient remaining recording time) in the non-selected slot.

However, images are not recorded if there is no media in the non-selected slot or if the media in the slot has insufficient remaining recording time. (A message notifying you that there is insufficient remaining recording time will appear on the viewfinder screen.)

- Shot marks are not recorded, even if the shot marks are set before the recording start operation.

If the camcorder is turned off during recording

- If the POWER switch on the camcorder is set to the OFF position, the media is accessed for several seconds to record the images stored in memory up till that moment, and then the power turns off automatically.
- If the battery is removed, the DC cable disconnected, or the AC adaptor turned off

during recording, the video and audio data stored in memory is erased and images up till that point are not recorded. Care should be exercised when exchanging the battery.

Recording Time-lapse Video (Interval


Rec Function)

The camcorder's Interval Rec function allows you to capture time-lapse video to the camcorder's internal memory. This function is an effective way to shoot slow-moving subjects.

When you start recording, the camcorder automatically records a specified number of frames at a specified interval time.

This function is enabled when the camcorder is set to any of the following video formats (page 34),

XAVC-I
XAVC-L
MPEG HD 422



A pre-lighting function is available when Interval Rec is enabled. This function automatically turns on the video light before recording starts, which

allows you to record pictures under stable light and color temperature conditions.

[Notes]

- Only one special recording function, such as Interval Rec recording, can be used at any one time. If another special recording mode is enabled while Interval Rec is in use, for example, Interval Rec is automatically released.
- Interval Rec settings cannot be changed during recording.

Setting Interval Rec

1 Select Operation > Rec Function > Interval Rec in the setup menu.

2 Turn the MENU knob to select [On], then press the knob. The camcorder enters Interval Rec mode, and "Int Sby" appears at the REC indicator position on the viewfinder screen. (The green tally indicator in the HDVF series viewfinder also flashes.)

3 Select [Number of Frames], turn the MENU knob to select the number of frames to record in one take, and then press the knob. You can select 2, 6, or 12 when the format is 50P or 59.9P. You can select 1, 3, 6, or 9 when the format is 23.98P, 25P, 29.97P, 50i, or 59.94i.

4 Select [Interval Time], turn the MENU knob to select the desired interval, and then press the knob. You can select 1 to 10/15/20/30/40/50 sec, 1 to 10/15/20/30/40/50 min, or 1 to 4/6/12/24 hour.

5 As required, select [Pre-Lighting], turn the MENU knob to select the length of lighting time before recording starts, and then press the knob. You can select 2, 5, 10 seconds, or Off.

[Notes]

- If you want to turn the video light on before the start of recording, set the camcorder's LIGHT switch to AUTO. The video light switch must also be turned on. When this is done, the video light turns on and off automatically. However, the video light remains lit if the time that it would be off is five seconds or less.
- If you set the LIGHT switch to MANUAL, and turn the video light switch on, the video light is always lit. (The video light does not turn on and off automatically.)

The camcorder exits Interval Rec mode when it is powered off, but the number of frames, interval time, and pre-lighting settings are maintained. You do not need to set them again the next time you shoot in Interval Rec mode.

Starting Interval Rec recording

Make the settings and preparations described in "Basic Operations" (page 47), secure the camcorder so that it does not move, and begin shooting.

When Interval Rec mode is set to On, "Int Sby" appears at the REC position on the viewfinder screen. When you start recording, "Int Rec" and "Int Sby" are displayed alternately. The TALLY indicators and the tally indicator on the front panel of the viewfinder light as they do during normal recording. (The green tally indicator in the HDVF series viewfinder also flashes at high speed.)

If you are using the pre-lighting function, the video light comes on before recording starts.

To exit, stop the recording. When shooting ends, the video data stored in memory up to that point is written to the media.

Canceling Interval Rec mode

- Do one of the following.
- Set the POWER switch to OFF.
 - In recording standby mode, set Operation > Rec Function > Interval Rec in the setup menu to Off.

[Note]

Restarting the camcorder automatically releases Interval Rec mode.

Limitations during recording

- Regardless of the setting of the F-RUN/SET/R-RUN switch, the advance mode of the internal timecode generator is always R-RUN.
- Audio is not recorded.
- Reviewing the recording (Rec Review) is not possible.
- Genlock is not possible.

If the camcorder is turned off during recording

- If the POWER switch on the camcorder is set to the OFF position, the media is accessed for several seconds to record the images stored in memory up till that moment, and then the power turns off automatically.
- If power is lost because the battery was removed, the DC power cord was disconnected, or the power was turned off on the AC adaptor side, then the video and audio data shot up to that point may be lost (maximum 10 seconds). Care should be exercised when exchanging the battery.

Shooting with Slow & Quick Motion

When the video format (page 34) is set to one of the formats listed below, you can specify a recording frame rate that is different from the playback frame rate.

[Note]

If shooting in XAVC recording format, the use of SxS Pro+ memory cards is recommended. The use of other SxS memory cards may be subject to limitations, so you should contact your dealer.

Recording format	System frequency	S&Q frame rate
XAVC-I 1080P	59.94P/50P/ 29.97P/23.98P/ 25P	1 FPS to 60 FPS (1 FPS units)
XAVC-L 50 1080P	59.94P/50P/ 29.97P/23.98P/ 25P	
XAVC-L 35 1080P	59.94P/50P/ 29.97P/23.98P/ 25P	
HD422 50 1080P	29.97P 23.98P 25P	1 FPS to 30 FPS (1 FPS units) 1 FPS to 25 FPS (1 FPS units)

By shooting with a frame rate that differs from the playback frame rate, you can obtain slow and quick motion effects that are smoother than low-speed or high-speed playback of content recorded at the normal frame rate.

Setting Slow & Quick Motion

- 1 Select Operation >Rec Function >Slow & Quick Motion in the setup menu.
- 2 Turn the MENU knob to select [On], then press the knob.
Slow & Quick Motion starts, and “S&Q Stby” appears in the recording status indicator area in the viewfinder.
Next, set the frame rate.
- 3 Select Operation >Rec Function >Slow & Quick Motion >Frame Rate in the setup menu.
- 4 Turn the MENU knob to select the frame rate, then press the knob.

When you finish making these settings, the system frequency and the frame rate appear at the top of

the viewfinder screen. You can change the frame rate while viewing the display in the viewfinder by turning the MENU knob.
The Slow & Quick Motion mode setting and the frame rate are retained even after the camcorder is powered off.

- [Notes]
- Only one special recording function, such as Slow & Quick Motion, can be used at any one time.
 - If another special recording function is enabled while using Slow & Quick Motion, Slow & Quick Motion is automatically canceled.
 - Slow & Quick Motion cannot be set during recording, playback, or while the thumbnail screen is displayed.
 - Slow & Quick Motion cannot be set if the slow shutter function is set.

Starting Slow & Quick Motion recording

Shoot as described in “Basic Operations” (page 47).

When recording starts, the “S&Q Stby” indication in the viewfinder changes to the “S&Q Rec” indication. The TALLY indicators and the tally indicator on the front panel of the viewfinder light as they do during normal recording.

To exit, stop the recording,

[Note]
It takes longer than normal for recording to stop when the frame rate is set to a low value (for a slow frame rate).

Canceling Slow & Quick Motion mode

With the camcorder in recording standby mode, set Operation >Rec Function >Slow & Quick in the setup menu to Off.

Limitations during recording

- Regardless of the setting of the F-RUN/SET/R-RUN switch, the advance mode of the internal timecode generator is always R-RUN.
- Audio cannot be recorded when the recording and playback frame rates differ.

- Reviewing the recording (Rec Review) is not possible.
- If you change the recording frame rate to a value faster than the current shutter speed, the shutter speed is changed to the slowest value for which shooting is possible.
Example: if the frame rate is 32 and the shutter speed is 1/40, and you change the frame rate to 55, then the shutter speed is changed to 1/60. It is not possible to select a shutter speed that is slower than the recording frame rate.
- Genlock is not possible.

Recording with the Clip Continuous Rec Function

Normally, a clip is created as an independent file each time that you start and stop recording. But this function allows you to start and stop recording while continuously recording to the same clip, for as long as the function remains enabled. This is convenient when you do not want to generate a large number of short clips, and when you want to record without worrying about exceeding the clip limit.

It is still easy to find recording start points, because a Rec Start essence mark is recorded at the recording start point each time you start recording. This function is enabled when the camcorder is set to any of the following video formats (page 34).

- XAVC-I
- XAVC-L
- MPEG HD 422

Setting Clip Continuous Rec

- 1 Select Operation >Rec Function >Clip Continuous Rec in the setup menu.

- 2 Turn the MENU knob to select [On], then press the knob.
“Cont Stby” appears in the viewfinder, and the function is enabled.

- [Notes]
- Only one special recording function, such as Clip Continuous Rec, can be used at any one time.
 - If another special recording mode is enabled while Clip Continuous Rec is in use, for example, the currently selected mode is automatically released.

You can assign the Clip Continuous Rec on/off function to one of the ASSIGN. 1/2/3 switches, ASSIGNABLE 4/5 switches, or the ONLINE button.

For details, see “Assigning Functions to Assignable Switches” (page 114).

Starting Clip Continuous Rec recording

Shoot as described in “Basic Operations” (page 47).

When recording starts, the “Cont Stby” indication in the viewfinder changes to “Cont Rec” indication.

The TALLY indicators and the tally indicator on the front panel of the viewfinder light as they do during normal recording.

[Note]
During recording or in recording standby mode (when “Cont Stby” indication is displayed), if you remove the media, the battery, or the power source, the media needs to be restored. It is not possible to restore media on a device other than this camcorder.
Exit Clip Continuous Rec mode (page 52) and then remove the media.
When “Cont Stby” indication is flashing (once per second), you can remove the media.

To exit, stop the recording,

[Note]
Stop the recording after recording for two or more seconds.

Canceling Clip Continuous Rec mode

With the camcorder in recording standby mode, set Operation >Rec Function>Clip Continuous Rec in the setup menu to Off.

Limitations during recording

- A single continuous clip cannot be created if you perform one of the following operations while the camcorder is in recording or recording standby mode. (A new clip will be created when you next start recording)
- Operate on a clip (lock, delete, or rename a clip)
 - Switch slots
 - Change the recording format
 - Turn off the POWER switch
 - Playback
 - Switch to the thumbnail screen

Recording Video Simultaneously to Two SxS Memory Cards (Simul Rec)

When the video format (page 34) is set to one of the options in the following table, you can record the same video to two SxS memory cards. This function is useful for making a video backup while shooting.

[Note]

It is recommended that both SxS memory cards be formatted (initialized) using the camcorder before use.

Operation >Format >Rec Format in the setup menu		Operation >Format >Frequency in the setup menu
XAVC-L 1920×1080P		59.94/59.29.97/25/23.98
XAVC-L 1920×1080i		59.94/50
XAVC-L 1280×720P		59.94/50
XAVC-L 50 1920×1080P	59.94/50/29.97/25/23.98	

Operation >Format >Rec Format in the setup menu	Operation >Format >Frequency in the setup menu
XAVC-L 50 1920×1080i	59.94/50

XAVC-L 50 1280×720P	59.94/50
XAVC-L 35 1080P	59.94/50/29.97/25/23.98
XAVC-L 35 1080i	59.94/50
XAVC-L 25 1080i	59.94/50
HD 422 50 1080P	29.97/25/23.98
HD 422 50 1080i	59.94/50
HD 422 50 720P	59.94/50/29.97/25/23.98
HQ 1920×1080P	29.97/25/23.98
HQ 1920×1080i	59.94/50
HQ 1440×1080i	59.94/50
HQ 1280×720P	59.94/50

Setting Simul Rec

- 1 Select Operation >Rec Function>Simul Rec in the setup menu.
- 2 Turn the MENU knob to select [On], then press the knob.

[Notes]

 - Only one special recording function, such as Simul Rec, can be used at any one time.
 - If another special recording mode is enabled while using Simul Rec, Simul Rec is automatically released.
 - Simul Rec cannot be set during recording, playback, or while the thumbnail screen is displayed.

Starting Simul Rec recording

- 1 Insert SxS memory cards in both memory slots A and B.
The ACCESS indicators for SxS slots A and B are lit. Also, icons for SxS slots A and B appear in the viewfinder (page 18).

- 2 Shoot as described in “Basic Operations” (page 47).

[Notes]

- Simultaneous recording is not possible if either of the media is defective or if the media is write protected.
- During simultaneous recording, if either of the media becomes full or an error occurs and recording cannot continue, recording to that media stops but recording to the other media continues.


To exit, stop the recording,

Canceling Simul Rec mode

In recording standby mode, set Operation >Rec Function >Simul Rec in the setup menu to Off.

Proxy Data

Proxy data is made up of low-resolution video data (H.264) and audio data (AAC-LC). This lightweight proxy data can be used in the same way as the original data, but it can be transferred more quickly, for more efficient viewing and editing. During clip recording, proxy data is recorded onto the SD card inserted into the PROXY SD card slot.



PROXY SD card slot

By importing proxy data recorded on the SD card into a computer, you can quickly check the recorded content or perform rapid offline editing. You can record proxy data separately from recording to SxS memory cards.

Proxy Recording using the Camcorder

- Proxy recording will not start unless an SxS memory card is inserted.
- When the camcorder has been turned on for about 35 seconds, the **[Proxy]** icon (media status indicator for Proxy SD slot) turns on in the LCD monitor and viewfinder screen to indicate that proxy recording is enabled.
- If you start shooting while the **[Proxy]** icon is flashing or is not lit, proxy files are not recorded.
- Before removing an SD card from the camcorder, always check that the ACCESS indicator for the PROXY SD card slot is not lit, then turn off the camcorder or turn off the proxy recording/wireless LAN connection function.

To turn off the proxy recording/wireless LAN connection function, make the following settings in the setup menu.

- Set Operation >Proxy Recording Mode >Setting to Off.
- Set Maintenance >Network >Setting to Off.
- Attempting to remove the SD card while either the proxy recording or wireless LAN connection function is enabled may display a warning (E91-1C0) in some cases. If the warning appears while recording, data is still recorded correctly to the SxS memory cards, but proxy files are not recorded. The warning message can be cleared by turning the camcorder off and then on again.
- Proxy recording will not start if Picture Cache Rec, Interval Rec, Slow & Quick Motion, or streaming is enabled.

SD Cards

SD cards supported for recording proxy data

SDHC memory cards* (Speed Class: 4 or higher, Capacity: up to 32 GB)
SDXC memory cards* (Speed Class: 4 or higher)
* Referred to as "SD cards" in this manual.

Formatting (initializing) SD cards

SD cards must be formatted the first time they are used in the camcorder.
SD cards for use in the camcorder should be formatted using the format function of the camcorder. If a message appears when the SD card is inserted into the camcorder, format the SD card.

- 1 Select Operation >Proxy Recording Mode >Setting in the setup menu.
- 2 Turn the MENU knob to select [On], then press the knob.

- 3 Select Operation >Format Media >SD Card(Proxy) in the setup menu.

- 4 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen prompting whether to format the card appears.

- 5 Turn the MENU knob to select [Execute], then press the knob.
Formatting begins.
During formatting, a message and progress state (%) is displayed and the ACCESS indicator is lit orange.
When formatting ends, a completion message appears. Press the MENU knob to dismiss the message.

[Note]
Formatting an SD card erases all data on the card. The card cannot be restored.

Checking the remaining recording capacity

You can check the remaining capacity on an SD card on the Media Status screen (page 15).

To use an SD card formatted on the camcorder in the slot of another device

First, make a backup of the card, then reformat the card in the device to be used.

Recording Proxy Data

To record proxy data simultaneously

- 1 Select Operation >Proxy Recording Mode >Setting in the setup menu.

- 2 Turn the MENU knob to select [On], then press the knob.

- 3 Insert an SD card for recording proxy data into the PROXY SD card slot.

- 4 Start recording.
The proxy data file is saved in the "/PRIVATE/PXROOT/Clip" directory of the SD card at the same time as the original data is being recorded onto an SxS memory card.
Proxy data recording automatically stops when you stop recording.

To record proxy data separately from recording original data

You can start and stop proxy recording independently by assigning the Proxy Rec Start/Stop function to an assignable switch.

- [Note]**
• If simultaneous proxy recording is started while recording proxy data independently is in progress, the proxy data recording continues without interruption. Subsequently, when simultaneous recording is stopped, proxy data recording also stops.
- If independent proxy recording is stopped while simultaneous recording is in progress, only the proxy data recording stops.

Proxy recording limitations

Proxy recording is not supported in the following cases.

- During streaming (Maintenance >Streaming >Setting in the setup menu set to On)
- During Interval Rec (Operation >Rec Function >Interval Rec in the setup menu set to On)
- Picture Cache Rec (Operation >Rec Function >Picture Cache Rec in the setup menu set to On)
- During Slow & Quick Motion (Operation >Rec Function >Slow & Quick Motion in the setup menu set to On)

- When network client mode is enabled (Maintenance >Network Client Mode >Setting in the setup menu is set to On). However, proxy recording is enabled when Maintenance >Network Client Mode >Detail Settings >NCM with Proxy in the setup menu is set to Enable.
- When Operation >Format >Frequency in the setup menu is set to 23.98P and Operation >Proxy Recording Mode >Size is set to HD Auto(9Mbps) or HD Auto(6Mbps)
- Proxy recording is not possible when power is being supplied to the external device connector (Operation >USB in the setup menu).

About the recorded files

- The file name extension is ".mp4".
- The timecode is also recorded simultaneously.
- A still image of the first frame is also recorded simultaneously.
- Location information and a Log file are recorded simultaneously if the GPS function is enabled. The Log file is saved in "Root/Private/Sony/GPS."

Canceling proxy data recording

Select Operation >Proxy Recording Mode >Setting in the setup menu to Off.

When there is insufficient remaining capacity on an SD card

A warning is displayed to indicate that there is insufficient free space.

Changing proxy recording settings

Select Operation >Proxy Recording Mode >Size and Audio Channel in the setup menu to change the settings for the size of the proxy recording format and the audio channel for proxy recording, respectively.

[Note]

When Operation >Proxy Recording Mode >Size in the setup menu is set to HD Auto(9Mbps) or HD Auto(6Mbps) and the system frequency is set to 29.97, 25, or 23.98, the proxy data picture size will be set to 1920x1080 even if the picture size of the recording video format is set to 1280x720.

Checking proxy recording settings

Select Operation >Proxy Recording Mode >Frame Rate and Bit Rate in the setup menu to view the settings for the video frame rate and video bit rate, respectively.

Planning Metadata

Planning metadata is information about shooting and recording plans, recorded in an XML file. You can shoot using clip names and shot mark names defined in advance in a planning metadata file.

[Note]
Use a font set that is compatible with the language set using Maintenance >Language in the setup menu when defining clip names and shot mark names. Using fonts for a language that is different from the language setting on the camcorder may cause characters to be displayed abnormally.

Loading a Planning Metadata File into Camcorder Memory when Recording a Clip

- 1 Save the planning metadata file on an SxS memory card beforehand. Planning metadata files are stored in the "General/Sony/Planning" directory.
- 2 Insert an SxS memory card in slot A or B.
- 3 Select Operation >Planning Metadata >Load Media(A) or Load Media(B) in the setup menu. A file list screen appears. Up to 64 planning metadata files are displayed in the list.
- 4 Turn the MENU knob to select a file to load and press the knob.
- 5 Turn the MENU knob to select [Load] and press the knob, then select [Execute] and press the knob again.

[Note]
Data cannot be loaded from SDXC cards.

Displaying Detailed Information in Planning Metadata

After loading planning metadata into the camcorder, you can check the detailed information that it contains, such as file names, date and time of creation, and titles.

- 1 Select Operation >Planning Metadata >Properties in the setup menu.
- 2 Turn the MENU knob to select [Execute], and then press the knob. The planning metadata information is displayed.

Item	Information
File Name	File name
Assign ID	Assign ID
Created	Date and time of creation
Modified	Date and time of most recent modification
Modified by	Name of person who modified the file
Title	Title1 specified in file (ASCII format clip name)
Title2	Title2 specified in file (UTF-8 format clip name)
Material Group	Number of material groups ^{a)}
Shot Mark0 to Shot Mark9	Names defined in file for Shot Mark 0 to Shot Mark 9

a) Material group: A group of clips recorded with the same planning metadata.

You can turn the MENU knob to scroll the list.

Clearing the Loaded Planning Metadata

- 1 Select Operation >Planning Metadata >Clear Memory in the setup menu.
- 2 Turn the MENU knob to select [Execute], and then press the knob. Deletion starts. The message "Clear Planning Metadata File OK" appears when the deletion finishes.

Defining Clip Names in Planning Metadata

- The following two types of clip name strings can be written in a planning metadata file.
- An ASCII format name that appears in the viewfinder
 - A UTF-8 format name that is actually registered as the clip name

You can select which type of clip name is displayed with Operation >Planning Metadata >Clip Name Disp in the setup menu.

When a clip name is set with planning metadata, the clip name is displayed.

[Note]
When you define both an ASCII format name and a UTF-8 format name with planning metadata, the UTF-8 format string is used as the clip name string. If you define either an ASCII format name or a UTF-8 format name with planning metadata, the defined format name is displayed though it is not selected by menu setting.

Clip name string example

Use a text editor to modify the two fields in the <Title> tag that contain the clip name strings. The shaded fields in the example are clip name strings. "Typhoon" is described in ASCII format (up to 44 characters). "Typhoon_Strikes_Tokyo" is described in UTF-8 format (up to 44 bytes). "sp" indicates a space and "↵" indicates a carriage return.

```
<?xml version="1.0" encoding="UTF-8"?>↵
<PlanningMetadata xmlns="http://
xmlns.sony.net/pro/metadata/
planningmetadata" sp:assignId="
P0001" sp:creationDate="
2016-11-30T17:00:00+09:00"
lastUpdate="
2016-12-06T17:00:00+09:00"
version="1.00">↵
  <Properties sp:propertyId="
assignment" sp:update="
2016-12-06T17:00:00+09:00"
modifiedBy="Chris">↵
    <Title_8USAscii="Typhoon"
      xml:lang="en">Typhoon_Strikes_Tokyo
    </Title>↵
  </Properties>↵
</PlanningMetadata>↵
```

- [Notes]**
- When you create a file, enter each statement as a single line with a CRLF only after the last character in the statement line, and do not enter spaces except where specified.
 - Up to 44 bytes (or characters) can be entered for the clip name. If the UTF-8 format string exceeds 44 bytes, the first 44 bytes are used as the clip name. If only an ASCII format name is specified, a 44-character string is used as the clip name. When neither an ASCII format name string nor UTF-8 format name string can be used, the standard format clip name is used.

Setting clip names

- 1 Load a planning metadata file that contains clip names into camcorder memory (page 97).

- 2 Set Operation >Clip >Clip Naming in the setup menu to Plan.

Each time that you record a clip, the camcorder automatically generates a name consisting of the clip name defined in the planning metadata file, with the addition of an underbar (_) and a five-digit serial number (00001 to 99999).

Examples:Typhoon_Strikes_Tokyo_00001, Typhoon_Strikes_Tokyo_00002,... After the number reaches 99999, the next increment returns the number to 00001.

[Note]

When you load another planning metadata file, the serial number continues incrementing. You can change the numbering using Operation >Clip >Number Set in the setup menu.

Selecting the clip name display format

When names are defined in both ASCII format and UTF-8 format, you can use Operation >Planning Metadata >Clip Name Disp in the setup menu to select which of the names to display on the LCD monitor and on the viewfinder screen.

To display ASCII format names:

Select Title1 (ASCII).

The clip name becomes "Typhoon_Strikes_Tokyo_SerialNumber", but "Typhoon_SerialNumber" is displayed on the screen.

To display UTF-8 format names:

Select Title2(UTF-8).

The clip name becomes "Typhoon_Strikes_Tokyo_SerialNumber", and the same name is displayed on the screen.

Defining Shot Mark Names in Planning Metadata

When you use planning metadata to set shot marks, you can define names for Shot Mark 0 to Shot Mark 9.

When you record shot marks, you can add the shot mark name strings defined in the planning metadata.

[Note]

Only Shot Mark 1 and Shot Mark 2 can be recorded on the camcorder.

Shot mark name string example

Use a text editor to modify the fields in the <Meta name> tag.

The shaded fields in the example are essence mark name strings. Names can be either in ASCII format (up to 32 characters) or UTF-8 format (up to 16 characters).

"sp" indicates a space and ↵ indicates a carriage return.

[Note]

If a name string contains even one non-ASCII character, the maximum length of that string is 16 characters.

```
<?xml version="1.0" spencoding="UTF-8" ?>↵
<PlanningMetadata xmlns="http://xmlns.sony.net/pro/metadata/planningmetadata" spassignId="H00123" spcreationDate="2016-11-30T08:00:00Z" splastUpdate="2016-11-30T15:00:00Z" spversion="1.00">↵
  <PropertiessppropertyId="assignment" spclass="original" spupdate="2016-11-30T15:00:00Z" spmodifiedBy="Chris">↵
    <TitlespusAscii="Football Game" spxmlLang="en">
      Football Game 30/11/2016</
```

Title>↵

```
<Metaspname="_ShotMark1" sp
  content="Goal"/>↵
<Metaspname="_ShotMark2" sp
  content="Shoot"/>↵
<Metaspname="_ShotMark3" sp
  content="Corner Kick"/>↵
<Metaspname="_ShotMark4" sp
  content="Free Kick"/>↵
<Metaspname="_ShotMark5" sp
  content="Goal Kick"/>↵
<Metaspname="_ShotMark6" sp
  content="Foul"/>↵
<Metaspname="_ShotMark7" sp
  content="PK"/>↵
<Metaspname="_ShotMark8" sp
  content="1st Half"/>↵
<Metaspname="_ShotMark9" sp
  content="2nd Half"/>↵
<Metaspname="_ShotMark0" sp
  content="Kick Off"/>↵
</Properties>↵
</PlanningMetadata>↵
```

[Note]

When you create a definition file, enter each statement as a single line with a CRLF only after the last character in the statement line, and do not enter spaces except where specified, except within essence mark name strings.

Obtaining Location Information (GPS)

Location and time information of video shot when positioning is enabled is recorded by the camcorder.

The GPS function is set to Off by factory default.

- 1
- Check that the camcorder is in standby state.
- 2
- Set Operation GPS to On in the setup menu.  is displayed in the viewfinder when the camcorder is seeking GPS satellites. When positioning is established, location information is recorded when shooting video.

The icon displayed in the viewfinder varies, depending on the signal reception from the GPS satellites.

Positioning status	Display	GPS reception state
--------------------	---------	---------------------

Off	No display	GPS is set to Off or an error occurred.
-----	------------	---

Positioning not available		Location information could not be obtained because GPS signal could not be received. Move to a location with a clear view of the sky.
---------------------------	---	---

Searching for satellites		Searching for GPS satellites. Several minutes may be required to acquire satellites.
--------------------------	---	--

Positioning		A weak GPS signal is being received.
-------------	---	--------------------------------------

		A GPS signal is being received. Location information can be acquired.
--	---	---

		A strong GPS signal is being received. Location information can be acquired.
--	---	--

- It may take some time to start acquiring location information after turning on the camcorder.

- If a positioning icon is not displayed after several minutes, there may be a problem with signal reception. Start shooting without location information, or move to an area with a clear view of the sky. Shooting when a positioning icon is not displayed means that location information will not be recorded.
- The GPS signal may not be received when indoors or near tall structures. Move to a location with a clear view of the sky.
- The recording of location information may be interrupted, depending on the strength of the received signal, even if a positioning icon is displayed.

Network Functions Supported by the Camcorder

The camcorder supports various network functions. This section provides an overview and detailed description of the network connections and functions.

Network Connection Overview

When using the IFU-WLM3 (supplied)

- 1 Attach the IFU-WLM3 to the camcorder.
⇒ (page 59)

Connecting devices using wireless LAN

The camcorder can connect to smartphones, tablets, and other devices using wireless LAN connection using the IFU-WLM3 USB Wireless LAN Module (supplied) or CBK-WA02 Wireless LAN Adaptor (option).

- 1 Select the wireless connection device:
IFU-WLM3 USB Wireless LAN Module (supplied) ⇒ (page 59)
CBK-WA02 Wireless LAN Adaptor (option) ⇒ (page 59)

- 2 Select the wireless LAN access mode.
Wi-Fi Access Point mode ⇒ (page 60)
Wi-Fi Station mode ⇒ (page 61)

Connecting to the Internet using a LAN cable

Connect the camcorder to the Internet via a router using the network connector.

- 1 Connect the camcorder and router using a LAN cable.
⇒ (page 63)

Connecting to the Internet using wireless LAN

Connect the camcorder to the Internet using the IFU-WLM3 USB Wireless LAN Module (supplied), CBK-WA02 Wireless LAN Adaptor (option), or modem (option).

[Note]

The CBK-NA1 Network Adaptor Kit (option) is required if connecting using a CBK-WA02 Wireless LAN Adaptor (option) or modem (option).

Network Function Overview

Transferring files recorded on the camcorder to a server on the Internet

You can transfer proxy files recorded on an SD card and original files recorded on SxS memory cards to a server on the Internet when connected via a 3G/4G/LTE network, access point, wired LAN router.
⇒ (page 66)

Transmitting streaming video and audio

You can transmit the video and audio captured/played back with the camcorder via the Internet or local network.

Streaming using the streaming settings on the camcorder
⇒ (page 68)

High-quality streaming using a Sony Network RX Station (option) as a Connection Control Manager
⇒ (page 69)

Common Information

Using Wi-Fi remote control

You can access the Wi-Fi remote control built into the camcorder from a smartphone, tablet, or other device over a wireless LAN connection.
⇒ (page 70)

Configuring from the web menu

The web menu of the camcorder appears when the camcorder is accessed from a browser on a device connected using a wireless LAN connection.
⇒ (page 72)

Supported network functions and operating limitations

⇒ (page 77)

Connecting Devices using Wireless LAN

The camcorder can connect to smartphones, tablets, and other devices using wireless LAN connection by attaching the IFU-WLM3 USB Wireless LAN Module (supplied) or CBK-WA02 Wireless LAN Adaptor (option).

The following operations can be performed between the camcorder and devices connected using a wireless LAN.

[Note]
USB wireless LAN modules/adaptors other than the IFU-WLM3 or CBK-WA02 cannot be used.

Remote operation via wireless LAN

The camcorder can be operated remotely from a smartphone, tablet, or computer that is connected using a wireless LAN.

File transfer via wireless LAN

Proxy files (low-resolution files) stored on the camcorder SD card and original files (high-resolution files) recorded on the camcorder can be transferred to a server via a wireless LAN.

Monitoring video via wireless LAN

You can create a stream (H.264) of the camera picture or playback picture of the camcorder for monitoring from a device via wireless LAN using the “Content Browser Mobile” application.

“Content Browser Mobile” is an application that can operate the camcorder remotely on the device screen, while streaming content, and can be used to configure the camcorder. You can also transfer a cutout part of a file by specifying In and Out points in the proxy file (page 66).

Always check that you have the latest version of the “Content Browser Mobile” application.

For details about the “Content Browser Mobile” application, contact your Sony sales or service representative.

[Notes]

- Proxy files (low-resolution files) recorded on the SD card in the camcorder can be streamed via a wireless LAN.

- Streaming is not supported when the video format is set to MPEG-IMX or DVCAM.
- Obstructions and electromagnetic interference between the camcorder and wireless LAN access point or terminal device, or the ambient environment (such as wall materials) could shorten the communication range or prevent connections altogether. If you experience these problems, check the connection/communication status after moving the camcorder to a new location, or bringing the camcorder and access point/terminal device closer together.

Compatible Devices


You can use a smartphone, tablet, or computer to configure and operate the camcorder. The supported devices, OS, and browsers are shown in the following table.

Device	OS	Browser
Smartphone	Android	Chrome
	4.4/5.0/5.1/6.0	
	iOS 8.0/8.1/8.2/	Safari
	8.3/8.4/9.0	
Tablet	Android	Chrome
	4.4/5.0/5.1/6.0	
	iOS 8.0/8.1/8.2/	
	8.3/8.4/9.0	
Computer	Microsoft	Chrome
	Windows 7/	
	Microsoft	
	Windows 8/	
	Microsoft	
	Windows 10	
	Mac OS	Safari
	10.9/10.10	


[Note]
Playback may not be supported, depending on the operating system of the terminal device used and the browser version. If this occurs, use “Content Browser Mobile.”

Attaching the IFU-WLM3


- 1 Open the cover of the USB wireless LAN module connector.



- 2 Attach the protective cap to the IFU-WLM3.



- 3 Plug the IFU-WLM3 into the connector.



[Notes]


- Always turn the camcorder off before connecting or removing the IFU-WLM3.
- For attachment of the guard, contact a Sony service representative.

If not using the IFU-WLM3

Unscrew the two screws, remove the guard, and close the connector cover.


Attaching the CBK-WA02

- 1 Attach the attachment bracket to the handle in the position shown in the following diagram. For attachment of the attachment bracket (Service Part No. A-2092-367-), contact a Sony service representative.




- 2 Attach the USB extension adaptor, supplied with the CBK-WA02 (option), to the attachment bracket.


- 3 Turn the fixing screw clockwise to secure the USB extension adaptor.




You can adjust the position of the USB extension adaptor over the range shown in the following diagram.




4 Attach the protective cap (supplied) to the USB connector of the USB extension adaptor.




5 Open the cover of the USB wireless LAN module connector. For attachment of the guard, contact a Sony service representative.



6 Plug the USB connector of the USB extension adaptor into the USB wireless LAN module connector.



7 Plug the CBK-WA02 into the USB connector of the USB extension adaptor.



8 Set the wireless LAN channel in Maintenance > Network > Channel in the setup menu (page 108).

For details about using the CBK-WA02, refer to the instruction manual supplied with the CBK-WA02.

[Notes]



- Always turn the camcorder off before connecting or removing the CBK-WA02.
- Attaching the CBK-WA02 and selecting Wi-Fi Station in Maintenance > Network > Setting in the setup menu enables connection to a 5 GHz access point.
- The Ch setting "Auto(5GHz)" in Wi-Fi Access Point mode may not be displayed, depending on the CBK-WA02 used.
- "Auto(5GHz)" is not displayed in the menu if use of the CBK-WA02 in the 5 GHz band is prohibited for outdoor use in your country or region. Check that the use of the CBK-WA02 is permitted in your country or region. For details, refer to the CBK-WA02 operation manual.

If not using the CBK-WA02

Unscrew the two screws, remove the guard, and close the connector cover.

Connecting using Wireless LAN Access Point (Wi-Fi Access Point Mode)

The camcorder can connect to devices that are set up as an access point.




Install "Content Browser Mobile" on the device to connect before starting the connection configuration.

One-touch connection using NFC-equipped devices

Devices that support NFC can be connected by one touch using NFC.

1 Select [Settings] on the device and enable the [NFC] function.




2 Turn the camcorder on, and set Maintenance >Network >Wireless Network to Wi-Fi Access Point.

3 Set Maintenance >Network >Setting to On.

4 Enable the NFC function.
Set NFC connection mode by executing Maintenance >Network >NFC in the setup menu or by pressing and holding an assignable switch that has been assigned with the NFC function for three seconds.
The NFC function can be used only when  is displayed on the screen.

[Note]
It may take some time (30 seconds to 90 seconds) for  to appear on the screen. Wait until the network "AP" (access point) wireless network indicator (page 17) stops flashing on the viewfinder screen.

5 Touch the device against the camcorder.
The device connects to the camcorder, and "Content Browser Mobile" launches.



- [Notes]**
- Wake a sleeping device and unlock the lock screen beforehand.
 - Continue to hold the device against the camcorder without moving it until "Content Browser Mobile" launches (1 to 2 seconds).
 - If a device with identical SSID has already been registered, the device may not be able to be connected, depending on the OS version of the device. In this case, you can connect the device by deleting the registered SSID from the device.

Connecting using WPS-equipped devices

Devices that support WPS can be connected using WPS.

1 Set Maintenance >Network >Wireless Network to Wi-Fi Access Point.

2 Set Maintenance >Network >Setting to On.

[Note]
It may take some time (30 seconds to 90 seconds) to enable access point mode. Wait until the network "AP" (access point) indicator (page 17) stops flashing on the LCD monitor or in the viewfinder.

3 Select Maintenance >Network >WPS in the setup menu.

4 Turn the MENU knob to select [Execute], then press the knob.

5 Open the device Network Settings or Wi-Fi Settings, and turn Wi-Fi on.

6 Select the camcorder SSID from the Wi-Fi network SSID list, display Option, and select WPS Push Button.

[Note]
The steps will vary depending on the device used.

Connecting using SSID and password on the device

Connect by entering the SSID and password on the device.

1 Set Maintenance >Network >Wireless Network to Wi-Fi Access Point.

2 Set Maintenance >Network >Setting to On.

[Note]
It may take some time (30 seconds to 90 seconds) to enable access point mode. Wait until the network "AP" (access point) indicator (page 17) stops flashing on the LCD monitor or in the viewfinder.




3 Open the device Network Settings or Wi-Fi Settings, and turn Wi-Fi on.

4 Select the camcorder SSID from the Wi-Fi network SSID list, then enter a password to connect.
For the camcorder SSID and password, see Maintenance >Network >SSID & Password (page 108) in the setup menu.

[Note]
The steps will vary depending on the device used.

Connecting Using Wireless LAN Station Mode (Wi-Fi Station Mode)

The camcorder can connect to an existing wireless LAN access point as a client.
The device connects via the access point.



Connecting to an access point using WPS

If an access point supports the WPS function, you can connect using a basic setting. If an access point does not support the WPS function, see "Connecting to an access point in station mode without using WPS" (page 74).

1 Turn the access point on.

2 Turn the camcorder on.

3 Set Maintenance >Network >Wireless Network to Wi-Fi Station.

4 Set Maintenance >Network >Setting to On.

[Note]

It may take some time (30 seconds to 1 minute) to enable station mode. Wait until the network indicator (page 17) signal strength icon stops flashing on the LCD monitor or in the viewfinder.

5 Select Maintenance > Network > WPS in the setup menu.

6 Turn the MENU knob to select [Execute], then press the knob.

7 Press the access point WPS button.
For details about WPS button operation, refer to the instruction manual for the access point.
When the connection is successful, the network indicator (page 17) signal strength icon will show a strength of 1 or higher on the LCD monitor or in the viewfinder.

[Note]

If the connection fails, perform the procedure again from step 1.

8 Connect the device to the access point.
For details about how to connect, refer to the instruction manual for each device.

Connecting to the Internet

You can connect to the Internet using a wired LAN or wireless LAN.

For wired LAN, connect a LAN cable (not supplied) to the network connector on the camcorder, and connect to the Internet via a router.

For wireless LAN, connect to the Internet using the IFU-WLM3 USB Wireless LAN Module (supplied), CBK-WA02 Wireless LAN Adaptor (option), or modem (option).

Required device for network connection

Wireless LAN connection

One of the following devices is required.

- IFU-WLM3 USB Wireless LAN Module (supplied)
- CBK-WA02 Wireless LAN Adaptor (option) + CBK-NA1E USB Extension Adaptor supplied with the CBK-NA1 Network Adaptor Kit (option)
- Modem (option) + CBK-NA1E USB Extension Adaptor supplied with the CBK-NA1 Network Adaptor Kit (option)

Wired LAN connection

- LAN cable (not supplied)

[Notes]

- The wireless LAN module may not be available in some countries/regions.
- The frequency band for the wireless LAN module is shared by various devices. Depending on the use environment, transmission speed and distance may be decreased, or communication may be disconnected, by using other devices.
- To use the 3G/4G/LTE services, you need to contract with a cell phone company.
- For details about the required compatible device for the network connection, contact your Sony dealer or a Sony service representative.

Limitations on simultaneous use of network connection function


The camcorder can connect to a network using wireless LAN or wired LAN methods.

However, there are limits on the simultaneous use of these connection functions.


For details, see "Limitations on Simultaneous Use of Network Functions" (page 77).

Connecting Using a LAN Cable (Wired LAN Connection)

You can connect to the Internet using a wired LAN connection via a router connected to the network connector on the camcorder.



- 1 Connect the network connector of the camcorder and a router using a LAN cable.



- 2 Set Maintenance -> Network -> Wired LAN to Enable.
- 3 Set Maintenance -> Network -> Setting to On. An IP address is automatically assigned to the camcorder.

[Notes]


- It may take some time (30 seconds to 1 minute) for the wired LAN connection to become enabled. Wait until the network status indicator (page 17) LAN icon stops flashing on the LCD screen or in the viewfinder.
- To transfer original files/proxy files recorded on the camcorder, use Wi-Fi remote control, operate the web menu, or monitor output using the "Content Browser Mobile" application, set Maintenance -> Network -> Wired LAN Remote in the setup menu to On (page 108).
- When connected to a network, using a LAN cable, that will not be used to connect to the Internet, it is recommended that Wired LAN Remote be set to On to prevent unauthorized access from the Internet. When connecting to the Internet, check that the network connection is to a secure network before use.
- A wired LAN connection is not possible if a modem (option) is attached to the USB wireless LAN module connector. For wired LAN connection, first remove the modem (option).
- When connected to the Internet using Wi-Fi Station mode and the wired LAN is not connected to the Internet, a network error may occur and Internet-related functions may not operate. In this case, set Wired LAN to Disable, and connect to the Internet using Wi-Fi Station mode only.

Preparation for Connection to the Internet Using a Modem

Attach the CBK-NA1E USB extension adaptor, supplied with the CBK-NA1 Network Adaptor Kit (option), to the USB wireless LAN module connector on the camcorder when planning to connect to the Internet via a 3G/4G network using the USB wireless LAN module connector.


- 1 Attach the attachment bracket to the handle in the position shown in the following diagram. For attachment of the attachment bracket (Service Part No. A-2092-367-), contact a Sony service representative.

Attachment bracket




- 2 Attach the USB extension adaptor to the attachment bracket.


3 Turn the fixing screw clockwise to secure the USB extension adaptor.




4 Attach the protective cap (supplied) to the USB connector of the USB extension adaptor.



5 Open the cover of the USB wireless LAN module connector. For attachment of the guard, contact a Sony service representative.




6 Plug the USB connector of the USB extension adaptor into the USB wireless LAN module connector.




Connecting Using a Modem

You can connect the camcorder to the Internet via a 3G/4G network by attaching a modem (option) to the camcorder using a CBK-NA1 Network Adaptor Kit (option).



Connecting

1 Connect the modem (option) to the USB connector of the CBK-NA1E USB extension adaptor.



For details about connecting a modem, refer to the instruction manual supplied with the modem.

2 Set Maintenance > Network > Wireless Network to Modem.

3 Set Maintenance > Network > Setting to On.


[Notes]

- Always turn the camcorder off before connecting or removing the CBK-NA1 and modem.
- It may take some time (30 seconds to 1 minute) to enable modem mode. Wait until the "3G/4G" network status indicator (page 17) stops flashing on the LCD screen or in the viewfinder.

Connecting Using Wireless LAN Station Mode (Wi-Fi Station Mode)

You can connect to the Internet using Wi-Fi station mode by attaching the IFU-WLM3 USB Wireless LAN Module (supplied) or CBK-WA02 Wireless LAN Adaptor (option) to the camcorder, and using a 3G/4G/LTE-compatible access point (option) or using device tethering.

For details about attaching devices, see "Attaching the IFU-WLM3" (page 59) and "Attaching the CBK-WA02" (page 59).



If the access point and device supports WPS, connect using the procedure in "Connecting to an access point using WPS" (page 61). If WPS is not supported, connect using the procedure in "Connecting to an access point in station mode without using WPS" (page 74).

First, turn the access point and device on, and configure the device tethering function if planning to use tethering.

Transferring Files

You can transfer proxy files recorded on an SD card and original files recorded on SxS memory cards to a server on the Internet when connected to the Internet via a 3G/4G/LTE network, access point, or wired LAN router.

Preparation for Transfer


- 1 Connect the camcorder to the Internet using the procedures in “Connecting Devices using Wireless LAN” (page 59) and “Connecting to the Internet” (page 63).
- 2 You must first register a server to which you want to transfer files.
For details about registering a server, see “To register a new destination server” (page 75).

Transferring

You can select proxy files on an SD card or original files on SxS memory cards for transfer to a server.

Transferring proxy files on an SD card

- 1 Connect the camcorder and device using a LAN connection, then launch a browser on the device to access the camcorder.
- 2 Display a file list screen to select files.
- 3 Tap  and select [Media Info], then tap [SD Card].
The SD Card screen appears.



Using “Content Browser Mobile” application version 2.0 or later, you can quickly display a thumbnail for a proxy file on an SD card by using the still image of the first frame.

- 4 Select the files you want to transfer.
Tap a file to select it. Tap a file a second time to de-select it. You can double-tap a file to play the file to check its content.

- 5 Tap [Transfer].
The default destination server specified in [Default Setting] appears (see “To register a new destination server” (page 75)).
To change the destination server, tap the destination server to display a list and then select a different server. Enter the directory on the destination server, as required.



- 6 Tap [Transfer].
Transfer of the selected files begins. To cancel file transfer, tap [Cancel].

If Maintenance >File Transfer >Auto Upload(Proxy) in the setup menu is set to On beforehand, the file is automatically uploaded to the specified server when proxy recording finishes.

Transferring parts of proxy files

Using “Content Browser Mobile” application version 2.0 or later, you can specify In/Out points in proxy files to cut out and transfer the cutout parts. You can also transfer the cutout portions of multiple files using the Storyboard.

[Notes]

- Margins of up to 15 frames are added before and after the cutout region in the created file.
- Files created from cutouts from proxy files recorded using network function software (V1.25 or earlier) may not be imported into non-linear editors.
- When partial transfer is performed using the Storyboard, the file for sending Storyboard information to a non-linear editor is displayed in the Job List.
- When transferring, a General/Sony/tmp folder is created automatically on the SD card. The file is temporarily stored in this folder, and is automatically deleted after the file transfer is completed.

Transferring original files on SxS memory cards


- 1 Connect the camcorder and device using a LAN connection, then launch a browser on the device to connect to the camcorder
“Connecting Devices using Wireless LAN” (page 59).

- 2 Select Maintenance >File Transfer >File Transfer in the setup menu.

- 3 Turn the MENU knob to select [Execute], then press the knob.
File transfer mode is initiated.


- 4 Display a file list screen to select files in the browser on the device.

- 5 Tap  and select [Media Info], then tap Slot A (for files recorded on media in slot A) or Slot B (for files recorded on media in slot B).
The Slot A or Slot B screen appears.
Example: Slot A screen



- 6 Select the files you want to transfer.
Tap a file to select it. Tap a file a second time to de-select it.

- 7 Tap [Transfer].
The default destination server specified in [Default Setting] appears (see “To register a new destination server” (page 75)).
To change the destination server, tap the destination server to display a list and then select a different server.
Enter the directory on the destination server in [Directory].



- 8 Tap [Transfer].
Transfer of the selected files begins. To cancel file transfer, tap [Cancel].
When the transfer of all files is completed, transfer mode is automatically released, and the display returns to the camera shooting screen.

If Maintenance >File Transfer >Remote File Transfer in the setup menu is set to Enable beforehand, file transfer mode is initiated automatically without performing steps 2 and 3.

[Note]

- Files cannot be transferred under the following conditions.
• During recording, playback, or when displaying the thumbnail screen

- When Maintenance >Network >Wireless Network >Wi-Fi Access Point and Wired LAN >Disable in the setup menu are set to Disable
- When the streaming function is enabled (Maintenance >Streaming >Setting is set to On)

Transferring parts of original files

Using “Content Browser Mobile” application version 2.0 or later, you can specify In/Out points in original files recorded by the camcorder to cut out and transfer the cutout parts.

You can also transfer the cutout portions of multiple files using the Storyboard.

The following formats of original files are supported.

- XAVC-I
- XAVC-L
- HD422 (exFAT/UDF)
- HD420HQ (exFAT/UDF)

[Note]

To transfer a part of an original file using “Content Browser Mobile,” a proxy file with the same file name as the original file is required.

Enable the creation of proxy files before you start to record. The relevant settings are shown below.

- Set Operation >Proxy Recording Mode >Setting in the setup menu to On.
- When network client mode is enabled, set Maintenance >Network Client Mode >Detail Settings> NCM with Proxy in the setup menu to Enable.

Monitoring the File Transfer

Tap [Job List] on the SD Card, Slot A, or Slot B screen to display the Job List screen to check the status of the file transfer (page 75).

Transmitting Streaming Video and Audio

You can transmit the video and audio captured/played back with the camcorder via the Internet or local network.

Preparation for Streaming Transmission

- 1 Connect the camcorder to the Internet using the procedures in “Connecting Devices using Wireless LAN” (page 59) and “Connecting to the Internet” (page 63).
- 2 Select Preset1 (or Preset2, Preset3) in Maintenance >Streaming in the setup menu. The streaming connection destination setup screen appears.
- 3 Set Size, Bit Rate, Type, and items according to Type on the screen. For details and limitations about settings, see “Streaming settings” (page 73).
- 4 Select Preset1 (or Preset2, Preset3), set in steps 1 and 2, in Maintenance >Streaming >Preset Select in the setup menu.

Starting Streaming

- 1 Set Maintenance >Streaming >Setting in the setup menu to On. Streaming starts according to the settings. You can assign Streaming to an assignable switch. For details about assignment, see “Assigning Functions to Assignable Switches” (page 114).

[Notes]

- Streaming cannot be started under the following menu settings.
 - When Maintenance >Network >Setting in the setup menu is set to Off
 - When Maintenance >Network Client Mode >Setting in the setup menu is set to On
 - When Maintenance >Network >Setting in the setup menu is set to On, but Maintenance >Network >Wireless Network is set to Off and Maintenance >Network >Wired LAN is set to Disable
- It may take several tens of seconds to stream actual video or audio after starting streaming.
- You cannot start streaming when playing back an SD format clip.
- If you set the streaming transmission destination is set incorrectly or the camcorder does not connect to the network, “X” appears on the screen as the streaming status indicator.
- Streaming in network client mode (page 69), monitoring, proxy recording, and file transfer are not available after switching to streaming mode.
- Starting streaming while monitoring, proxy recording, or transferring files will stop the corresponding function.

Stopping Streaming

Set Maintenance >Streaming >Setting to Off to stop streaming.
When Streaming is On, streaming can also be stopped by pressing the assignable switch to which Streaming has been assigned.

When the camcorder is connected to a device via Wireless LAN (page 59) or is connected to the Internet using wireless LAN station mode (page 61), you can also set the streaming transmission destination and start/stop streaming from the web menu (page 72).

Streaming High Quality Video

High-quality streaming is supported by enabling network client mode and connecting and using a Network RX Station (option) as a Connection Control Manager (CCM).

- 1 Connect the camcorder to the network.
For details, see “Connecting Devices using Wireless LAN” (page 59) and “Connecting to the Internet” (page 63).

- 2 Set each item in Maintenance > Network Client Mode > Detail Settings in the setup menu.

Item	Description
CCM Address	Enter the IP address of the CCM to connect. (Host name or IP address)
CCM Port	Enter the port number of the CCM to connect.
User Name	Enter the user name.
Password	Enter the password.
NCM With Proxy	Enable/disable proxy recording when connected with a CCM.

[Notes]

- Network client mode cannot be set if values are not entered for all items.
- Setting Maintenance > Network Client Mode > Detail Settings > NCM with Proxy in the setup menu to Enable enables proxy recording, even when network client mode is enabled. To enable the NCM with Proxy setting, set Operation > Proxy Recording Mode > Setting in the setup menu to On.
- If Maintenance > Network Client Mode > Detail Settings > NCM with Proxy in the setup menu is set to Disable, proxy recording stops if network client mode is set to On during recording.
If original file recording is continuing, set both to Off to restart proxy recording.
- If Operation > Proxy Recording Mode > Proxy File > Size in the setup menu is set to HD Auto(9Mbps) or HD Auto(6Mbps), NCM with Proxy cannot be enabled.
If HD Auto(9Mbps) or HD Auto(6Mbps) is set after NCM with Proxy is set to Enable, the setting is maintained, but proxy recording is not performed.

- 3 Set Maintenance > Network Client Mode > Setting in the setup menu to On.

Network client mode is enabled, and the camcorder connects to the Network RX Station.

Live streaming starts in response to Network RX Station operation.

For details about operation, refer to the instruction manual for the Network RX Station. You can assign Setting (On/Off) for Network Client Mode to an assignable switch. For details about assignment, see “Assigning Functions to Assignable Switches” (page 114).

[Notes]

- Changing to network client mode during normal streaming (page 68) is not possible.
- After changing to network client mode, normal streaming (page 68) and monitoring are not available.
- Changing to network client mode while monitoring will stop the monitoring.
- File transfer is not supported during streaming in network client mode. File transfer is supported after stopping streaming.
- If streaming in network client mode is started during file transfer, the file transfer stops. File transfer restarts after stopping streaming.
- The available streaming bit rates that can be configured by the Network RX Station are limited to the following.
 - If the proxy recording format is 1280x720 9Mbps/6Mbps, the streaming bit rate is set to 1 Mbps or lower.
 - If the proxy recording format is 640x360 3Mbps, the streaming bit rate is set to 3 Mbps or lower.
- The proxy format cannot be changed in network client mode. To change the format, first set Network Client Mode to Off.

Transferring files in network client mode

You can transfer files to a server set by the CCM by connecting a Network RX Station acting as a CCM and the camcorder in network client mode.

- 1 Select the files you want to transfer.

- To transfer a proxy recording:
Follow steps 1 to 4 in “Transferring proxy files on an SD card” (page 66).

- To transfer original files:
Follow steps 1 to 6 in “Transferring original files on SxS memory cards” (page 66)

- 2 Tap [Transfer].

“NCM: RX Server” is displayed as a destination. Specify “NCM: RX Server” as the destination.

- 3 Tap [Transfer].

Transfer of the selected files to the server specified on the CCM starts.

[Note]

The destination can also be set to “NCM: RX Server” when not in network client mode.
In this case, transfer is placed on hold, and then transfer to the server specified on the CCM starts after connecting to the CCM in network client mode.

Using Wi-Fi Remote Control

You can access the Wi-Fi remote control built into the camcorder from a smartphone, tablet, or other device over a wireless LAN connection.

Using the Wi-Fi remote control allows you to operate the camcorder remotely. This allows you to start/stop recording or configure settings remotely, and is useful in applications where the camcorder is fixed in a remote location or mounted on a crane, for example.

Displaying the Wi-Fi Remote Control

The Wi-Fi Remote screen is automatically resized to match the screen size of the connected device.

1 Connect the camcorder to the Internet using the procedures in "Connecting Devices using Wireless LAN" (page 59) and "Connecting to the Internet" (page 63).

2 Launch a browser on the device and enter "http://<IP_address>/rm.html" in the URL bar, where "<IP_address>" is the IP address (Maintenance >Network >IP Address (Wireless) in the setup menu) of the camcorder. For example, if the IP address is 192.168.1.1, enter "http://192.168.1.1/rm.html" in the URL bar.

3 Enter the user name and password (Maintenance >Basic Authentication (page 108) in the setup menu) on the browser screen.

When connection is successful, the Wi-Fi Remote screen appears on the device.

You use the Wi-Fi Remote screen to operate the camcorder.

You can disable the REC button operation by sliding the Lock knob to the right on the screen.

You can also display the Wi-Fi remote control


using [Cam Remote Control] (page 72) from the web menu.

[Notes]

- To display the page for a smartphone, change "rm.html" to "rms.html" in the URL. To display the page for a tablet, change "rm.html" to "rmthtml" in the URL. When "rm.html" is entered, the page automatically switches for display on the corresponding device. However, the appropriate page may not be displayed, depending on the device.
- The Wi-Fi Remote screen may not match the camcorder settings under the following circumstances. If this occurs, reload the browser window.
 - If the camcorder is restarted while connected
 - If the camcorder is operated directly while connected
 - If the device has been reconnected
 - If the browser Forward/Back buttons have been used
- The Wi-Fi remote control may not function if the wireless signal strength becomes weak


Wi-Fi Remote Screen (Smartphones)

Main screen




- Status display
- Shooting settings
 - Iris, Focus, Zoom, S&Q FPS, Shutter, White, Gamma, Auto Iris, Gain, ATW, Color Bars, Auto Black, Auto White

Cursor screen



- Status indicators
- Cursor control buttons, menu/status display
 - Up, Left, Set, Right, Down, Cancel/Back, Menu, Status, Thumbnail, Option (SHIFT + SET)

Assign screen



- Status display
- Assignable switches
 - Assignable switch 0, 1, 3, 4, 5

Playback screen



- Status display
- Playback control buttons
 - F Rev, Play/Pause, F Fwd, Prev, Stop, Next


Wi-Fi Remote Screen (Tablets)

Main screen




- Status display
- Assignable switches
 - Assignable switch 0, 1, 3, 4, 5
- Shooting settings
 - s&o, FPS, Shutter, White, Gamma, Auto Iris, Gain, ATW, Color Bars, Auto Black, Auto White

Playback screen




- Status display
- Playback control buttons
 - F Rev, Play/Pause, F Fwd, Stop, Next

Cursor screen



- Status display
- Cursor control buttons, menu/status display
 - Up, Left, Set, Right, Down, Cancel/Back, Menu, Status, Thumbnail, Option (SHIFT + SET)

Assign screen



- Assignable switches
 - Assignable switch 0, 1, 3, 4, 5

Configuring from the Web Menu

The web menu of the camcorder appears when the camcorder is accessed from a browser on a device connected using a wireless LAN connection. Using the web menu, you can configure settings related to wireless functions, transfer files, and perform other actions.

Displaying the Web Menu

- 1 Connect the camcorder to the Internet using the procedures in “Connecting Devices using Wireless LAN” (page 59) and “Connecting to the Internet” (page 63).
- 2 Launch a browser on the device and enter “http://192.168.1.1:8080/index.html” in the URL bar.
The user name and password entry screen appears.
- 3 Enter a user name and password, then select [OK].
For the user name and password for access authentication, see Maintenance > Basic Authentication (page 108) in the setup menu.

Setup Menu

Launch a browser on the device and enter “http://<IP_address>:8080” in the URL bar, where “<IP_address>” is the IP address (Maintenance > Network > IP Address in the setup menu) of the camcorder, to display the Media Info > SD Card screen of the camcorder
Tapping  in the top left of the web menu screen will display the configuration menus. Tap the item you want to configure.

The menu has the following items: Settings, Media Info, Job List, and Cam Remote Control.

Settings

Used to configure the camcorder. This screen has the following items.

Item	Description	See
Wireless Module	Streaming format settings	Streaming Format Settings (page 72)
>Streaming Format		
Wireless Module	Proxy format settings	Proxy Format Settings (page 73)
>Proxy Format		
Wireless LAN	Wireless LAN settings	Wireless LAN Station Settings (page 73)
>Station Settings		
Wireless LAN	Wireless LAN settings status	Checking wireless LAN settings (page 74)

Wired LAN	Wired LAN settings	Wired LAN Settings (page 74)
>Wired LAN Settings		
Wired LAN	Wired LAN settings status	Checking wired LAN settings (page 74)
>Status		
Upload Settings	Transfer settings	Transfer (Upload) Settings (page 75)

Media Info

Displays media information and is used to select files to transfer from media.

- SD Card: Media inserted into the PROXY SD card slot of the camcorder
Double-clicking a file will start playback of the selected file.

[Note]

Playback may not be supported, depending on the operating system of the terminal device used and the browser version. If this occurs, use “Content Browser Mobile.”

- Slot A: Media inserted into card slot A of the camcorder
- Slot B: Media inserted into card slot B of the camcorder

Job List

Displays the Job List screen for managing file transfers (page 75).

Cam Remote Control

Displays the Wi-Fi remote control screen (page 70).

Streaming Format Settings


You can configure the stream for monitoring by devices, and set the format and transmission destination of the stream for streaming via the Internet or local network.

Video

- AVC/H.264 Main Profile, 4:2:0 Long GOP
- Size is selected in the following settings.

Audio

- AAC-LC compression
- Sampling frequency: 48 KHz
- Bit rate: 128 kbps for stereo



Monitoring Settings

You can set the format for monitoring by devices.

Item	Description	Setting
Monitoring Size	Sets the video size and bit rate for monitoring.	480x270(1Mbps)/480x270(0.5Mbps)
Monitoring Frame Rate	Displays the video frame rate for monitoring.	23.98fps/25fps/29.97fps/50fps/59.94fps
Monitoring Bit Rate	Displays the video bit rate for monitoring.	1Mbps(VBR)/0.5Mbps(VBR)

[Notes]

- The bit rate is an average value, so this value may be exceeded at times.
- A video frame rate of 24 fps is not supported.
- 640x360 (3Mbps (VBR)) is not supported for Monitoring Size.

Streaming settings

You can set the format and transmission destination for streaming. Up to three settings can be preset.

Item	Description	Setting
On/Off	Switches streaming transmission on/off.	On/Off

Preset	Selects the preset from Preset 1 to Preset 3. You can edit Preset by tapping Edit.	Preset1/Preset2/ Preset3
Type	Selects the type of video for streaming.	MPEG-2 TS/UDP/ MPEG-2 TS/ RTP

Size	Sets the size of video for streaming. When HD Auto is selected, the size is set to 1920×1080 or 1280×720, according to the setting of the recording format recorded on the SxS memory card or the format of the clip to be played back.	HD Auto/ 1280×720/ 640×360/ 480×270/ set to 1920×1080 or 320×180
Bit Rate	Sets the bit rate of video for streaming. The selectable bit rate varies depending on the Size setting.	9Mbps/6Mbps/ 3Mbps/2Mbps/ 1Mbps/0.5Mbps/ 0.3Mbps(Mono L)/ 0.3Mbps(Mono R)/ 0.2Mbps(Mono L)/ 0.2Mbps(Mono R)
Destination Address	Enter the address of the transmission destination server for streaming data.	Host name or IP address

Item	Description	Setting
Destination Port	Enter the port number of the transmission destination server used for streaming.	1 to 65535
Audio Channel Select	Selects the audio channels for the streaming output.	Ch-1 & Ch-2/ Ch-3 & Ch-4

[Notes]

- When Streaming is set to On, the monitoring function cannot be used.
- Audio/video data is transmitted as-is via the Internet. Accordingly, the data may potentially be exposed to other parties.
- Always check that the transmission destination can receive the streaming data. The data may be sent to an unintended party if the address or other settings are configured incorrectly.
- Not all frames may be played, depending on the status of the network.
- The picture quality may deteriorate in scenes with excessive motion.
- Not all frames may be played when the stream is set to a large size with a small bit rate.
- To reduce this, select a smaller size for the Size setting.
- If a network with bandwidth of less than 500 kbps is used, Size and Bit Rate are set to the following.
 - When Size is 480×270, Bit Rate is set to 0.3Mbps(Mono L), 0.3Mbps(Mono R), 0.2Mbps(Mono L), or 0.2Mbps(Mono R).
 - When Size is 320×180, Bit Rate is set to 0.2Mbps(Mono L) or 0.2Mbps(Mono R).
- When this occurs, video is set to a frame rate of 10 fps, and audio is set to a sampling frequency of 48 kHz and a bit rate of 56 kbps.
- When Bit Rate is 0.3Mbps(Mono L) or 0.2Mbps(Mono L), Audio Channel Select >Ch-1 & Ch-2 is set to Ch-1 or Ch-3 & Ch-4 is set to Ch-3.
- When Bit Rate is 0.3Mbps(Mono R) or 0.2Mbps(Mono R), Audio Channel Select >Ch-1 & Ch-2 is set to Ch-2 or Ch-3 & Ch-4 is set to Ch-4.

Proxy Format Settings


You can set the format of the proxy file that is recorded on the SD card of the camcorder.

Video

- XAVC Proxy (AVC/H.264 Main Profile, 4:2:0 Long GOP)
- Size is selected in the following settings.

Audio

- AAC-LC compression
- Sampling frequency: 48 kHz
- Bit rate: 128 kbps for stereo



Item	Description	Setting
Proxy File	Sets the video size and bit rate for proxy files.	HD Auto(9Mbps)/ HD Auto(6Mbps)/ 1280×720(9Mbps)/ 1280×720(6Mbps)/ 640×360(3Mbps)/ 480×270(1Mbps)/ 480×270(0.5Mbps)
Proxy File recording	Displays the video frame rate for proxy files.	23.98fps/ 25fps/ 29.97fps/ 50fps/ 59.94fps
Proxy File recording >Frame Rate	Displays the video bit rate for proxy files.	9Mbps(VBR)/ 6Mbps(VBR)/ 3Mbps(VBR)/ 1Mbps(VBR)/ 0.5Mbps(VBR)


Item	Description	Setting
Proxy File recording >Audio Channel Select	Sets the audio channel to record to proxy data.	Ch-1 & Ch-2/ Ch-3 & Ch-4

[Notes]

- The bit rate is an average value, so this value may be exceeded at times.
- 24 fps is not supported.
- When HD Auto is selected for Size in the proxy format settings, the proxy format is set according to the setting of the recording format recorded on the SxS memory card or the format of the clip to be played back.
- Proxy files recorded with Size set to HD Auto in the proxy format settings may not be able to be played in a browser or Content Browser Mobile. Insert SD cards for recording proxy files directly into a computer to play the files.

Wireless LAN Station Settings

Use this screen to make settings for connecting the camcorder to a wireless LAN.



Item	Description
Host Name	Name of the camcorder (can be modified)
SSID	Displays the SSID selected in [Access Point1].
Key	Enter the password for the access point.

Item	Description
DHCP	Enables/disables DHCP. When set to [On], an IP address is automatically assigned to the camcorder.
IP Address	To enter the camcorder IP address manually, set to [Off].
Subnet mask	Enter the IP address of the camcorder. Enabled only when DHCP is [Off].
Gateway	Enter the gateway for the access point. Enabled only when DHCP is [Off].
DNS Auto	Obtains DNS address automatically. When set to On, the address of the DNS server is obtained automatically.
Primary DNS Server	Enter the primary DNS server for the access point. Enabled only when DNS Auto is [Off].
Secondary DNS Server	Enter the secondary DNS server for the access point. Enabled only when DNS Auto is [Off].
Submit	Applies the wireless LAN settings.

Connecting to an access point in station mode without using WPS

- 1 Connect the camcorder and device using access point mode (page 60).
- 2 Configure settings on the Station Settings screen.

Configure settings to match the settings of the access point connection.
For details about access point settings, refer to the instruction manual for the access point.

- 3 Tap [Submit].
The specified settings are applied.
- 4 Select Maintenance > Network > Wireless Network in the setup menu.
- 5 Turn the MENU knob to select [Wi-Fi Station], then press the knob.
This step connects the camcorder to the access point in station mode. Proceed to step 9 in "Connecting to an access point using WPS" (page 61) to access the camcorder from the device.


Checking wireless LAN settings

Use the Wireless LAN > Status tab to monitor the wireless LAN status.
The displayed settings will vary depending on the wireless LAN mode of the camcorder.

Access point mode




Station mode



Wired LAN Settings

Use this screen to make settings for connecting the camcorder to a wired LAN.



Item	Description
DHCP	Enables/disables DHCP. When set to [On], an IP address is automatically assigned to the camcorder.
IP Address	To enter the camcorder IP address manually, set to [Off].
Subnet mask	Enter the IP address of the camcorder. Enabled when DHCP is [Off].
Gateway	Enter the gateway for the access point. Enabled when DHCP is [Off].


Item	Description
DNS Auto	Obtains DNS address automatically. When set to On, the address of the DNS server is obtained automatically.
Primary DNS Server	Enter the primary DNS server of the router. Enabled when DNS Auto is [Off].
Secondary DNS Server	Enter the secondary DNS server of the router. Enabled when DNS Auto is [Off].

Web/Cam Remote	Enables/disables access to the camcorder web menu and Wi-Fi remote control. When set to On, access is permitted.
Submit	Sets the wired LAN settings.

[Note]
To prevent unauthorized access from the Internet, it is recommended that Web/Cam Remote be set to On only when the wired LAN network is not connected to the Internet. When connecting to the Internet, check that the network connection is a secure network before use.

Checking wired LAN settings

Use the Wired LAN > Status tab to monitor the wired LAN status.



- Abort selected: Stop file transfer.
- Delete from list: Delete the file from the transfer list.
- Start selected: Start file transfer.
- Select All: Select all files in the list.
- Clear completed: Delete all files that have been transferred from the list.

Supported Network Functions and Operating Limitations

Network Functions and Network Connection Settings

The supported network functions and corresponding network connection settings (Maintenance >Network >Wireless Network and Wired LAN settings) are shown below.

To enable the network functions, set Maintenance >Network >Setting in the setup menu to On.

Network function	Maintenance >Network>Wireless Network in the setup menu				Maintenance >Network >Wired LAN in the setup menu			
	Wi-Fi Access Point	Wi-Fi Station	Modem	Off	Enable	Disable		
Proxy recording ¹⁾ (page 53)	Yes	Yes	Yes	Yes	Yes	Yes		
Proxy playback (page 72)	Yes ²⁾	Yes ²⁾	No	No	No	Yes ²⁾	No	
File transfer (page 66)	No	Yes ²⁾	Yes ²⁾	No	Yes ²⁾	No	No	
Streaming transmission (page 68)	No	Yes	Yes	No	Yes	No	No	
Monitoring (page 72)	Yes ²⁾	Yes ²⁾	No	No	Yes ²⁾	No	No	
Network client mode (page 69)	No	Yes	Yes	No	Yes	No	No	
Camcorder remote control (page 70)	Yes ²⁾	Yes ²⁾	No	No	Yes ²⁾	No	No	

1) Proxy recording is enabled when Operation >Proxy Recording Mode >Setting in the setup menu is set to On.
2) Supports camcorder and network-connected device functions.

Limitations on Simultaneous Use of Network Functions

The following limitations apply to the simultaneous use of network functions.

Wireless LAN connection	Wired LAN connection	Operation
None	Disabled	Network function stopped
USB wireless LAN module	Disabled	USB wireless LAN module operating
3G/4G/LTE USB modem	Disabled	3G/4G/LTE USB modem operating
None	Enabled	Wired LAN operating
USB wireless LAN module	Enabled	USB wireless LAN module and wired LAN operating ¹⁾


1) Streaming and file transfer operate using wired LAN. The USB wireless LAN module is reserved for Wi-Fi remote control operation.

[Note]

Wired LAN connection is not possible when the USB extension adaptor of the CBK-NA1R Ethernet Adaptor, supplied with the CBK-NA1 (option), is attached to the USB wireless LAN module on the camcorder.

Clip Operations on the Thumbnail Screen

Thumbnail Screen



The thumbnail screen appears if you press the THUMBNAI button in E-E or playback mode. Thumbnail screens display lists of the index pictures of clips stored on SxS memory cards as thumbnails. You can select any clip (page 79) on the thumbnail screen and start playback of that clip (page 79). You can also add a clip flag to any clip on the thumbnail screen to filter clips according to the flags. You can also switch to the Essence Mark thumbnail screen from the thumbnail screen and add essence marks (for example, shot marks) to any frame in the clip.

To hide the thumbnail screen, press the THUMBNAI button.

- Thumbnail (index picture)**
When a clip is recorded, its first frame is automatically displayed as the index picture. You can change the index picture to any frame (page 82).
- Selected media icon/media status**
A mark is displayed if the media is protected. If two SxS memory cards are inserted in the camcorder, you can switch between them using the SLOT SELECT button.
[Note]
You cannot switch between SxS memory cards while the Essence Mark thumbnail screen is displayed.
- Clip number / total number of clips**
- Battery / Voltage status**
- Playback disabled indicator**
- Clip status**
Displays the clips status using an icon.

Icon	Meaning
S, OK, NG, KP	Essence mark or clip flag attached to a clip
Lock icon	Clip is locked (protected)
- Clip select checkbox**
Place a check mark in the checkbox to select a clip (thumbnail).
- Thumbnail information**
Displays thumbnail information. The displayed information varies according to the Customize View setting (page 83).
- Clip name / title**
Displays the name or title of the selected clip.
- Recording video format**
- Special recording information**
Displays the recording mode if the clip was recorded using a special recording mode (Slow & Quick Motion). For Slow & Quick Motion clips, the [Recording frame rate/Playback frame rate] are displayed on the right.
- Clip duration**
- Creation date**

Selecting Clips

To select a clip thumbnail, do one of the following to move the yellow cursor to the thumbnail that you want to select:

- Press the , , ,  buttons.
- Turn the MENU knob.
- Press the PREV or NEXT button.

Selecting the First Thumbnail

Press and hold the F REV button, and press the PREV button.

Selecting the Last Thumbnail

Press and hold the F FWD button, and press the NEXT button.

Playing Clips Sequentially Starting from the Selected Clip

- 1 Select the thumbnail of the clip that you want to play first.
- 2 Press the PLAY/PAUSE button. Playback begins from the start of the selected clip.

It plays all clips sequentially starting from the selected clip.

After the last clip has been played, the camcorder enters pause (still image) mode at the last frame of the last clip.

Press the THUMBNAIL button to return to the thumbnail screen.

[Notes]

- Not all clips may be played back sequentially if the clips on the SxS memory cards were recorded with a mixture of different recording formats.
- Clips with an playback-disabled icon (page 78) displayed on the thumbnail screen are not played. The corresponding clips are skipped and sequential playback continues.
- There may be momentary picture breakup or still image display at the boundary between clips. During this time, the play controls and the THUMBNAIL button cannot be operated.
- When you select a clip in the thumbnail screen and begin playback, there may be momentary picture breakup at the start of the clip. To view the start of the clip without breakup, put the camcorder into playback mode, pause, use the PREV button to return to the start of the clip, and start play again.

Pausing Playback

Press the PLAY/PAUSE button.

The PLAY/PAUSE indicator flashes while play is paused.

Press the button again to return to play mode.

Playing at High Speed

Press the F FWD button (page 8) or the F REV button (page 7).

To return to normal playback, press the PLAY/PAUSE button.

Returning to the Start of the Current Clip

Press the PREV button.

- During playback or F FWD, this jumps to the start of the current clip and starts playback.
- During F REV or pause, this jumps to the start of the current clip and displays a still image.
- Each subsequent press of the button moves to the previous clip.

Playing from the Start of the First Clip

Simultaneously press the PREV and F REV buttons. This jumps to the start of the first clip on the SxS memory card.

Jumping to the Start of the Next Clip

Press the NEXT button.

- During playback or F FWD, this jumps to the start of the next clip and starts playback.
- During F REV or pause, this jumps to the start of the next clip and displays a still image.
- Each subsequent press of the button moves to the next clip.

Jumping to the Last Clip

Simultaneously press the F FWD and NEXT buttons. This jumps to the last frame of the last clip recorded on the SxS memory card.

Adding a Shot Mark during Playback

You can add shot marks to clips during playback by using the same method used during recording (page 49).

[Notes]

- Shot marks cannot be recorded when the SxS memory card is write protected.
- Shot marks cannot be added to the first frame of each clip or the last frame of the last clip.

Stopping Playback

Press the STOP button: Playback stops, and the camcorder enters E-E mode.

Press the THUMBNAIL button: Playback stops and the thumbnail screen (page 78) appears in the viewfinder.


Play also stops if you eject the memory card. In this case, the camera picture appears in the viewfinder.

Basic Thumbnail Menu Operations

The Thumbnail menu is used to protect/delete clips, check properties, add/delete clip flags and essence marks to frames in a clip, and other tasks.

- 1 Press the THUMBNAI button.
The thumbnail screen appears.
- 2 Set the MENU ON/OFF switch to ON, or press the MENU button.
The menu screen appears.

- 3 Turn the MENU knob to select [Thumbnail], then press the knob.
You can also press the $\uparrow$ or $\downarrow$ button to select [Thumbnail], and press the SET button.



To hide the Thumbnail menu, press the MENU button again.

To select a menu item/sub-item, do one of the following.

- Turn the MENU knob to select an item or sub-item, then press the knob.
- Press the arrow buttons ($\uparrow$, $\downarrow$, $\leftarrow$, $\rightarrow$) to select an item or sub-item, then press the SET button. A selection list or a clip properties screen appears (page 81) according to the selected item or sub-item.

To return to the previous screen, push the MENU CANCEL/PRST/ESCAPE switch down to the ESCAPE position.

[Notes]

- When an SxS memory card is write protected, it is not possible to copy, delete, change index pictures, or add and delete clip flags marks and shot marks.
- Some items cannot be selected, depending on the state when the menu was displayed.

For details about the thumbnail screen structure, see “Thumbnail Menu” (page 83).

Protecting Clips

You can protect a specified clip or all clips to protect the clips from being deleted.

$\mathcal{P}$ is added to the thumbnails of protected clips. Clips can be protected on the thumbnail screen or the filtered clip thumbnail screen (page 82).

Protecting a specific clip

- 1 Select Thumbnail > Lock/Unlock Clip > Select Clip in the setup menu.

- 2 Turn the MENU knob to select [Execute], then press the knob.
The clip selection screen appears.

- 3 Turn the MENU knob to select a clip to protect, then press the knob.
A check mark is attached to the selected clip.

- 4 Simultaneously press the SET button and SHIFT button.
A confirmation screen appears.

- 5 Turn the MENU knob to select [Execute], then press the knob.
The clip is protected, and a completion message appears.

- 6 Press the MENU knob to dismiss the message.

Protecting all clips

- 1 Select Thumbnail > Lock/Unlock Clip > Lock All Clips in the setup menu.

- 2 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen appears.

- 3 Turn the MENU knob to select [Execute], then press the knob.
All clips are protected, and a completion message appears.

- 4 Press the MENU knob to dismiss the message.

Unlocking all clips

- 1 Select Thumbnail > Lock/Unlock Clip > Unlock All Clips in the setup menu.

- 2 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen appears.

- 3 Turn the MENU knob to select [Execute], then press the knob.
All clips are unlocked, and a completion message appears.

- 4 Press the MENU knob to dismiss the message.

Copying Clips

You can copy clips to another SxS memory card. Clips are copied to destination SxS memory cards using the same names as the original clips.

[Notes]

- If a clip with the same name already exists at the copy destination SxS memory card, a one-digit number in parentheses is added to the original name.
The number in parentheses is the smallest number that does not exist at the copy destination.

Example:

ABCD0002 $\rightarrow$ ABCD0002(1)
ABCD0002(1) $\rightarrow$ ABCD0002(2)
ABCD0005(3) $\rightarrow$ ABCD0005(4)

- If the parenthetical numbers (1) to (999) already exist at the copy destination, because a clip has been copied more than 1000 times, it is not possible to copy any more clips under that name.

- A message appears if there is not enough free space on the copy destination SxS memory card. Exchange the card for one with more free space.
- When multiple clips are recorded on the source SxS memory card, it may not be possible to copy all clips even when the source and destination memory cards have the same capacity, depending on the memory characteristics and usage of the memory cards.

Copying a specific clip

- 1 Select Thumbnail > Copy Clip > Select Clip in the setup menu.

- 2 Turn the MENU knob to select [Execute], then press the knob.
The clip selection screen appears.

- 3 Turn the MENU knob to select a clip to copy, then press the knob.
A check mark is attached to the selected clip.

- 4 Simultaneously press the SET button and SHIFT button.
A confirmation screen appears.

5 Turn the MENU knob to select [Execute], then press the knob.
The clip is copied, and a completion message appears.

6 Press the MENU knob to dismiss the message.

Copying all clips

You can copy all clips stored on the same SxS memory card at the same time to another SxS memory card.

1 Select Thumbnail >Copy Clip >All Clips in the setup menu.

2 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen appears.

3 Turn the MENU knob to select [Execute], then press the knob.
All clips are copied, and a completion message appears.

4 Press the MENU knob to dismiss the message.

Deleting Clips

You can delete clips from SxS memory cards. Clips can be deleted on the thumbnail screen or the filtered clip thumbnail screen (page 82).

1 Select Thumbnail >Delete Clip >Select Clip in the setup menu.

2 Turn the MENU knob to select [Execute], then press the knob.
The clip selection screen appears.

3 Turn the MENU knob to select a clip to delete, then press the knob.
A check mark is attached to the selected clip.

4 Simultaneously press the SET button and SHIFT button.
A confirmation screen appears.

5 Turn the MENU knob to select [Execute], then press the knob.
The clip is deleted, and a completion message appears.

6 Press the MENU knob to dismiss the message.

The clips below the deleted clip on the thumbnail screen move up one position.

Deleting all clips

You can delete all clips stored on the same SxS memory card at the same time.

[Notes]

- Deleted clips cannot be restored.
- If the media or clip is protected, this function is disabled.

1 Select Thumbnail >Delete Clip >All Clips in the setup menu.


2 Turn the MENU knob to select [Execute], then press the knob.
A confirmation screen appears.

3 Turn the MENU knob to select [Execute], then press the knob.
All clips are deleted, and a completion message appears.

4 Press the MENU knob to dismiss the message.

Displaying Clip Properties

The clip properties screen for the selected clip appears when you select Thumbnail >Display Clip Properties in the setup menu.



1. **Current clip image**
Displays the index picture and status of the selected clip.

2. **Timecode display**
TC Index: Timecode of the displayed image
Start: Timecode of the recording start point
End: Timecode of the recording end point
Duration: Duration between start and end points

3. **Creation date and modified date**

4. **Clip name**

5. **Recording format**
Video Codec: Video codec
Size: Picture size
FPS: Frame rate
Audio Codec: Audio codec
Ch/Bit: Audio recording channel/Number of bits for audio recording

6. **Special recording information**

7. **Recording device name**

To hide the clip properties screen, do one of the following.

Press the RESET/RETURN button: Returns to the Thumbnail menu screen.
Press the THUMBNAIL button: Sets the camcorder to E-E mode and displays the camera picture.
Press the PLAY/PAUSE button: Starts playback of the selected clip.

Adding Clip Flags to Clips

You can add clip flags (OK, NG or KP marks) to clips to filter the display of clips based on the clip flags. You can perform this operation on the thumbnail screen or the filtered clip thumbnail screen (page 82).

1 Select the thumbnail for the clip to which you want to add the clip flag, then select Thumbnail >Set Clip Flag in the setup menu.

2 Turn the MENU knob to select a clip flag, then press the knob.

Setting	Added clip flag
Add OK	OK
Add NG	NG
Add KEEP	KP

The clip flag is added to the thumbnail of the selected clip.

You can also use an assignable switch assigned with the clip flag function to add clip flags (page 114).

Deleting a Clip Flag

- 1 Select the thumbnail for the clip from which you want to delete a clip flag, then select Thumbnail >Set Clip Flag >Delete Clip Flag in the setup menu.
The clip flag is deleted.

Filtering the Clips Displayed using the Filtered Clip Screen

- 1 Select Thumbnail >Filter Clips in the setup menu.
 - 2 Turn the MENU knob to select a clip flag used to filter clips, then press the knob.
- | Setting | Filter clip flag |
|---------|--------------------------|
| OK | OK |
| NG | NG |
| KEEP | KP |
| None | (Clips are not filtered) |

The clip screen appears showing the clips filtered by the selected clip flag. This screen is referred to as the filtered clip screen.

- To cancel filtering, do one of the following.
- Press the RESET/RETURN button.
 - Select Thumbnail >Thumbnail View >All in the setup menu.

Adding/Deleting Essence Marks on Clips

You can add (and delete) essence marks (shot marks, recording start marks) to any frame in a clip. You add/delete essence marks on the essence mark thumbnail screen.

Adding a shot mark

- 1 Select Thumbnail > Thumbnail View > Essence Mark Thumbnail in the setup menu.
 - 2 Turn the MENU knob to select [All], and then press the knob.
 - 3 Select the thumbnail for the frame to which you want to add the essence mark on the essence mark thumbnail screen, then select Thumbnail >Set Shot Mark in the setup menu.
 - 4 Turn the MENU knob to select one of the following, then press the knob.
- | Setting | Operation |
|----------------|------------------|
| Add Shot Mark1 | Adds Shot Mark 1 |
| Add Shot Mark2 | Adds Shot Mark 2 |
- The shot mark is added to the selected frame.

Deleting a shot mark

- 1 Select Thumbnail > Thumbnail View > Essence Mark Thumbnail in the setup menu.
 - 2 Select the type of shot mark to delete.
 - 3 Select the thumbnail for the frame from which you want to delete a shot mark on the essence mark thumbnail screen, then select Thumbnail >Set Shot Mark in the setup menu.
 - 4 Turn the MENU knob to select one of the following, then press the knob.
- | Setting | Operation |
|-------------------|---------------------|
| Delete Shot Mark1 | Deletes Shot Mark 1 |
| Delete Shot Mark2 | Deletes Shot Mark 2 |
- The shot mark is deleted from the selected frame.

Filtering Clips (Frames) using the Essence Mark Thumbnail Screen

The essence mark thumbnail screen displays only those frames in a clip where an essence mark has been recorded in thumbnail view. Display the thumbnail screen, then either press the ESSENCE MARK button (page 9) or use the following procedure to display the essence mark thumbnail screen.

- 1 Select Thumbnail >Thumbnail View >Essence Mark Thumbnail in the setup menu.
- 2 Turn the MENU knob to select an essence mark used to filter frames, then press the knob.

Setting	Description
All	All frames with added essence marks
Rec Start	Frames with a recording start mark and the first frame of clips that do not have a recording start mark
Shot Mark0 to Shot Mark9	Frames with each shot mark

The essence mark thumbnail screen appears filtered by the selected essence mark.

If a clip is recorded using planning metadata that defines names for shot mark 0 to shot mark 9, the selection options in the list are displayed by the defined names.

Changing the Index Picture of a Clip

You can set the frame selected on the essence mark thumbnail screen as the index picture for the clip.
Select the thumbnail of the frame you want to set as the index picture for the clip, then select Thumbnail >Set Index Picture in the setup menu.

Thumbnail Menu

Default values are shown in **bold**.


Item	Sub-item setting	Description
Display Clip Properties	-	Displays clip properties (page 81).
Set Index Picture	-	Sets/changes the index picture of a clip (page 82).
Thumbnail View	Essence Mark Thumbnail All/Rec Start/Shot Mark1/Shot Mark2/Shot Mark3/Shot Mark4/Shot Mark5/Shot Mark6/Shot Mark7/Shot Mark8/Shot Mark9/Shot Mark0	Displays the essence mark thumbnail screen with clips filtered by essence mark (page 82).
Set Shot Mark	Clip Thumbnail	Displays the thumbnail screen (clip thumbnail screen) (page 78).
	Add Shot Mark1	Adds Shot Mark 1 to a frame (page 82).
	Delete Shot Mark1	Deletes Shot Mark 1 (page 82).
	Add Shot Mark2	Adds Shot Mark 2 to a frame (page 82).
	Delete Shot Mark2	Deletes Shot Mark 2 (page 82).
Set Clip Flag	Add OK	Adds an OK flag to a clip (page 81).
	Add NG	Adds an NG flag to a clip (page 81).
	Add KEEP	Adds a KP (Keep) flag to a clip (page 81).
Lock/Unlock Clip	Delete Clip Flag	Deletes a clip flag (page 82).
	Select Clip	Selects the clip to protect (page 80).
	Lock All Clips	Protects all clips on the media (page 80).
	Unlock All Clips	Unlocks all clips on the media (page 80).
Copy Clip	Select Clip	Selects the clip to copy (page 80).
	All Clips	Copies all clips on the media (page 81).
Delete Clip	Select Clip	Selects the clip to delete (page 81).
	All Clips	Deletes all clips on the media (page 81).

Item	Sub-item setting	Description
Filter Clips	OK	Filters the display of clips by OK flags (page 82).
	NG	Filters the display of clips by NG flags (page 82).
	KEEP	Filters the display of clips by KP (Keep) flags (page 82).
	None	Clips are not filtered (page 82).
Customize View	Thumbnail Caption Date Time/ Time Code / Duration/Sequential Number	Selects the information displayed beneath clip thumbnails. Date Time: Displays the date and time. Time Code: Displays the timecode. Duration: Displays the duration of the clip. Sequential Number: Displays a sequential number for each clip.

Setup Menu Organization

On this camcorder, settings for shooting and playback are made in the setup menu, which appears in the viewfinder.

The setup menu can also be displayed on an external video monitor (page 126).



Menu Structure

User menu

Menu used to arrange items from the setup menu in any chosen order (page 88).

Operation menu

Menu used to make settings related to shooting (excluding settings related to picture quality).

Paint menu

Menu used to make settings related to picture quality.

Thumbnail menu

Menu used to make settings related to clip thumbnails (page 83).

[Note]

The Thumbnail menu can be used only when a thumbnail screen (page 78) is displayed. It is disabled when the thumbnail screen is not displayed.

Maintenance Menu

Menu used to make settings related to camcorder maintenance and system management.

File menu

Menu used to make perform operations on files.

Menu Items

Operation menu

Item	Description	Page
Format	System settings	90
Format Media	Media format settings	91
Input/Output	Input/output signal settings	91
Super Impose	Superimposition settings	91
LCD	LCD monitor settings	91
Rec Function	Special recording mode settings	92
Proxy Recording Mode	Proxy data settings	92
Assignable Switch	Assign functions to assignable switches	93
VF Setting	Viewfinder settings	93
Marker	Marker settings	93
Gain Switch	Gain value settings	94
Auto Iris	Auto iris settings	94
Zebra	Zebra pattern settings	94
Display On/Off	Viewfinder display item settings	94
1/4" LED	Viewfinder 1/4" settings	95
White Setting	White balance settings	96
Offset White	Offset white settings	96
Shutter	Shutter settings	96
Slow Shutter	Slow shutter settings	96
Time Zone	Time settings	96
Clip	Clip settings	97
Update Media	Update media management information	97
GPS	Location information (GPS) settings	97

Item	Description	Page
Planning Metadata	Planning metadata settings	97
Flash Band Reduce	Flashband correction settings	98

Paint menu

Item	Description	Page
Switch Status	Correction functions and test signal on/off settings	98
White	Color temperature settings	98
Black	Black level settings	99
Flare	Flare correction settings	99
Gamma	Gamma correction settings	99
Black Gamma	Black gamma correction settings	99
Knee	Knee correction settings	100
White Clip	White clip settings	100
Detail(HD)	Detail settings	100
Detail(SD)	Detail settings	100
Aperture	Aperture correction settings	101
Skin Detail	Skin detail correction settings	101
Matrix	Matrix correction settings	101
Multi Matrix	Multi matrix correction settings	101
V Modulation	V modulation shading correction settings	102
Low Key	Low key saturation correction settings	102
Saturation	Saturation correction settings	102
Noise Suppression	Noise suppression settings	102

Maintenance menu

Item	Description	Page
White Shading	White shading correction settings	103
Black Shading	Black shading correction settings	103
Battery	Battery settings	103
DC Voltage Alarm	External DC source voltage alarm settings	103
Audio	Audio settings	103
WRR Setting	Wireless tuner settings	105
Time Code	Timecode settings	105
Essence Mark	Essence mark settings	106
Camera Config	Camcorder operation settings	106
Preset White	Preset white settings	107
White Filter	Filter settings	107
DCC Adjust	DCC settings	107
Flicker Reduce	Flicker correction settings	108
Genlock	Genlock settings	108
Auto Shading	Auto black shading correction settings	108
APR	APR settings	108
Basic	Basic authentication settings	108
Authentication	Network connection settings	108
Network	Network client mode settings	109
File Transfer	Wi-Fi transfer settings	109
Streaming	Streaming settings	109
Clock Set	Internal clock settings	110
Language	Display language settings	110
Hours Meter	Digital time counter settings	110
Network Reset	Network reset	110

Item	Description	Page
Fan Control	Fan control settings	110
VF Display Setting	Viewfinder display settings	110
Version	Version settings	111

File menu


Item	Description	Page
User File	User file settings	111
All File	ALL file settings	111
Scene File	Scene file settings	112
Reference File	Reference file settings	112
Lens File	Lens file settings	112
User Gamma	Gamma file settings	113

Basic Setup Menu Operations

Displaying the Setup Menu

Set the MENU ON/OFF switch to ON, or press the MENU button.
The camcorder enters menu mode and the menu list appears on the screen.

The following example shows the cursor positioned at the Operation menu




[Note]
The setup menu cannot be used when the camcorder is in focus magnification mode. Exit focus magnification mode by pressing the assignable switch to which the Focus Mag function has been assigned.

Making Menu Settings


- 1 Turn the MENU knob, or press the $\uparrow$ or $\downarrow$ button, to move the cursor to the desired menu.
A list of selectable menu items appears in the menu item selection area to the right of the menu list.
- 2 Press the MENU knob or the SET button.
The menu item selection screen appears.
You can also display the menu item selection screen by pressing the $\Rightarrow$ button.

• The menu item selection area displays a maximum of seven lines. You can scroll through menus with more than seven lines by moving the cursor up and down.




- Menu item selection area
- If the selected item has sub-items, they appear on the right.
- If there are no sub-items, the current setting appears on the right.
- Select [Back] to return to the previous level.

- 3 Turn the MENU knob, or press the $\uparrow$ or $\downarrow$ button, to move the cursor to the menu item that you want to set, and then confirm by pressing the MENU knob or the SET button.
The sub-items area appears to the right of the menu item selection area, and the cursor moves to the first sub-item.



- Settings area
- Displays sub-items and their current settings
- To return to the previous level, select [Back], press the $\Leftarrow$ button, or push the MENU CANCEL/PRST/ESCAPE switch down to the ESCAPE position.

- 4 Turn the MENU knob, or press the $\uparrow$ or $\downarrow$ button, to move the cursor to the sub-item that you want to set, and then confirm by pressing the MENU knob or the SET button.
The settings of the selected sub-item appear, and the cursor moves to the currently selected value.



- The settings area displays a maximum of nine lines. You can scroll through menus with more than nine sub-items by moving the cursor up and down.
- For sub-items with a large settings range (for example, -99 to +99), the settings area is not displayed. The current setting is highlighted to indicate that the value can be changed.


- 5 Turn the MENU knob, or press the $\uparrow$ or $\downarrow$ button, to select the value to set, and then confirm by pressing the MENU knob or the SET button.

The setting is changed, and the display is updated to show the new setting.
If you select [Execute] for an executable item, the corresponding function is executed.

If an item requires confirmation before execution, selecting the item in step 3 hides the menu and a confirmation message appears. Follow the instructions in the message to execute or cancel the operation.

Entering Text

When you select an item, such as a file name, which requires character entry, the character entry screen appears.



- 1 Press the MENU knob to select the type of character to enter, then press the MENU knob or SET button.

ABC: Uppercase alphabetic characters
abc: Lowercase alphabetic characters
123: Numeric characters
!#\$: Special characters

- 2 Select a character from the selected character type, then press the knob.
The cursor moves to the next field.
Space: Enters a space character at the cursor position.

$\Leftarrow$ / $\rightarrow$: Moves the position of the cursor.
BS: Deletes the character on the left of the cursor (backspace).

- 3 When finished, select [Done] and press the dial.
The character string is confirmed and the character entry screen disappears.

Canceling Changes to Settings

- 1 Push the MENU CANCEL/PRST/ESCAPE switch down to the ESCAPE position.

Exiting the Menu

- 1 Set the MENU ON/OFF switch to OFF or press the MENU button.
The normal camera picture reappears.

Locking/Unlocking the Menu

You can lock the setup menu so that only the User menu is displayed.

Locking the menu

- 1 Press and hold the MENU knob and press the MENU ON/OFF switch down to display the setup menu.
- 2 Display Maintenance >Camera Config >User Menu with Lock in the setup menu.

[Notes]

- When you press and hold the MENU knob and press the MENU ON/OFF switch down, Camera Config >User Menu Only changes to User Menu with Lock.
- If you press the MENU ON/OFF switch down without pressing the MENU knob or you press the MENU button to display the menu, Camera Config >User Menu with Lock is not displayed.

- 3 Select "On," then press the MENU knob.
The viewfinder screen display switches to the passcode number input screen.

- 4 Enter an arbitrary passcode number.

The valid input range is 0000 to 9999. The default value is 0000.

Enter a number and press the MENU knob to move the cursor to the next digit.

When all digits have been entered, move the cursor to [Set].

- 5 With [Set] selected, press the MENU knob.

The entry is applied.

A confirmation message appears.

Subsequently, only the User menu is displayed.

[Notes]

- If the menu is locked without registering the following setup menu items in the User menu, assigning the menu function to an assignable switch is not possible.
- If some of the following setup menu items are assigned to an assignable switch when the menu is locked, the setting for the functions assigned to assignable switches are forcibly set to Off when the menu is locked.

Setup menu	Functions assignable to assignable switches
------------	---

Operation > Rec Function	Picture Cache Rec
>Picture Cache Rec	
Operation > Rec Function	Clip Continuous Rec
>Clip Continuous Rec	
Operation > VF Setting	VF Mode
>Color Mode	

Operation > Display On/ Off >Video Signal Monitor	Video Signal Monitor
---	----------------------

Operation > Display On/ Off >Lens Info	Lens Info
Operation > Auto Iris	Spotlight
>Mode	Backlight
Operation > Marker	Marker
>Setting	
Maintenance > Audio	Front MIC
>Front MIC Select	
Maintenance > Network	Network Client
Client Mode >Setting	Mode

Maintenance >File Transfer >Auto Upload(Proxy)	Auto Upload(Proxy)
--	--------------------

Unlocking the menu

- 1 Press and hold the MENU knob and press the MENU ON/OFF switch down to display the setup menu.

- 2 Display User >Camera Config >User Menu with Lock in the setup menu.

[Notes]

- When you press and hold the MENU knob and press the MENU ON/OFF switch down, Camera Config >User Menu Only changes to User Menu with Lock.
- If you press the MENU ON/OFF switch down without pressing the MENU knob or you press the MENU button to display the menu, Camera Config >User Menu with Lock is not displayed.

- 3 Select "Off," then press the MENU knob.

The viewfinder screen display switches to the passcode number input screen.

- 4 Enter the passcode number used to lock the menu.

The valid input range is 0000 to 9999.

Enter a number and press the MENU knob to move the cursor to the next digit.

When all digits have been entered, move the cursor to [Set].

- 5 With [Set] selected, press the MENU knob.

The entry is applied.

If the entered passcode number matches the passcode number used to lock the menu, a confirmation message appears and the display of all menus is enabled.

[Notes]

- If the entered passcode number does not match the passcode number used to lock the menu, the menu is not unlocked.

- It is recommended that you leave a record of the passcode nearby, just in case it is forgotten. If you do forget the passcode number, contact your Sony service representative.

Editing the User Menu

You can edit the User menu, such as adding items, deleting items, and rearranging items, to make the User menu more useful using Edit User Menu.

You can select items in the Operation menu, Paint menu, Maintenance menu, and some items in the File menu, and add them to the User menu.

Up to 20 items can be registered in the User menu.


There are six items registered in the User menu by factory default, one of which must always be present, allowing you to add up to 19 new items.

[Note]
Editing is unavailable when the menu is locked.


Displaying the Edit User Menu Screen

You edit the User menu on the Edit User Menu screen.

- 1 Turn the MENU knob to select User >Edit User Menu, then press the knob.




The Edit User Menu screen appears.



Adding Items and Sub-Items

- 1 Turn the MENU knob to select Edit User Menu >Add Item, then press the knob.
The items that can be added are displayed.

- 2 Turn the MENU knob to select an item, then press the knob.
A screen for selecting sub-items to add appears.



- 3 Turn the MENU knob to select a sub-item, then press the knob.
Place a check mark in the All checkbox to add all sub-items.
Place a check mark in the individual checkboxes to specify which sub-items to add.

- 4 Turn the MENU knob to select [OK], then press the knob.
The item/sub-item(s) are added.

[Note]
The same item or sub-item cannot be registered twice. Also, the name of the item or sub-item cannot be changed.


Editing Sub-Items

You can specify the sub-items to display.


- 1 Display the Edit User Menu screen.

- 2 Turn the MENU knob to select an item to edit, then press the knob.
The edit function list appears.

- 3 Turn the MENU knob to select Edit Sub item in the edit function list, then press the knob.



The Edit Sub item screen appears.



All sub-items are checked when the screen is first opened (function to display all sub-items). Remove the check marks for the sub-items you do not want to display in the User menu.


- 4 Turn the MENU knob to select [OK], then press the knob.
Editing is completed.

Deleting Items

- 1 Display the Edit User Menu screen.

- 2 Turn the MENU knob to select an item to edit, then press the knob.
The edit function list appears.

- 3 Turn the MENU knob to select Delete in the edit function list, then press the knob.




The item is deleted.


Moving Items

- 1 Display the Edit User Menu screen.
- 2 Turn the MENU knob to select an item to move, then press the knob.
The edit function list appears.

- 3 Turn the MENU knob to select Move in the edit function list, then press the knob.




The item to move is highlighted, and a triangle mark and line indicate the destination position.



Triangle mark and line indicating move destination

- 4 Turn the MENU knob to move the triangle and line to the desired destination, then press the knob.
The item is moved.



Restoring the User Menu to Factory Default State

- 1 Turn the MENU knob to select Edit User Menu
>Customize Reset, then press the knob.
The Customize Reset screen appears.
- 2 Turn the MENU knob to select [Reset], then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.
The User menu is restored to the factory default state.

Operation >Format Media		
Formats the media.		
Item	Setting	Description
Media (A)	Execute/Cancel	Initializes the SxS memory card in slot A (execute by selecting Execute).
Media (B)	Execute/Cancel	Initializes the SxS memory card in slot B (execute by selecting Execute).
SD Card(Utility)	Execute/Cancel	Initializes the SD card in the UTILITY SD card slot (execute by selecting Execute).
SD Card(Proxy)	Execute/Cancel	Initializes the SD card in the PROXY SD card slot (execute by selecting Execute).
Operation >Input/Output		
Sets input/output signals.		
Item	Setting	Description
Output Format	Settings vary according to the system frequency setting.	Selects the output format (execute by selecting Execute). Settings vary according to the recording format setting (page 35).
Source Select	Camera/External	Selects the camera picture (Camera) or SDI IN connector input signal for the video input source.
SDI Out1 Output	On/Off	Turns the output signal from the SDI OUT1 connector on/off.
SDI Out2 Output	On/Off	Turns the output signal from the SDI OUT2 connector on/off.
HDMI Output	On/Off	Turns the output signal from the HDMI connector on/off.
SDI Out2/HDMI Super	Off/On	Turns character information (superimposed) from the SDI OUT2 and HDMI connectors on/off.
Video Out Super	Off/On	Turns character information (superimposed) from the VIDEO OUT connector on/off.
Down Converter	Edge Crop/Letter Box/Squeeze	Selects the signal conversion mode for output of SD signals. Edge Crop: Crops the edges of the 16:9 picture for output as a 4:3 picture. Letter Box: Masks the top and bottom of the 4:3 picture and displays a 16:9 picture in the center of the screen. Squeeze: Squeezes the 16:9 picture horizontally for output as a 4:3 picture.

Operation >Input/Output		
Sets input/output signals.		
Item	Setting	Description
Wide ID	Through/Auto	Selects whether to add a wide ID signal to the SD output signal. Through: Outputs without adding a wide ID signal. Auto: Adds and outputs a wide ID signal to the video signal when the wide ID signal is set to Squeeze.
Wide Mode(Ext)	Auto/16:9	When the input signal is SD, sets the method that determines wide screen information. Auto: Records with 16:9 aspect ratio when the wide screen information of the input signal is Squeeze. Otherwise, records with 4:3 aspect ratio. 16:9: Records with 16:9 aspect ratio.
Operation >Super Impose		
Sets character information/markers to be superimposed.		
Item	Setting	Description
Super(VF Display)	On/Off	When Input/Output >SDI Out2/HDMI Super or Input/Output >Video Out Super is set to On, this turns superimposition of character information on the output from the SDI OUT connector or VIDEO OUT connector, respectively.
Super(Menu)	On/Off	
Super(Marker)	On/Off	When Input/Output >SDI Out2/HDMI Super or Input/Output >Video Out Super is set to On, this turns superimposition of markers on the output from the SDI OUT connector or VIDEO OUT connector on/off, respectively.
Operation >LCD		
Sets the LCD monitor.		
Item	Setting	Description
LCD Color	-99 to ±0 to +99	Adjusts the color depth of the LCD monitor.
LCD Marker&Zebra	On/Off	Turns the marker and zebra pattern display on the LCD monitor on/off.

Operation >Rec Function		
Sets the special recording mode.		
Item	Setting	Description
Slow & Quick Motion	On/Off	Turns Slow & Quick Motion on/off. (When set to On, the settings for other special recording modes are set to Off.)
Frame Rate	Settings vary according to the recording format setting.	
	1 to 60	When the recording mode is exFAT, and the recording format is XAVC Intra or XAVC Long.
	1 to 50	When the recording mode is UDF, and the recording format is MPEG2 HD 422 50M (1280×720), 50P/25P.
	1 to 30	When the recording mode is exFAT or UDF, and the recording format is MPEG2 HD 422 50M (1920×1080), 29.97P/23.98P.
	1 to 25	When the recording mode is exFAT or UDF, and the recording format is MPEG2 HD 422 50M (1920×1080), 25P.
	On/Off	Turns Clip Continuous Rec mode on/off. (When set to On, the settings for other special recording modes are set to Off.)
Picture Cache Rec	On/Off	Turns picture cache recording mode on/off. (When set to On, the settings for other special recording modes are set to Off.)
Cache Rec Time	Settings vary according to the recording format setting.	
	0 to 2/2 to 4sec	When the recording format is XAVC-I 1920×1080P (system frequency is 59.94/50)
	0 to 2/2 to 4/4 to 6/6 to 8sec	When the recording format is XAVC-I 1920×1080P (system frequency is 29.97/25/23.98), XAVC-I 1920×1080i, or XAVC-I 1280×720P
	0 to 2/2 to 4/4 to 6/6 to 8/8 to 10/10 to 12/12 to 14/13 to 15sec	When the recording format is XAVC-L, MPEG2 HD 422, MPEG2 HD 420, or MPEG IMX 50.
Interval Rec	On/Off	Turns Interval Rec mode on/off. (When set to On, the settings for other special recording modes are set to Off.)

Operation >Rec Function		
Sets the special recording mode.		
Item	Setting	Description
Number of Frames	The available settings vary depending on the Format >Frequency setting.	When Interval Rec is set to On, this sets the number of frames to shoot in one Interval Rec take.
	2frames/6frames/12frames	When the recording format frame rate is 50P or 59.94P.
	1frame/3frames/6frames/9frames	When the recording format frame rate is 23.98P, 25P, 29.97P, 50i, or 59.94i.
Interval Time	1/2/3/4/5/6/7/8/9/10/15/20/30/40/50 (sec) 1/2/3/4/5/6/7/8/9/10/15/20/30/40/50 (min) 1/2/3/4/6/12/24 (hour)	When Interval Rec is set to On, this sets the interval for Interval Rec shooting.
Pre-Lighting	Off/2sec/5sec/10sec	Sets the number of seconds that the video light is turned on prior to the start of Interval Rec shooting. To not turn the video light on, select Off.
Simul Rec	On/Off	Turns simultaneous recording to slots A and B on/off.
Operation >Proxy Recording Mode		
Item	Setting	Description
Setting	On/Off	Turns proxy recording on/off.
Size	HD Auto(9Mbps)/	Selects the size of the proxy recording format.
	HD Auto(6Mbps)/	
	1280×720(9Mbps)/	
	1280×720(6Mbps)/	
	640×360(3Mbps)/	
	480×270(1Mbps)/	
	480×270(0.5Mbps)	
Frame Rate	23.98fps/25fps/29.97fps/50fps/59.94fps	Selects the frame rate of the proxy recording format.
Bit Rate	9Mbps/6Mbps/3Mbps/1Mbps/0.5Mbps	Selects the bit rate of the proxy recording format.
Audio Channel	CH1/CH2/CH3/CH4	Selects the audio channel to record to proxy data.

Operation >Assignable Switch

Assigns functions to assignable switches.

For details about assigning functions, see “Assigning Functions to Assignable Switches” (page 114).

Item	Setting	Description
<0>	114	Assigns a function to the ASSIGN. 0 switch.
<1>	115	Assigns a function to the ASSIGN. 1 switch.
<2>	114	Assigns a function to the ASSIGN. 2 switch.
<3>	115	Assigns a function to the ASSIGN. 3 switch.
<4>	115	Assigns a function to the ASSIGNABLE 4 switch.
<5>	115	Assigns a function to the ASSIGNABLE 5 switch.
Lens RET	116	Assigns a function to RET button on the lens.
Online	115	Assigns a function to the ONLINE button.
Zoom Speed	0 to 20 to 99	When Zoom has been assigned to the ASSIGNABLE 4 or 5 switch, this sets the zoom speed.

Operation >VF Setting

Sets the viewfinder screen.

Item	Setting	Description
Color	–99 to ±0 to +99	Adjusts the color depth of the viewfinder image.
Color Mode	Color/B&W	Selects the viewfinder display mode (when using CBK-VF02). Color: Color B&W: Black & white
Peaking Type	Normal/Color	Selects the type of peaking (when using CBK-VF02). Normal: Normal peaking Color: Color peaking
Peaking Frequency	Normal/High	When Peaking Type is set to Normal, this selects Normal or High peaking frequency (when using CBK-VF02).
Peaking Color	B&W/Red/Yellow/Blue	Selects the peaking color when Peaking Type is set to Color (when using CBK-VF02). B&W: Black & white Red: Red Yellow: Yellow Blue: Blue
VF Detail Level	–99 to ±0 to +99	Sets the detail level (set on the camcorder) of the viewfinder (when using HDV-F-20A).

Operation >Marker

Sets the marker display in the viewfinder.

Item	Setting	Description
Setting	On/Off	Turns the display of all markers on/off. [Note] When Marker is assigned to the ASSIGN. 2 switch, this setting is disabled.
Color	White/Yellow/Cyan/Green/Magenta/Red/Blue	Selects the marker display color.
Center Marker	1/2/3/4/Off	When the center marker is displayed, selects the type. Select Off if you do not want to display the marker.
Safety Zone	On/Off	Turns the safety zone indicator on/off.
Safety Area	80%/90%/92.5%/95%	Selects the safety zone range.
Aspect Marker	Line/Mask/Off	When an aspect marker is to be displayed, selects the display method. Select Off if you do not want to display the marker. Line: Show as white lines. Mask: Displays a lower video signal level for areas outside the marker area.
Aspect Select	15.9/14.9/13.9/4.3/1.66:1/1.85:1/2.35:1/2.4:1	Selects the aspect ratio of the marker.
Aspect Mask	0% to 12% to 15%	When the Aspect Marker setting is Mask, this sets the video signal level of areas outside the marker area as a percentage value relative to the video signal level of areas inside the marker area.
Aspect Safety Zone	On/Off	Turns the aspect safety zone marker on/off.
Aspect Safety Area	80%/90%/92.5%/95%	Selects the size of the aspect safety zone marker (as a percentage of total screen size).
100% Marker	On/Off	Turns the 100% safety zone marker indicator on/off.
User Box	On/Off	Turns the box cursor display on/off.
User Box Width	40 to 500 to 999	Sets the box cursor width (distance from the center to the left and right edges).
User Box Height	70 to 500 to 999	Sets the box cursor height (distance from the center to the top and bottom edges).
User Box H Position	–479 to 0 to 479	Sets the horizontal position of the box cursor center.
User Box V Position	–464 to 0 to 464	Sets the vertical position of the box cursor center.

Operation >Gain Switch		
Sets the gain value switch settings.		
Item	Setting	Description
Gain <L>	–3dB/0dB/3dB/6dB/9dB/1 2dB/1 8dB/24dB/30dB/36dB/42dB	Selects the gain value for the L position of the GAIN switch.
Gain <M>	–3dB/0dB/3dB/6dB/9dB/1 2dB/1 8dB/24dB/30dB/36dB/42dB	Selects the gain value for the M position of the GAIN switch.
Gain <H>	–3dB/0dB/3dB/6dB/ 9dB/1 2dB/1 8dB/24dB/30dB/ 36dB/42dB	Selects the gain value for the H position of the GAIN switch.
Gain <Turbo>	–3dB/0dB/3dB/6dB/ 9dB/1 2dB/8dB/24dB/30dB/36dB/ 42dB	Selects the gain value when the Turbo Gain function is assigned to an assignable switch.
Shockless Gain	On/Off	Turns shockless gain (function that switches the gain smoothly when the gain is switched) on/off.
Operation >Auto Iris		
Sets the auto iris.		
Item	Setting	Description
Iris Override	On/Off	Turns iris override (setting opens or closes the iris more than normal) on/off.
Mode	Backlight/Standard/Spotlight	Selects the control mode of the auto iris. Backlight: Backlight mode (mode for reduced darkening of a subject when the subject is backlit) Standard: Standard mode (cannot be selected when using optional remote control connection) Spotlight: Spotlight mode (mode for reduced blown out highlights when subject is lit by spotlighting)
Level	–99 to ±0 to +99	Sets the convergence target level (larger values increase brightness.)
Speed	–99 to ±0 to +99	Sets the control speed (speed of response to changes in the video). (Larger values specify quicker reaction times.)
Clip High light	On/Off	Turns the function that ignores brightest areas to provide a flatter reaction to high luminance on/off.
Detect Window	1/2/3/4/5/6/Var	Selects the type of auto iris detection window. Var: Variable
Detect Window Indication	On/Off	Turns the function that displays the auto iris detection window frame using a marker on/off.

Operation >Auto Iris		
Sets the auto iris.		
Item	Setting	Description
Iris APL Ratio	–99 to ±0 to +99	If the Mode setting for Auto Iris is set to Standard, sets the mix ratio of peak to mean auto iris detection value.
Iris Var Width	40 to 500 to 999	Sets the width of the window when Iris Window is set to Var.
Iris Var Height	70 to 500 to 999	Sets the height of the window when Iris Window is set to Var.
Iris Var H Position	–479 to 0 to 479	Sets the horizontal position of the window when Iris Window is set to Var.
Iris Var V Position	–464 to 0 to 464	Sets the vertical position of the window when Iris Window is set to Var.

Operation >Zebra		
Sets the display of zebra patterns.		
Item	Setting	Description
Zebra Select	1/2/Both	Selects the zebra pattern type (Zebra 1, Zebra 2, Both).
Zebra1 Level	50% to 70% to 107%	Sets the Zebra 1 display level.
Zebra1 Aperture Level	1 to 10% to 20%	Sets the Zebra 1 aperture level.
Zebra2 Level	52% to 100% to 109%	Sets the Zebra 2 display level.
Operation >Display On/Off		
Selects the items to display in the viewfinder.		
Item	Setting	Description
Video Level Warning	On/Off	Turns the warnings that appear when the video level is too bright or too dark on/off.
Shutter Setting	On/Off	Turns the shutter mode and shutter speed indicators on/off.
ND Filter Position	On/Off	Turns the ND filter setting indicator on/off.
Gain Setting	On/Off	Turns the gain setting indicator on/off.
Rec/Play Status	On/Off	Turns the recording and playback indicators on/off.
Color Temp.	On/Off	Turns the color temperature indicator on/off.
Frame Rate/Interval	On/Off	Turns the special recording mode indicator on/off.

Operation > Display On/Off		
Selects the items to display in the viewfinder.		
Item	Setting	Description
Battery Remain	Auto/Voltage/Off	Sets the mode of the remaining battery capacity and input voltage indicators. Auto: Displays the remaining capacity, according to the battery type. Voltage: Displays the input voltage, regardless of the battery type. Off: No display.
Timecode	On/Off	Turns the display of time data (timecode, user bits, counter, duration) on/off.
Audio Level Meter	On/Off	Turns the display of the audio level meter on/off.
Media Status	On/Off	Turns the media status indicator on/off.
SD Card(Utility)	On/Off	Turns the SD card (Utility) indicator on/off.
Focus Position	Meter/Feet/Off	Turns the lens focus position indicator on/off and selects the display units.
Iris Position	On/Off	Turns the lens iris position indicator on/off.
Zoom Position	On/Off	Turns the lens zoom position indicator on/off.
Extender	On/Off	Turns the lens and digital extender indicator on/off.
ALAC	On/Off	Turns the lens aberration correction indicator on/off.
AE Mode	On/Off	Turns AE mode and the AE level setting indicator on/off.
Focus Mode	On/Off	Turns the focus mode indicator on/off.
White Balance Mode	On/Off	Turns the white balance mode indicator on/off.
CC5600K	On/Off	Turns the CC5600K indicator on/off.
Rec Format	On/Off	Turns the recording format indicator on/off.
Gamma	On/Off	Turns the selected gamma type indicator on/off.
Timecode Lock	On/Off	Turns the timecode indicator on/off.
Network Condition	On/Off	Turns the network connection status indicator on/off.
Proxy Status	On/Off	Turns the proxy status indicator on/off.
NW Client Mode Status	On/Off	Turns the network client mode indicator on/off.
Streaming Status	On/Off	Turns streaming transmission on/off.
GPS	On/Off	Turns the GPS reception status indicator on/off.

Operation > Display On/Off		
Selects the items to display in the viewfinder.		
Item	Setting	Description
Video Signal Monitor	Off/Waveform/Vector/Histogram	Selects whether to display the video signal, and the type of video signal to display. [Note] Not displayed in the following circumstances. When Operation > Input/Output > SDI Out1 Select and SDI Out2 Select in the setup menu are both set to Off. When Operation > Input/Output > Output Format in the setup menu is set to 720x480P or 720x576P.
Clip Name	On/Off	Turns the clip name display on/off.
Focus Assist Indicator	On/Off	Turns the focus assist indicator on/off.
Focus Area Marker	On/Off	Turns the focus area marker indicator on/off.
Lens Info	Meter/Feet/Off	Selects whether to display depth of field and the units to display.
WRR RF Level	On/Off	Turns the wireless tuner reception status indicator on/off.
Clip Number	On/Off	Turns the clip information display on/off.

Operation > I/LED		
Sets the "I" indicator in the viewfinder. (Enabled when using HDV-F-20A).		
Item	Setting	Description
Gain <I>	On/Off	Turns the function to light the I indicator on/off when the gain is set to other than 0 dB.
Shutter <I>	On/Off	Turns the function to light the I indicator on/off when the SHUTTER switch is set to ON.
White Preset <I>	On/Off	Turns the function to light the I indicator on/off when the WHITE BAL switch is set to PRST.
ATW Run <I>	On/Off	Turns the function to light the I indicator on/off when ATW is used.
Extender <I>	On/Off	Turns the function to light the I indicator on/off when the digital extender function or lens extender is used.
Filter <I>	On/Off	Turns the function to light the I indicator on/off when the ND filter is set to other than 1.
Iris Override <I>	On/Off	Turns the function to light the I indicator on/off when the auto iris override is not set to Standard.

Operation >White Setting		
Makes settings related to white balance adjustment.		
Item	Setting	Description
White Switch	Memory/ATW	Sets the operating mode selected by the B position of the WHITE BAL switch. Memory: Auto white balance ATW: Auto tracing white balance
Shockless White	Off/1/2/3	Selects the transition time when the WHITE BAL switch setting is changed (1 is fastest).
ATW Speed	1/2/3/4/5	Selects the ATW (auto tracing white) transition speed (1 is fastest).
AWB Fixed Area	On/Off	Runs AWB (auto white balance) for the center of the screen.
Filter White Memory	On/Off	Sets the white balance memory area for each FILTER knob position number when White Balance is set to Preset or ATW. - When Electrical CC is assigned to an assignable switch, this sets independent white balance memory areas for Electrical CC A, B, C, and D settings. - When Electrical CC is not assigned to an assignable switch, this sets white balance memory areas for each FILTER knob position number.
Operation >Offset White		
Makes settings related to white balance offset values.		
Item	Setting	Description
Offset White<A>	On/Off	Selects whether to add (On) or not to add (Off) an offset value to the white balance in memory A.
Warm Cool <A>	Approximate color temperature display (Approx. 1600K to 3200K to 16000K)	When Offset White<A> is set to On, this specifies the offset (as a color temperature) to add to the white balance in memory A. (Note that the error increases for higher offset color temperatures. Adjust while viewing the actual image.)
Warm Cool Balance<A>	−99 to ±0 to +99	Specifies a more precise color temperature, for use when a satisfactory image cannot be obtained with the Warm Cool <A> setting.
Offset White 	On/Off	When this is set to On, the offset adjusted here is added to the white balance of channel B.

Operation >Offset White		
Makes settings related to white balance offset values.		
Item	Setting	Description
Warm Cool 	Approximate color temperature display (Approx. 1600K to 3200K to 16000K)	When Offset White is set to On, this specifies the offset (as a color temperature) to add to the white balance in memory A. (Note that the error increases for higher offset color temperatures. Adjust while viewing the actual image.)
Warm Cool Balance	−99 to ±0 to +99	Specifies a more precise color temperature, for use when a satisfactory image cannot be obtained with the Warm Cool setting.
Operation >Shutter		
Sets the shutter operating mode.		
Item	Setting	Description
Mode	Speed/Angle	Selects the operating mode of the electronic shutter. Speed: Sets the shutter speed as a time (units: seconds). Angle: Sets the shutter speed as an angle (units: degrees).
Operation >Slow Shutter		
Sets the slow shutter.		
Item	Setting	Description
Setting	On/Off	Turns the slow shutter function on/off.
Number of Frames	2/3/4/5/6/7/8/16	Sets the number of accumulated frames for the slow shutter function.
Operation >Time Zone		
Sets the time zone.		
Item	Setting	Description
Time Zone	UTC +1 4:00 to UTC Greenwich to UTC −1 2:00 Kwajalein	Selects the difference in time from UTC (Greenwich Mean Time) in units of 30 minutes.

Operation >Clip Makes settings relating to clip names and management. [Note] Do not assign clip names that begin with the "." (period) symbol. Clips with names in which the first character is "." cannot be viewed in the application software on a computer.		
Item	Setting	Description
Clip Naming	Title/Plan	Selects the clip naming format. Title: Name specified by Title Prefix. Plan: Name specified in planning metadata (if no name is specified in planning metadata, the name specified by Title Prefix is used).
Title Prefix	Text Input	Sets the title part (4 to 46 alphanumeric characters) of clip titles using a character string entry screen (page 86).
Number Set	Settings vary according to the Clip Naming setting.	Sets the numeric portion of the clip name. When Clip Naming is set to Title: 0001 to 9999 When Clip Naming is set to Plan and a planning metadata file is loaded: 00001 to 99999
Operation >Update Media Updates the media's management file.		
Item	Setting	Description
Media (A)	Execute/Cancel	Updates the management information of the SxS memory card in slot A (execute by selecting Execute).
Media (B)	Execute/Cancel	Updates the management information of the SxS memory card in slot B (execute by selecting Execute).
Operation >GPS Turns location information (GPS) on/off.		
Item	Setting	Description
GPS	On/Off	Turns the GPS function on/off.
Operation >Planning Metadata Makes settings relating to planning metadata operations.		
Item	Setting	Description
Load Media (A)	Execute/Cancel	Loads planning metadata from the SxS memory card in slot A. Execute to display a list of planning metadata files stored on the SxS memory card in slot A. Select a file to display the properties screen.

Operation >Planning Metadata Makes settings relating to planning metadata operations.		
Item	Setting	Description
Load Media (B)	Execute/Cancel	Loads planning metadata from the SxS memory card in slot B. Execute to display a list of planning metadata files stored on the SxS memory card in slot B. Select a file to display the properties screen.
Properties	Execute/Cancel	Displays the planning metadata content loaded in the camcorder (execute by selecting Execute).
Clear Memory	Execute/Cancel	Clears the planning metadata loaded in the camcorder (execute by selecting Execute).
Clip Name Disp	Title1(ASCII)/Title2(UTF-8)	Selects the display format if the clip name is specified in planning metadata (page 55).
Operation >USB Makes settings related to copying clips from the recording media inserted in an SxS card slot of the camcorder to USB media.		
Item	Setting	Description
Select Folder		Selects a folder on the USB media. Creates a new folder on the USB media.
View Clip List		Displays a list of clips on the USB media.
Rename Folder	On/Off	Renames a folder on the USB media.
Error Check	On/Off	Selects whether to perform error checking when copying clips from the recording media inserted in an SxS card slot of the camcorder to USB media.
Format USB	Execute/Cancel	Formats the USB media (execute by selecting Execute).
Copy to USB	Media(A) to USB/ Media(B) to USB/ Media(A)(B) to USB	Selects the target slot when copying all clips from an SxS card slot. Media(A) to USB: Copies all clips from the recording media inserted in slot A. Media(B) to USB: Copies all clips from the recording media inserted in slot B. Media(A)(B) to USB: Copies all clips from the recording media inserted in slot A and slot B.
Media Remain	(Free space: numeric display and bar display)	Displays the remaining free space on the USB media.

Operation >Flash Band Reduce Corrects the flashband phenomena. [Note] This item is disabled (grayed out) during recording and when Slow&Quick is set to On.		
Item	Setting	Description
Setting	On/Off	Turns the flashband reduction function on/off. [Notes] • Momentary noise may occur due to discontinuous video and audio when switching Flash Band Reduce on/off. • The setting returns to the default value when power is switched off.

Paint Menu

Default values are shown in **bold**.

Paint >Switch Status Turns various correction functions and the test signal on/off.		
Item	Setting	Description
Gamma	On/Off	Turns the gamma function on/off.
Black Gamma	On/Off	Turns the black gamma function on/off.
Matix	On/Off	Turns the matrix function on/off.
Knee	On/Off	Turns the knee function on/off.
White Clip	On/Off	Turns the white clip function on/off. [Note] If set to Off, it is reset to On when power is next turned on.
Detail	On/Off	Turns the detail function on/off.
Aperture	On/Off	Turns the aperture function on/off.
Flare	On/Off	Turns the flare correction function on/off.
Test Saw	On/Off	Turns the test signal on/off.
Paint >White Sets the color temperature, and adjusts white balance manually.		
Item	Setting	Description
Color Temp <A>	1500K to 3200K to 50000K	Displays the white balance color temperature saved in memory A.
Color Temp Balance <A>	-99 to ±0 to +99	Sets the white balance gain value saved in memory A (linked to R gain and B gain).
R Gain<A>	-99 to ±0 to +99	Sets the white balance R gain value saved in memory A.
B Gain<A>	-99 to ±0 to +99	Sets the white balance B gain value saved in memory A.
Color Temp 	1500K to 3200K to 50000K	Displays the white balance color temperature saved in memory B.
Color Temp Balance 	-99 to ±0 to +99	Sets the white balance gain values saved in memory B (linked R gain and B gain).
R Gain 	-99 to ±0 to +99	Sets the white balance R gain value saved in memory B.
B Gain 	-99 to ±0 to +99	Sets the white balance B gain value saved in memory B.

Paint >Black Sets the black level (image level without lighting). You can achieve a desired look by adjusting the black level for deeper or shallower blacks.		
Item	Setting	Description
Master Black	-99 to ±0 to +99	Sets the master black level.
R Black	-99 to ±0 to +99	Sets the R black level.
B Black	-99 to ±0 to +99	Sets the B black level.
Paint >Flare Makes settings related to flare correction. Flare is a phenomenon where the video level increases across the entire image due to the effects of bright regions in the image, increasing the brightness of darker regions and reducing contrast. It is caused by reflected light inside the lens.		
Item	Setting	Description
Setting	On/Off	Turns the flare correction function on/off.
Master Flare	-99 to ±0 to +99	Sets the master flare correction level.
R Flare	-99 to ±0 to +99	Sets the R flare correction level.
G Flare	-99 to ±0 to +99	Sets the G flare correction level.
B Flare	-99 to ±0 to +99	Sets the B flare correction level.
Paint >Gamma Makes settings related to gamma correction. Gamma correction allows you to adjust the contrast of the image to significantly alter the impression of an image.		
Item	Setting	Description
Setting	On/Off	Turns the gamma correction function on/off.
Step Gamma	0.35 to 0.45 to 0.90 (0.05 steps)	Sets a gamma correction value in 0.05 steps.
Master Gamma	-99 to ±0 to +99	Sets the master gamma level.
R Gamma	-99 to ±0 to +99	Sets the R gamma level.
G Gamma	-99 to ±0 to +99	Sets the G gamma level.
B Gamma	-99 to ±0 to +99	Sets the B gamma level.
Gamma Category	STD/HG/User	Selects the gamma category. STD: Standard gamma curve for video signals HG: Gamma curve that imitates gradation and color reproduction of shooting with film User: User-defined gamma curve created using CyFileEditorTM V4.2

Paint >Gamma Makes settings related to gamma correction. Gamma correction allows you to adjust the contrast of the image to significantly alter the impression of an image.		
Item	Setting	Description
Gamma Select	Settings vary according to the Gamma Category setting.	Selects the gamma table used for gamma correction. When Gamma Category is STD STD1 DWV: DWV camcorder equivalent STD2 x4.5: x4.5 gain STD3 x3.5: x3.5 gain STD4 240M: SMPTE-240M equivalent STD5 R709: ITU-R709 equivalent (default setting) STD6 x5.0: x5.0 gain When Gamma Category is HG HG1 3250G36: Compresses 325% video input to 100% video output. HG2 4600G30: Compresses 460% video input to 100% video output. HG3 3259G40: Compresses 325% video input to 109% video output. HG4 4609G33: Compresses 460% video input to 109% video output (default setting).
When Gamma Category is User User 1: Gamma table registered in User1 (default setting) User 2: Gamma table registered in User2 User 3: Gamma table registered in User3 User 4: Gamma table registered in User4 User 5: Gamma table registered in User5		
Paint >Black Gamma Makes settings related to black gamma correction. Black gamma correction allows you to reproduce gradations and colors in black or near-black (dark) parts of the picture.		
Item	Setting	Description
Setting	On/Off	Turns the black gamma correction function on/off. [Note] To enable the black gamma function, set Saturation Mode to Low Key.

Paint >Black Gamma Makes settings related to black gamma correction. Black gamma correction allows you to reproduce gradations and colors in black or near-black (dark) parts of the picture.		
Item	Setting	Description
Range	Low/L.Mid/H.Mid	Selects the effective range of the black gamma correction. Low: 0 to 3.6% L.Mid: 0 to 7.2% H.Mid: 0 to 14.4%
Master Black Gamma	-99 to ±0 to +99	Sets the master black gamma level.
Paint >Knee Makes settings related to knee correction. Knee correction is processing that prevents blown out highlights by compressing the bright parts of the image in response to the upper limit for the dynamic range of the recorded/output image. The signal level where knee processing begins is called the "knee point," and the slope of knee compression is called the "knee slope."		
Item	Setting	Description
Setting	On/Off	Turns the knee correction function on/off.
Point	75% to 95% to 109%	Sets the knee point when the DCC function is off.
Slope	-99 to ±0 to +99	Sets the knee slope when the DCC function is off.
Knee Saturation	On/Off	Turns the knee saturation function on/off. [Note] To enable the knee saturation function, set Saturation Mode to Knee.
Knee Saturation Level	-99 to ±0 to +99	Sets the knee saturation level.
Paint >White Clip Makes settings related to white clip adjustment. White clip processing limits the maximum level of video output signals. The maximum video output signal value is called the "white clip level."		
Item	Setting	Description
Setting	On/Off	Turns the white clip adjustment function on/off.
Level	90.0% to 109.0% The default setting varies according to the system frequency setting.	Sets the white clip level. The default setting is 108.0% when the system frequency is 59.94, 29.97, 24, or 23.98. The setting is 105.0% when the system frequency is 50.25.

Paint >Detail(HD)/Detail(SD) Makes settings related to detail adjustments in HD mode and SD mode. Detail adjustment processing improves the clarity of images by adding a detail signal to the outline of the subject.		
Item	Setting	Description
Setting	On/Off	Turns the detail adjustment function on/off.
Level	-99 to ±0 to +99	Sets the detail level.
H/V Ratio	-99 to ±0 to +99	Sets the mix ratio between the H detail level and the V detail level.
Crispining	-99 to ±0 to +99	Sets the crispining level.
Level Depend	On/Off	Turns the level dependence adjustment function on/off.
Level Depend Level	-99 to ±0 to +99	Sets the level dependence level.
Frequency	-99 to ±0 to +99	Sets the center frequency of the H detail signal (larger values give finer detail).
Knee Aperture	On/Off	Turns the knee aperture correction function on/off.
Knee Aperture Level	-99 to ±0 to +99	Sets the knee aperture level.
Limit	-99 to ±0 to +99	Sets the detail limiter for both the white-side and black-side directions.
White Limit	-99 to ±0 to +99	Sets the white-side detail limiter.
Black Limit	-99 to ±0 to +99	Sets the black-side detail limiter.
V Black Limit	-99 to ±0 to +99	Sets the black-side V detail limiter.
V Detail Creation	NAM/ V /G/G+R	Selects the source signal used to generate the V detail signal. NAM: V detail signal created from the R signal, V detail signal created from the G signal, or V detail signal created from the B signal, whichever signal has the highest level V: V signal G: G signal G+R: Mixed signal comprising the G signal and R signal in a 1:1 ratio
Cross Color Suppress (SD mode)	-99 to ±0 to +99	Sets the cross color suppression level of the detail. [Note] This setting is disabled if the detail adjustment function is Off, and when Operation Format Frequency in the setup menu is set to 50 or 25.

Paint >Aperture Makes settings related to aperture correction. Aperture correction processing improves resolution by adding high-frequency aperture signals to the video signal, which corrects deterioration due to high-frequency characteristics.		
Item	Setting	Description
Setting	On/Off	Turns the aperture correction function on/off.
Level	–99 to ±0 to +99	Sets the aperture level.
Paint >Skin Detail Makes settings related to skin detail correction. Skin detail correction processing increases or decreases the detail level of a specified color range, for the purpose of obtaining attractive reproduction of skin tones.		
Item	Setting	Description
Setting	On/Off	Turns the skin detail correction function on/off.
Area Detection	Execute/Cancel	Displays a color detection screen for detecting colors for skin detail correction (execute by selecting Execute).
Area Indication	On/Off	Turns the display of a zebra pattern in areas targeted for skin detail correction on/off.
Level	–99 to ±0 to +99	Sets the skin detail level.
Saturation	–99 to ±0 to +99	Sets the saturation of the color targeted for skin detail correction.
Hue	0 to 359	Sets the hue of the color targeted for skin detail correction.
Width	0 to 40 to 90	Sets the range for the hue of the color targeted for skin detail correction.
Paint >Matrix Makes settings related to matrix correction. Adjusts the hue and vividness of the image using matrix correction. You can select a matrix to achieve a specific purpose using "Adaptive Matrix" to control the effect of a linear matrix or "Preset Matrix" for a predefined parameter set. You can also set user-defined parameters as a "User Matrix."		
Item	Setting	Description
Setting	On/Off	Turns the matrix correction function on/off.
Adaptive Matrix	On/Off	Turns the adaptive matrix function on/off.
Preset Matrix	On/Off	Turns the preset matrix function on/off.

Paint >Matrix Makes settings related to matrix correction. Adjusts the hue and vividness of the image using matrix correction. You can select a matrix to achieve a specific purpose using “Adaptive Matrix” to control the effect of a linear matrix or “Preset Matrix” for a predefined parameter set. You can also set user-defined parameters as a “User Matrix.”		
Item	Setting	Description
Preset Select	1: SMPTE240M 2: ITU-709 3: SMPTE Wide 4: NTSC 5: EBU 6: PAL	Selects a preset matrix. 1: SMPTE240M: SMPTE-240M equivalent 2: ITU-709: ITU-709 equivalent 3: SMPTE Wide: SMPTE WIDE equivalent 4: NTSC: NTSC equivalent 5: EBU: EBU equivalent 6: PAL: PAL equivalent
User Matrix	On/Off	Turns the user matrix correction function on/off.
Level	–99 to ±0 to +99	Sets the saturation of the color of the entire image.
Phase	–99 to ±0 to +99	Sets the color tone (phase) of the entire image.
User Matrix R-G	–99 to ±0 to +99	Sets a user-defined R-G user matrix.
User Matrix R-B	–99 to ±0 to +99	Sets a user-defined R-B user matrix.
User Matrix G-R	–99 to ±0 to +99	Sets a user-defined G-R user matrix.
User Matrix G-B	–99 to ±0 to +99	Sets a user-defined G-B user matrix.
User Matrix B-R	–99 to ±0 to +99	Sets a user-defined B-R user matrix.
User Matrix B-G	–99 to ±0 to +99	Sets a user-defined B-G user matrix.
Paint >Multi Matrix Makes settings related to multi matrix correction. Multi-matrix correction sets the saturation using a 16-axis hue space.		
Item	Setting	Description
Setting	On/Off	Turns the multi matrix correction function on/off.
Area Indication	On/Off	Turns the display of a zebra pattern in the color area targeted for multi matrix correction on/off.
Color Detection	Execute/Cancel	Displays a color detection screen for detecting colors for multi matrix correction (execute by selecting Execute).
Reset	Execute/Cancel	Sets all hue and saturation on each axis to default values (execute by selecting Execute).
Axis	B/B+ /MG–/MG/MG+/R/R+/Y/L–/Y/LYL+/G–/G/G+/CY/CY+/B–	Sets the color targeted for multi matrix correction (16-axis mode)
Hue	–99 to ±0 to +99	Sets the hue of the color targeted for multi matrix correction for each 16-axis mode.

Paint >Multi Matrix Makes settings related to multi matrix correction. Multi-matrix correction sets the saturation using a 16-axis hue space.		
Item	Setting	Description
Saturation	-99 to ±0 to +99	Sets the saturation of the color targeted for multi matrix correction for each 16-axis mode.
Paint >V Modulation Makes settings related to V modulation shading correction. V modulation shading corrects the vertical slope of the sensitivity arising from the relationship between the lens and prism.		
Item	Setting	Description
Setting	On/Off	Turns the V modulation shading correction function on/off.
Master V Modulation	-99 to ±0 to +99	Sets the master V modulation level.
R V Modulation	-99 to ±0 to +99	Sets the V modulation level of the R signal.
G V Modulation	-99 to ±0 to +99	Sets the V modulation level of the G signal.
B V Modulation	-99 to ±0 to +99	Sets the V modulation level of the B signal.
Paint >Low Key Saturation Makes settings related to low key saturation correction. Corrects the saturation of colors in dark parts of the image.		
Item	Setting	Description
Setting	On/Off	Turns the low key saturation correction function on/off. [Note] To enable the low key saturation function, set Saturation Mode to Low Key.
Level	-99 to ±0 to +99	Sets the saturation of colors in low luminance areas.
Range	Low/L,Mid/H,Mid	Selects the luminance level for which low key saturation is enabled.
Paint >Saturation Mode Makes settings related to saturation correction.		
Item	Setting	Description
Saturation Mode	Knee/Low Key	Selects whether the saturation function operates at high levels (Knee) or low levels (Low Key).
Knee Saturation	On/Off	Turns the knee saturation function on/off.
Black Gamma	On/Off	Turns the black gamma correction function on/off.
Low Key Saturation	On/Off	Turns the low knee saturation function on/off.

Paint >Noise Suppression Makes settings related to noise suppression (noise compression). This allows you to effectively suppress noise components while preserving fine edge components of the subject.		
Item	Setting	Description
Setting	On/Off	Turns the noise suppression function on/off.
Level	Low/ Mid /High	Selects the noise suppression level.

Maintenance Menu

Default values are shown in **bold**.

Maintenance >White Shading		
Makes settings related to white shading correction. White shading is required for each different lens to correct luminance and color irregularities in bright areas arising from lens characteristics.		
Item	Setting	Description
Channel Select	Red/Green/Blue	Selects the target for white shading correction.
White H Saw	-99 to ±0 to +99	Sets the SAW white shading correction value for the horizontal direction.
White H Para	-99 to ±0 to +99	Sets the parabola white shading correction value for the horizontal direction.
White V Saw	-99 to ±0 to +99	Sets the SAW white shading correction value for the vertical direction.
White V Para	-99 to ±0 to +99	Sets the parabola white shading correction value for the vertical direction.
White Saw/Para	On/Off	Turns the white shading SAW/parabola correction function on/off.
Maintenance >Black Shading		
Makes settings related to black shading correction.		
Item	Setting	Description
Channel Select	Red/Green/Blue	Selects the target for black shading correction.
Black H Saw	-99 to ±0 to +99	Sets the SAW black shading correction value for the horizontal direction.
Black H Para	-99 to ±0 to +99	Sets the parabola black shading correction value for the horizontal direction.
Black V Saw	-99 to ±0 to +99	Sets the SAW black shading correction value for the vertical direction.
Black V Para	-99 to ±0 to +99	Sets the parabola black shading correction value for the vertical direction.
Black Saw/Para	On/Off	Turns the black shading SAW/parabola correction function on/off.
Master Black	-99 to ±0 to +99	Sets the master black level.
Master Gain (TMP)	-3dB/0dB/3dB/6dB/9dB/12dB/18dB/24dB/30dB/36dB/42dB	Sets a temporary master gain value.

Maintenance >Battery		
Makes settings related to batteries.		
Item	Setting	Description
Near End: Info Battery	5% /10%/15%..95%/100%	Sets the threshold value for displaying the "Battery Near End" warning when using a BP-FLX75/GL65A/GL95A battery pack.
End: Info Battery	0%/1%/2%/3%/4%/5%	Sets the threshold value for displaying the "Battery End" warning when using a BP-FLX75/GL65A/GL95A battery pack.
Near End: Sony Battery	11.5V to 17V (0.1V steps)	Sets the threshold value for displaying the "Battery Near End" warning when using a BP-L60S/L80S battery pack.
End: Sony Battery	11.0V to 11.5V (0.1V steps)	Sets the threshold value for displaying the "Battery End" warning when using a BP-L60S/L80S battery pack.
Near End: Other Battery	11.5V to 11.8V to 17.0V (0.1V steps)	Sets the threshold value for displaying the "Battery Near End" warning when using a non-Sony battery pack.
End: Other Battery	11.0V to 14.0V (0.1V steps)	Sets the threshold value for displaying the "Battery End" warning when using a non-Sony battery pack.
Detected Battery	Sony Info Battery/Sony Battery/Other Battery/DC IN	Displays the result of automatic battery pack type detection.
Maintenance >DC Voltage Alarm		
Sets alarms relating to external DC supply voltage.		
Item	Setting	Description
DC Low Voltage1	11.5V to 17V (0.1V steps)	Sets the threshold value for displaying the "Battery Near End" warning when using an external power source connected to the DC IN connector.
DC Low Voltage2	11.0V to 14.0V (0.1V steps)	Sets the threshold value for displaying the "Battery End" warning when using an external power source connected to the DC IN connector.
Maintenance >Audio		
Makes settings related to audio.		
Item	Setting	Description
Front MIC Select	Mono/ Stereo	Selects whether the front microphone is monaural (Mono) or stereo (Stereo).
Rear XLR Auto	On/ Off	Turns the automatic detection function on/off for detecting cable connections on the AUDIO IN CH-1/CH-2 connectors on the rear panel.
Front MIC CH1 Ref	-70dB/-60dB/ -50dB /-40dB/-30dB	Selects the reference level of the front microphone for channel 1.

Maintenance >Audio		
Makes settings related to audio.		
Item	Setting	Description
Front MIC CH2 Ref	-70dB/-60dB/-50dB/-40dB/-30dB	Selects the reference level of the front microphone for channel 2.
Rear MIC CH1 Ref	-70dB/-60dB/-50dB/-40dB/-30dB	Selects the reference input level when the AUDIO IN CH1 switch is set to MIC.
Rear MIC CH2 Ref	-70dB/-60dB/-50dB/-40dB/-30dB	Selects the reference input level when the AUDIO IN CH2 switch is set to MIC.
Line Input Ref	+4dB/0dB/-3dB/EBUL	Selects the reference input level when the AUDIO IN CH1 and AUDIO IN CH2 switches are set to LINE.
Min Alarm Volume	Off/Set	Selects the volume when the ALARM knob is turned all the way down. Off: Inaudible Set: Audible
Speaker Attenuate	Off/3dB/6dB/9dB/12dB	Selects the volume from the monitor speakers (does not affect earphone volume).
Headphone Out	Mono/Stereo	Selects whether the earphones are monaural (Mono) or stereo (Stereo).
Reference Level	-20dB/-18dB/-16dB/-12dB/EBUL	Sets the output level of the 1 kHz test signal.
Reference Out	+4dB/0dB/-3dB/EBUL	Sets the output level relative to the reference input level.
CH1&2 AGC Mode	Mono/Stereo	Automatically adjusts the input level of analog audio signals recorded on channels 1 and 2, and selects whether to make the adjustments separately for each channel (Mono) or in stereo mode (Stereo).
CH3&4 AGC Mode	Mono/Stereo	Automatically adjusts the input level of analog audio signals recorded on channels 3 and 4, and selects whether to make the adjustments separately for each channel (Mono) or in stereo mode (Stereo).
AGC Spec	-6dB/-9dB/-12dB/-15dB/-17dB	Selects the AGC characteristic (saturation level).
Limiter Mode	Off/-6dB/-9dB/-12dB/-15dB/-17dB	Selects the limiter characteristic (saturation level) for large input signals when adjusting the audio input level manually. Select Off if not using the limiter.
Output Limiter	On/Off	Turns the audio output limiter on/off.
CH1 Wind Filter	On/Off	Turns the channel 1 wind noise reduction filter on/off.

Maintenance >Audio		
Makes settings related to audio.		
Item	Setting	Description
CH2 Wind Filter	On/Off	Turns the channel 2 wind noise reduction filter on/off.
CH2 Wind Filter	On/Off	Turns the channel 3 wind noise reduction filter on/off.
CH4 Wind Filter	On/Off	Turns the channel 4 wind noise reduction filter on/off.
1kHz Tone on Color Bars	On/Off/Auto	Sets whether to output (On) or not output (Off) a 1 kHz test signal in color bar mode. Auto: Outputs a test signal only when the AUDIO SELECT CH1 switch is set to AUTO.
MIC CH1 Level	Side1/Front/Front+Side1	Selects the knob for adjusting the audio level when recording input audio from the front microphone on channel 1. Side1: LEVEL knob (left) on the side panel Front: MIC LEVEL knob on the front panel Front+Side1: LEVEL knob (left) and MIC LEVEL knob (linked control)
MIC CH2 Level	Side2/Front/Front+Side2	Selects the knob for adjusting the audio level when recording input audio from the front microphone on channel 2. Side2: LEVEL knob (right) on the side panel Front: MIC LEVEL knob on the front panel Front+Side2: LEVEL knob (right) and MIC LEVEL knob (linked control)
Rear1/MRR Level	Side1/Front/Front+Side1	Selects the knob for adjusting the audio level of a wireless microphone or a device connected to the AUDIO IN CH-1 connector on the rear panel. Side1: LEVEL knob (left) on the side panel Front: MIC LEVEL knob on the front panel Front+Side1: LEVEL knob (left) and MIC LEVEL knob (linked control)
Rear2/WRR Level	Side2/Front/Front+Side2	Selects the knob for adjusting the audio level of a wireless microphone or a device connected to the AUDIO IN CH-2 connector on the rear panel. Side2: LEVEL knob (right) on the side panel Front: MIC LEVEL knob on the front panel Front+Side2: LEVEL knob (right) and MIC LEVEL knob (linked control)

Maintenance >Audio		
Makes settings related to audio.		
Item	Setting	Description
Audio CH3 Level	Side3/Front/Front+Side3	Selects the knob for adjusting the audio level recorded on channel 3. Side3: LEVEL knob on the side panel Front: MIC LEVEL knob on the front panel Front+Side3: LEVEL knob and MIC LEVEL knob (linked control)
Audio CH4 Level	Side4/Front/Front+Side4	Selects the knob for adjusting the audio level recorded on channel 4. Side4: LEVEL knob on the side panel Front: MIC LEVEL knob on the front panel Front+Side4: LEVEL knob and MIC LEVEL knob (linked control)
Maintenance >WRR Setting		
Makes settings related to the wireless tuner.		
Item	Setting	Description
WRR Valid CH Sel	All/CH1	Selects whether to enable channels 1 and 2 of the wireless tuner (All) or channel 1 only (CH1).
WRR CH Select	TX1 /TX2	Selects the reception channel for display in the menu. TX1: Displays channel 1. TX2: Displays channel 2.
WRR Delay Comp	On/Off	Selects whether to enable (On) or disable (Off) the delay compensation function for wireless input audio. (When On is selected, all E-E output audio is delayed by about 8 ms.)
TX	---	Displays the name of the transmitter whose signals are being received on the channel selected by WRR CH Select.
TX Audio Peak	---/Peak	Displays whether the AF level of the transmitter whose signals are being received on the channel selected by WRR CH Select are over peak.
TX Input Level	---/Mic/Line	Displays whether the input level of the transmitter whose signals are being received on the channel selected by WRR CH Select is set to microphone (Mic) or line (line).
TX ATT Level	---	Sets the ATT level of the transmitter whose signals are being received on the channel selected by WRR CH Select. (The setting range varies depending on the transmitter.)

Maintenance >WRR Setting		
Makes settings related to the wireless tuner.		
Item	Setting	Description
TX LCF Frequency	---	Sets the low cut filter frequency of the transmitter whose signals are being received on the channel selected by WRR CH Select. (The setting range varies depending on the transmitter.)
TX System Delay	Auto/0.0ms to 8.0ms	Sets the amount of audio delay. Auto: Automatically corrects for the amount of delay so that the delay in the audio from the wireless tuner is zero. 0.0ms to 8.0ms: Sets the amount of estimated wireless system delay, for cases in which several wireless systems are being used via a device such as an audio mixer.
TX RF Power	High (Power value) mW/Mid (Power value) mW/Low (Power value) mW	Sets the RF power level of the transmitter communicating on the channel selected by WRR CH Select. (The setting range varies depending on the transmitter.)
TX Power Save	Active/Sleep	Sets the power saving mode of the transmitter whose signals are being received on the channel selected by WRR CH Select. Active: Set the transmitter to startup mode. Sleep: Set the transmitter to power saving mode.
Maintenance >Time Code		
Makes settings related to timecode.		
Item	Setting	Description
TC Out	Auto/Generator	Selects the timecode output. Auto: Outputs the timecode generator value during recording, and the timecode reader value during playback. Generator: Outputs the timecode generator value during recording and playback.
DF/NDF	DF/NDF	Selects drop-frame mode (DF) or non-drop-frame mode (NDF).
LTC UBIT	Fix/Time	Sets the data recorded in LTC user bits. Fix: Records user-specified data. Time: Records the current time.

Maintenance >Time Code		
Makes settings related to timecode.		
Item	Setting	Description
Counter Display	Counter/Duration	Select the method used to reset the counter value displayed on the viewfinder screen. Counter: Continue to increment until the RESET button is pressed. Duration: Reset each time that recording is started.

Maintenance >Essence Mark		
Makes settings related to essence marks.		
Item	Setting	Description
Find Mode	Clip/Rec Start	Sets the operation when the NEXT/PREV button is pressed. Rec Start: Moves to the next or the previous recording start mark, respectively. Clip: Moves to the start of the next clip when the NEXT button is pressed. Moves to the start of the current clip when the PREV button is pressed (or moves to the start of the previous clip if the PREV button is pressed at the start of the clip).

Maintenance >Camera Config		
Makes settings related to various camcorder operations.		
Item	Setting	Description
HD/SDI Remote I/F	Off/Characters/ Green Tally/Red Tally	Sets whether to enable the recording control function for an external device connected to the SDI OUT 1/2 connector (HD SDI output) of the camcorder. If enabled, it selects the indicator used to display the recording state of the external device. Off: Recording control function is disabled. Chara: Displayed using the external device control indicator on the status display in the viewfinder. G-Tally: Displayed using the TALLY indicator (green tally) in the viewfinder. R-Tally: Displayed using the REC indicator (recording red tally) in the viewfinder.
Color Bars Select	ARIB/100%/75%/SMPT-E	Selects the color bar type.
User Menu Only	On/Off	Selects whether to display the User menu only (On) or display the menu list (Off) when the camcorder is displaying the menu.

Maintenance >Camera Config		
Makes settings related to various camcorder operations.		
Item	Setting	Description
User Menu with Lock	On/Off	Selects whether to lock the menu display, showing the User menu only. On: Enter an arbitrary passcode number to lock the menu display. (Only the User menu is displayed) Off: Enter the passcode number entered when "On" was selected to unlock the menu display. (When unlocked, the normal menu list is displayed)
RM Common Memory	On/Off	[Note] In normal menu display operation, this item is not displayed. For details about menu display operation, see page 87. Selects whether to share (On) or not share (Off) settings between when using a remote control unit connection and when the camcorder is operated locally.
RM Rec Start	RM/Camera/PARA	Selects which of the recording start/stop buttons are enabled when a remote control unit is connected. RM: Remote control unit Camera: Camcorder PARA: Both
SET Key on Thumbnail	Pause/Play	Selects the operation when the MENU knob is pressed with only one thumbnail selected.

Maintenance >Camera Config		
Makes settings related to various camcorder operations.		
Item	Setting	Description

ALAC **Auto/Off**

Sets whether to execute ALAC (Auto Lens Aberration Correction) automatically.
Auto: Execute ALAC automatically when an ALAC-compatible lens is attached and ALAC is enabled.
Off: Do not execute.

[Note]
Depending on the aberration correction lens, the aberration correction function may not be activated immediately ("ALAC" does not appear on the viewfinder screen) after turning the power on, even when this setting is set to Auto. If this occurs, turn the lens zoom ring and focus ring to the end stop and back, and check whether the "ALAC" indicator appears on the viewfinder screen.
Contact a Sony service representative for information about aberration correction lenses.

Maintenance >White Filter		
Makes settings related to filters.		
Item	Setting	Description

ND Filter C.Temp

On/Off

Turns the function that assigns electrical CC filters to ND filters on/off.

ND FLT C.Temp<1>

3200K/4300K/5600K/6300K

Selects the color temperature when electrical CC filters are assigned to ND filters (filter 1).

ND FLT C.Temp<2-4>

3200K/4300K/5600K/6300K

Selects the color temperature when electrical CC filters are assigned to ND filters (filters 2 to 4).

Electrical CC<A>

3200K/4300K/5600K/6300K

Selects the color temperature when the electrical CC filter switching function is assigned to an assignable switch.

Electrical CC

3200K/4300K/5600K/6300K

Selects the color temperature when the electrical CC filter switching function is assigned to an assignable switch.

Electrical CC<C>

3200K/4300K/5600K/6300K/---

Selects the color temperature when the electrical CC filter switching function is assigned to an assignable switch. Select "---" if not using C.

Electrical CC<D>

3200K/4300K/5600K/6300K/---

Selects the color temperature when the electrical CC filter switching function is assigned to an assignable switch. Select "---" if not using D.

Maintenance >Preset White		
Makes settings related to white balance preset values.		
Item	Setting	Description
Color Temp <P>	1500K to 3200K to 50000K	Sets the white balance preset value.
C.Temp BAL <P>	-99 to ±0 to +99	Sets the fine color temperature settings, for use when a satisfactory image cannot be obtained using Color Temp<P>.
R Gain <P>	-99 to ±0 to +99	Sets the R gain preset value.
B Gain <P>	-99 to ±0 to +99	Sets the B gain preset value.
AWB Enable <P>	On/Off	Turns execution of the AWB (auto white balance) function on/off when the WHITE BAL switch is set to PRST.
Color Temp <P>	1500K to 3200K to 50000K	Sets the white balance preset value.
C.Temp BAL <P>	-99 to ±0 to +99	Sets the fine color temperature settings, for use when a satisfactory image cannot be obtained using Color Temp<P>.
R Gain <P>	-99 to ±0 to +99	Sets the R gain preset value.
B Gain <P>	-99 to ±0 to +99	Sets the B gain preset value.
AWB Enable <P>	On/Off	Turns execution of the AWB (auto white balance) function on/off when the WHITE BAL switch is set to PRST.

Maintenance >DCC Adjust		
Makes settings related to DCC (dynamic contrast control).		
Item	Setting	Description
DCC Function Select	DCC/Fix	Selects the setting method for the knee point when the OUTPUT/DCC switch is set to CAM with DCC on. DCC: Automatically adjusts the knee point to match the luminance of the subject. Fix: Sets the knee point to a fixed value.
DCC D Range	400%/450%/500%/550%/600% 600%	Sets the dynamic range when the OUTPUT/DCC switch is set to CAM with DCC on.
DCC Point	-99 to ±0 to +99	Sets the DCC minimum knee point.
DCC Gain	-99 to ±0 to +99	Sets the gain relative to the DCC detected value.
DCC Delay Time	-99 to ±0 to +99	Sets the DCC control speed (speed of response to changes in the video).
DCC Peak Filter	-99 to ±0 to +99	Adjusts the response sensitivity relative to the peaks in DCC detected values.

Maintenance >Flicker Reduce Makes settings related to the flicker correction function. You can correct the flicker created when shooting a subject under lighting where the brightness varies periodically, such as fluorescent lighting, due to the relationship between the frequency and the recording frame rate.		
Item	Setting	Description
Mode	Auto/On/Off	Sets the operation of the flicker correction function. On: Always operating. Auto: Operates when flicker is detected. Off: Does not operate.
Frequency	60Hz/50Hz	The factory setting is 60Hz when System Frequency is set to 59.94, 29.97, or 23.98. The factory setting is 50Hz when System Frequency is set to 50 or 25.
Maintenance >Genlock Makes settings related to genlock.		
Item	Setting	Description
Genlock	On/Off	Turns the genlock function on/off.
Reference	Internal/External(HD)/ External(SD)/SDI IN/CA	Displays the type of reference signal used by the camcorder.
Maintenance >Auto Shading Executes auto black shading correction.		
Item	Setting	Description
Auto Black Shading	Execute/Cancel	Executes auto black shading correction (execute by selecting Execute).
Reset Black Shading	Execute/Cancel	Clears the black shading correction value (execute by selecting Execute).
Master Gain (TMP)	-3dB/0dB/3dB/6dB/9dB/12dB/ 18dB/24dB/30dB/36dB/42dB	Sets a temporary master gain value. (The value is the same as the value selected with the GAIN switch.)
Maintenance >APR Makes settings related to automatic pixel noise reduction.		
Item	Setting	Description
APR	Execute/Cancel	Executes the automatic pixel noise reduction function to suppress white flecks in SIS mode (execute by selecting Execute).
Reset	Execute/Cancel	Deletes white flecks data that were added by execution of the APR and automatic black balance adjustment functions (execute by selecting Execute).

Maintenance >Basic Authentication Makes settings related to basic authentication.		
Item	Setting	Description
User Name	(Displays the current user name.)	Sets the user name (arbitrary name for basic authentication). Set to "admin" by factory default.
Password	*****	Sets the password (for basic authentication). Set to "pxw-x400" by factory default.
Maintenance >Network Makes settings related to network connections.		
Item	Setting	Description
Setting	On/Off	Turns the network function on/off.
Wireless Network	Wi-Fi Access Point/Wi-Fi Station/ Modem/Off	Sets the operating mode for wireless LAN connections.
NFC	Execute/Cancel	Initiates a one-touch connection using NFC (execute by selecting Execute).
WPS	Execute/Cancel	Starts Wi-Fi Protected Setup (WPS) (execute by selecting Execute).
Channel	Auto(5GHz)/Auto/CH1/CH2/ CH3/CH4/CH5/CH6/CH7/CH8/ CH9/CH10/CH11	Sets the wireless LAN channel. [Note] "Auto(5GHz)" may not be displayed, depending on the wireless LAN module used.
SSID & Password	(SSID display) (Password display)	Displays the SSID and password.
Device Name (Wireless)		Displays the name of network device attached to the USB wireless LAN module connector
IP Address (Wireless)		Displays the IP address when connected to a wireless LAN.
Subnet Mask (Wireless)		Displays the subnet mask when connected to a wireless LAN.
MAC Address (Wireless)		Displays the MAC address of the USB Wireless LAN Module attached to the camcorder.
Regenerate Password	Execute/Cancel	Regenerates a password (execute by selecting Execute).
Wired LAN	Enable/Disable	Enables/disables wired LAN connection.
Wired LAN Remote	On/Off	If connected to a network using a LAN cable, operation from a Wi-Fi remote control, web menu, and "Content Browser Mobile" is enabled.

Maintenance >Network		
Makes settings related to network connections.		
Item	Setting	Description
Wired LAN Detail Settings	DHCP (On/Off)	Enables/disables DHCP. When set to On, an IP address is automatically assigned to the camcorder. To enter the camcorder IP address manually, set to Off.
	IP Address (DHCP/On: obtain automatically , DHCP/Off: 192.168.2.50)	Enter the IP address of the camcorder. Enabled only when DHCP is Off.
	Subnet Mask (DHCP/On: obtain automatically , DHCP/Off: 255.255.255.0)	Enter the subnet mask of the camcorder. Enabled only when DHCP is Off.
	Gateway (DHCP/On: obtain automatically , DHCP/Off: 0.0.0.0)	Enter the gateway for the access point. Enabled only when DHCP is Off.
	DNS Auto (On/Off)	Enables/disables automatic DNS. When set to On, the address of the DNS server is obtained automatically.
	Primary DNS Server (DNS Auto/On: obtain automatically , DNS Auto/Off: 0.0.0.0)	Enter the primary DNS server for the router. Enabled only when DNS Auto is Off.
	Secondary DNS Server (DNS Auto/On: obtain automatically , DNS Auto/Off: 0.0.0.0)	Enter the secondary DNS server for the router. Enabled only when DNS Auto is Off.
Maintenance >Network Client Mode		
Makes settings related to network client mode.		
[Note] Network client mode cannot be set if values are not entered for all items.		
Item	Setting	Description
Setting	On/Off	Turns network client mode on/off. [Note] When set to On, the firmware version cannot be updated.

Maintenance >Network Client Mode		
Makes settings related to network client mode.		
[Note] Network client mode cannot be set if values are not entered for all items.		
Item	Setting	Description
Detail Settings	CCM Address	Sets the address of the CCM to connect. Host name or IP address
	CCM Port (1 to 65535 (8443))	Sets the port number of the CCM to connect
	User Name	Sets the user name for authentication of the CCM to connect.
	Password	Sets the password of the CCM to connect.
	NCM with Proxy (Enable/ Disable)	Enable: Enable proxy recording when connected with a CCM. Disable: Disable proxy recording when connected with a CCM.
Maintenance >File Transfer		
Makes settings related to network transfer of data on SxS memory cards in the camcorder.		
Item	Setting	Description
File Transfer	Execute/Cancel	Switches to transfer mode (execute by selecting Execute).
Remote File Transfer	Enable/ Disable	Sets whether to enable/disable switching to transfer mode to transfer original files recorded on the camcorder by remote operation over a network. Enable: Enable switching to transfer mode by remote operation over a network. It is not necessary to execute a transfer using Maintenance >File Transfer. Disable: Disable switching to transfer mode by remote operation over a network. It is necessary to execute a transfer using Maintenance >File Transfer.
Auto Upload (Proxy)	Off/On	Turns proxy file auto transfer on/off.
Maintenance >Streaming		
Makes settings related to streaming.		
Item	Setting	Description
Setting	On/Off	Turns streaming transmission on/off. [Notes] • This setting is set to Off when you turn the power on again. • When set to On, the monitoring function is not available.

Maintenance >Streaming		
Makes settings related to streaming.		
Item	Setting	Description
Preset Select	Preset 1/Preset 2/Preset 3	Selects a streaming preset. The settings are common to Preset 1/Preset 2/ Preset 3. See below for descriptions for the settings in a preset.
Size	HD Auto/1280×720/ 640×360 / 480×270/320×180	Sets the size of video for streaming. When “HD Auto” is selected, the size is set to 1920×1080 or 1280×720, according to the setting of the recording format recorded on the SxS memory card or the format of the clip to be played back.
Bit Rate	9Mbps/6Mbps/ 3Mbps / 2Mbps/1Mbps/0.5Mbps/ 0.3Mbps(Mono L)/ 0.3Mbps(Mono R)/ 0.2Mbps(Mono L)/ 0.2Mbps(Mono R)	Sets the bit rate of video for streaming. The selectable bit rate varies depending on the Size setting. [Notes] - Audio/video data is transmitted as-is via the Internet. Accordingly, the data may potentially be exposed to other parties. Always check that the transmission destination can receive the streaming data. - The data may be sent to an unintended party if the address or other settings are configured incorrectly. - Not all frames may be played, depending on the status of the network. - The picture quality may deteriorate in scenes with excessive motion. - Not all frames may be played when the stream is set to a large size with a small bit rate. To reduce this, select a smaller size for the Size setting.
Type	MPEG-2 TS/UDP/MPEG-2 TS/ RTP	Selects the type of video for streaming.
Destination Address	Character string (0.0.0.0)	Enter the address of the transmission destination server for streaming data.
Destination Port	1 to 65545 (1234)	Enter the port number of the transmission destination server used for streaming.
Audio Channel	CH1/CH2/CH3/CH4	Selects the audio channel for the streaming output.
Maintenance >Clock Set		
Sets the internal clock.		
Item	Setting	Description
Date Mode	YYMMDD/MMDDYY/DDMMYY	Selects the display format for dates.
12H/24H	12H/24H	Selects the clock display format.
Date		Displays the date setting screen.

Maintenance >Clock Set		
Sets the internal clock.		
Item	Setting	Description
Time		Displays the time setting screen.
Maintenance >Language		
Selects the display language for messages.		
Item	Setting	Description
Select	English/ 中文(簡)/ 日本語 / Espanol/ Русский	Selects the display language for messages.
Maintenance >Hours Meter		
Makes settings related to the digital hours meter.		
Item	Setting	Description
Hours (System)	xxxxH (xxxx hours)	Displays the cumulative hours of use (cannot be reset).
Hours (Reset)	xxxxH (xxx hours)	Displays the cumulative hours of use (can be reset).
Reset	Execute/Cancel	Resets the Hours (Reset) display to 0 (execute by selecting Execute).
Maintenance >Network Reset		
Returns network-related settings to their factory default state.		
Item	Setting	Description
Reset	Execute/Cancel	Resets network related settings (execute by selecting Execute).
Maintenance >Fan Control		
Sets the fan control mode.		
Item	Setting	Description
Setting	Auto/Minimum/Off in Rec	Selects the fan control mode.
Maintenance >VF Display Setting		
Makes settings related to the viewfinder display.		
Item	Setting	Description
Chara/Marker Brightness	5/4/3/2/1	Sets the brightness of character strings, icons, and markers superimposed in the viewfinder image.

Maintenance >Version		
Displays the version of the camcorder, and updates the camcorder.		
Item	Setting	Description
Number	Version Up Execute/Cancel	Displays the software version of the camcorder (Vx.xx). Updates the camcorder (execute by selecting Execute).
		[Note] Cannot be selected when the version updater SD card is not inserted.
Net-Func Version Number		Displays the firmware version of the wireless LAN connection function of the camcorder (Vx.xx)
Net-Func Ver.Up	Execute/Cancel	Updates the firmware of the wireless LAN connection function (execute by selecting Execute).

File Menu

Default values are shown in **bold**.

File > User File		
Makes settings relating to user file operations.		
Item	Setting	Description
Load SD Card		Displays a screen for loading user file settings from an SD card.
Save SD Card		Displays a screen for saving user file settings onto an SD card.
File ID		Displays a screen for displaying/editing the file ID of user files.
Recall User Preset	Execute/Cancel	Returns the value of menu items registered in the User menu to the preset values (execute by selecting [Execute]).
Store User Preset	Execute/Cancel	Stores the value of menu items registered in the User menu items as the preset values (execute by selecting [Execute]).
Clear User Preset	Execute/Cancel	Returns the current settings and preset values of menu items registered in the User menu to the factory default values (execute by selecting [Execute]).
Load Customize Data	On/ Off	Sets whether to load User menu customized information when [Load SD Card] is executed.
Load White Data	On/ Off	Sets whether to load white balance information when [Load SD Card] is executed.
File > All File		
Makes settings related to ALL file operations.		
Item	Setting	Description
Load SD Card		Displays a screen for loading All File settings from an SD card.
Save SD Card		Displays a screen for saving All File settings onto an SD card.
File ID		Displays a screen for displaying/editing the file ID of All Files.
All Preset	Execute/Cancel	Returns all items to their preset values (execute by selecting Execute).
Store All Preset	Execute/Cancel	Stores the current settings of all items as the preset values (execute by selecting [Execute]).

File > All File		
Makes settings related to ALL file operations.		
Item	Setting	Description
Clear All Preset	Execute/Cancel	Returns the current settings and presets of All File menu items to their factory default values (execute by selecting Execute).
35Sec Clear Preset	On/Off	Turns the function that clears the current settings and presets of each item on/off, when the MENU CANCEL/PRST/ESCAPE switch is pushed up and held for three seconds in the CANCEL/PRST position.

File > Scene File		
Makes settings related to scene file operations.		
Item	Setting	Description
Recall Internal Memory		Displays a screen for recalling scene files from internal memory.
Store Internal Memory		Displays a screen for storing scene files in internal memory.
Load SD Card		Displays a screen for loading scene files from an SD card.
Save SD Card		Displays a screen for saving scene files onto an SD card.
File ID		Displays a screen for displaying/editing the file ID of scene files.
Scene White Data	On/Off	Sets whether to reflect the white balance data of scene files when recalling scene files.

File > Reference File		
Makes settings related to reference file operations.		
Item	Setting	Description
Store Reference	Execute/Cancel	Stores the current settings of reference file target menu items as the preset values (execute by selecting [Execute]).
Clear Reference	Execute/Cancel	Returns the current settings and preset values of reference file target menu items to the factory default values (execute by selecting [Execute]).
Load Reference(SD Card)	Execute/Cancel	Loads reference file settings from an SD card and sets the preset values (execute by selecting [Execute]).
Save Reference(SD Card)	Execute/Cancel	Stores the preset values of reference file target menu items to an SD card (execute by selecting [Execute]).

File > Reference File		
Makes settings related to reference file operations.		
Item	Setting	Description
File ID		Displays a screen for displaying/editing the file ID of reference files.

File > Lens File		
Makes settings related to lens file operations.		
Item	Setting	Description
Display Mode	Model Name/Lens ID	Selects the items to display in the list box that appears when saving or loading a file.
Recall Internal Memory		Displays a screen for recalling lens files from internal memory.
Store Internal Memory		Displays a screen for storing lens files in internal memory.
Load SD Card		Displays a screen for loading lens files from an SD card.
Save SD Card		Displays a screen for saving lens files onto an SD card.

File ID		Displays a screen for displaying/editing the file ID of lens files.
File Source		Displays the number of the selected file.
Clear Lens Offset	Execute/Cancel	Clears the lens file (execute by selecting Execute).
Lens Auto Recall	Off/On(Lens Name)/ On(Serial Number)	Sets whether to automatically recall a lens file when a lens that supports serial communication is attached.
Lens Serial Number		Displays the serial number of the attached lens (lenses that support serial communication only).
Lens Name		Displays the model name of the attached lens (lenses that support serial communication only).
Lens Manufacturer		Displays the name of the manufacturer of the attached lens (lenses that support serial communication only).
Master V Modulation	-99 to ±0 to +99	Sets the SAW shading correction value in the vertical direction in the lens file.
Lens Center H	-40 to ±0 to +40	Sets the horizontal position of the center marker in the lens file.
Lens Center V	-40 to ±0 to +40	Sets the vertical position of the center marker in the lens file.
R Flare	-99 to ±0 to +99	Sets the R flare level in the lens file.
G Flare	-99 to ±0 to +99	Sets the G flare level in the lens file.
B Flare	-99 to ±0 to +99	Sets the B flare level in the lens file.

File > Lens File		
Makes settings related to lens file operations.		
Item	Setting	Description
White Offset R	-99 to ± 0 to +99	Sets the white balance offset R channel correction value for the lens in the lens file.
White Offset B	-99 to ± 0 to +99	Sets the white balance offset B channel correction value for the lens in the lens file.
Shading Ch Select	Red/Green/Blue	Selects the target for white shading correction.
Shading H SAW	-99 to ± 0 to +99	Sets the SAW white shading correction value in the horizontal direction in the lens file.
Shading H PARA	-99 to ± 0 to +99	Sets the parabola white shading correction value in the horizontal direction in the lens file.
Shading V SAW	-99 to ± 0 to +99	Sets the SAW white shading correction value in the vertical direction in the lens file.
Shading V PARA	-99 to ± 0 to +99	Sets the parabola white shading correction value in the vertical direction in the lens file.
File > User Gamma		
Makes settings related to user gamma.		
Item	Setting	Description
Current Settings		Displays a list screen of the current user gamma file settings (file names).
Load SD Card		Displays a screen for loading User Gamma settings from an SD card.
Reset	1/2/3/4/5/All	Resets the settings in the selected user gamma file (execute by selecting Execute). Select All to reset all user gamma files.

Assigning Functions to Assignable Switches

Using the Assignable Switch item of the Operation menu, you can assign user-specified functions to the ASSIGN. 0 to 3 switches, the ASSIGNABLE 4 and 5 switches, the ONLINE button, and the RET button on the lens.

The following tables lists the functions that are assigned when the camcorder is shipped from the factory.

Switch or button	Function	Assignable Switch setting
ASSIGN. 0 switch	No assignment	Off
ASSIGN. 1 switch	No assignment	Off
ASSIGN. 2 switch	No assignment	Off
ASSIGN. 3 switch	No assignment	Off
ASSIGNABLE 4 switch	No assignment	Off
ASSIGNABLE 5 switch	No assignment	Off
RET button	Rec Review (if playback is allowed)	Lens RET
ONLINE button	Auto transfer proxy clip	Network Client Mode

Functions That Can Be Assigned to the ASSIGN. 0 Switch

Assignable Switch setting	Function	State when camcorder is next powered on
Off	No assignment	—
Marker	Turns the display of all markers on/off.	Setting retained
ATW Hold	Holds the white balance setting in the ATW (auto-tracking white balance) mode	—
Picture Cache Rec	Turns picture cache recording mode on/off.	Setting retained
Focus Magnifier	Turns the focus magnification function on/off.	Setting not retained
Zebra	Turns zebra display on/off.	Setting not retained
Shot Mark1	Writes Shot Mark1.	—
Shot Mark2	Writes Shot Mark2.	—
Clip Flag OK	Adds/Clears an OK mark to/from the clip being recorded or played.	Setting not retained
Clip Flag NG	Adds/Clears an NG mark to/from the clip being recorded or played.	Setting not retained
Clip Flag Keep	Adds/Clears a KP (Keep) mark to/from the clip being recorded or played.	Setting not retained
Flash Band Reduce	Turns the flashband correction function on/off.	Setting not retained

Functions That Can Be Assigned to the ASSIGN. 2 Switch

[Note]

Immediately after you assign a function to the ASSIGN. 2 switch or you switch the recording format, the setting of the switch at that point may not match the camcorder's internal state. After assigning a function, switch the ASSIGN. 2 switch or power the camcorder off and on again.

Assignable Switch setting	Function
Off	No assignment
Front Mic	Switches between stereo and monaural when a stereo microphone is connected.
Marker	Turns the display of all markers on/off.
Picture Cache Rec ¹⁾	Turns picture cache recording mode on/off.
Zebra	Turns zebra display on/off.
Clip Continuous Rec	Turns Clip Continuous Rec mode on/off.
Rec Source	Switches the signals to be recorded between the camera picture and external input. (If the camcorder is currently recording or playing, the switch takes effect after recording or playback ends.)
Digital Extender x2	Turns the screen magnification (x2) function on/off.
Digital Extender x3	Turns the screen magnification (x3) function on/off.
Digital Extender x4	Turns the screen magnification (x4) function on/off.

1) When Picture Cache Rec is assigned, Operation >Rec Function is disabled (grayed out) and cannot be set.

Functions That Can Be Assigned to the ASSIGN. 1 and 3 Switches, the ASSIGNABLE 4 and 5 Switches, and the ONLINE Button

Assignable Switch setting	Function	State when camcorder is next powered on
Off	No assignment	—
Front Mic	Switches between stereo (On) and monaural (Off) when a stereo microphone is connected.	Setting retained
Marker	Turns the display of all markers on/off.	Setting retained
ATW	Turns ATW (auto tracing white balance) mode on/off.	Setting not retained
ATW Hold	Hold the white balance setting in the ATW mode.	—
Turbo Gain	Executes Turbo Gain according to the setting of Operation >Gain Switch >Gain Turbo.	Setting not retained
Rec Review	Executes recording review.	—
Rec	Starts or stops recording.	—
NFC	Executes the NFC function.	—
Network Client Mode	Turns network client mode on/off.	Setting retained
Streaming	Turns streaming transmission on/off.	Setting not retained
Auto Upload(Proxy)	Turns proxy file auto transfer on/off.	Setting retained
Picture Cache Rec	Turns picture cache recording mode on/off.	Setting retained
Spotlight	Turns the spotlight function in auto iris mode on/off.	Setting retained
Backlight	Turns the backlight function in auto iris mode on/off.	Setting retained
VF Mode	Switches the viewfinder screen between B&W (On) and color (Off).	Setting retained
Video Signal Monitor	Switches the video signal monitor display function.	Setting retained
Lens Info	Switches the depth of field indication between off, displayed in meters, and displayed in feet.	Setting retained
Zoom Tele/Wide	When a lens that supports serial communication is installed, assigns the Zoom Tele function to ASSIGNABLE 4, and assigns the Zoom Wide function to ASSIGNABLE 5 (displayed only when <4> and <5> are set).	—
Zoom Wide/Tele	When a lens that supports serial communication is installed, assigns the Zoom Wide function to ASSIGNABLE 4, and assigns the Zoom Tele function to ASSIGNABLE 5 (displayed only when <4> and <5> are set).	—

Assignable Switch setting	Function	State when camcorder is next powered on
Manual Focus Assist	Turns the manual focus assist function on/off.	Setting retained
Focus Magnifier	Turns the focus magnification function on/off.	Setting not retained
Zebra	Turns zebra display on/off.	Setting not retained
Lens RET	Displays return video signal. When a camera extension unit is not connected: Rec Review (if playback is allowed)	—
Return Video	Displays the return 1 video signal.	—
Return Video2	Displays the return 2 video signal.	—
Return Video3	Displays the return 3 video signal.	—
Return Video4	Displays the return 4 video signal.	—
Shot Mark1	Writes Shot Mark1.	—
Shot Mark2	Writes Shot Mark2.	—
Clip Flag OK	Adds/Clears an OK mark to/from the clip being recorded or played.	Setting not retained
Clip Flag NG	Adds/Clears an NG mark to/from the clip being recorded or played.	Setting not retained
Clip Flag Keep	Adds/Clears a KP (Keep) mark to/from the clip being recorded or played.	Setting not retained
Color Temp SW 3200K	Adjusts white balance using 3200K preset value.	Setting retained
Color Temp SW 4300K	Adjusts white balance using 4300K preset value.	Setting retained
Color Temp SW 5600K	Adjusts white balance using 5600K preset value.	Setting retained
Color Temp SW 6300K	Adjusts white balance using 6300K preset value.	Setting retained
Electrical CC	Function that switches the electrical CC filter (3200K/4300K/5600K/6300K) applied to white balance adjustment values. Sequence with each press of the switch/button: 3200K → 4300K → 5600K → 6300K Can be changed using menu settings (Electrical CC <A> <C> <D>).	Setting retained
[Note] This function is not available when Maintenance >White Filter >ND Filter C/Temp in the setup menu is set to On. If you set ND Filter C/Temp to On after assigning the function, the assignable switch ceases to function.		
CC5600K	Applies a 5600K electrical CC filter to white balance adjustment values.	Setting retained
Clip Continuous Rec	Turns Clip Continuous Rec mode on/off.	Setting not retained
Slot Select	When recording media is loaded in both card slots A and B, selects the card you want to use.	—
Digital Extender x2	Turns the screen magnification (x2) function on/off.	Setting not retained

Assignable Switch setting	Function	State when camcorder is next powered on
Digital Extender x3	Turns the screen magnification (x3) function on/off.	Setting not retained
Digital Extender x4	Turns the screen magnification (x4) function on/off.	Setting not retained
Digital Extender x2x3x4	Switches the magnification of the screen magnification function. Each press of the switch or button switches in the order Off → x2 → x3 → x4 → Off.	Setting not retained
Flash Band Reduce	Turns the flashband correction function on/off.	Setting not retained
Proxy Rec Start/Stop	Starts/stops proxy recording.	Setting not retained

Functions That Can Be Assigned to the RET Button on the Lens

Assignable Switch setting	Function	State when camcorder is next powered on
Off	No assignment	—
Lens RET	Displays return video signal. When a camera extension unit is not connected: Rec Review (if playback is allowed)	—
Return Video	Displays return video signal.	—
Rec Review	Executes recording review.	—
Shot Mark1	Writes Shot Mark1.	—
Shot Mark2	Writes Shot Mark2.	—
Clip Flag OK	Adds/Clears an OK mark to/from the clip being recorded or played.	Setting not retained
Clip Flag NG	Adds/Clears an NG mark to/from the clip being recorded or played.	Setting not retained
Clip Flag Keep	Adds/Clears a KP (Keep) mark to/from the clip being recorded or played.	Setting not retained
Focus Magnifier	Turns the focus magnification function on/off.	Setting not retained
Digital Extender x2	Turns the screen magnification (x2) function on/off.	Setting not retained
Digital Extender x3	Turns the screen magnification (x3) function on/off.	Setting not retained
Digital Extender x4	Turns the screen magnification (x4) function on/off.	Setting not retained
Digital Extender x2x3x4	Switches the magnification of the screen magnification function. Each press of the switch or button switches in the order Off → x2 → x3 → x4 → Off.	Setting not retained
Proxy Rec Start/Stop	Starts/stops proxy recording.	Setting not retained

User Configuration Data

You can save setup menu settings in the camcorder's internal memory and on SD cards. This allows you to quickly recall an appropriate set of menu settings for the current situation. To save setup data on an SD card, insert a writable SD card (page 32) into the UTILITY SD card slot before proceeding.

Inserting an SD card (for saving configuration data)

- 1 Open the switch cover.
- 2 Insert the SD card (for saving configuration data) in the UTILITY SD card slot.
- 3 Close the switch cover.

Ejecting an SD card (for saving configuration data)

- 1 Open the switch cover.
- 2 Press the SD card in slightly, then remove the card.

[Notes]

 - If the camcorder is turned off or the SD card is removed while the SD is being accessed, the integrity of data on the card cannot be guaranteed. All data recorded on the card may be discarded. Always make sure the ACCESS indicator is off before turning off the camcorder or removing the SD card.
 - Take caution to prevent the SD card from flying out when inserting/ejecting the card.

The following user data is supported.

User Files

User files save the setting items and data of the customizable User menu. You can save up to 64 files on an SD card. By loading this file into the camcorder memory, you can customize the setup of the User menu.

ALL Files

ALL files save the configuration data of all menus. You can save up to 64 files on an SD card.

[Note]
Device specific data (shading, output levels, and other data that requires adjustment for the specific device) is not saved.

Scene Files

Scene files save adjustments to Paint menu items for the purpose of shooting a particular scene. You can save up to five files in the camcorder's internal memory and up to 64 files on an SD card. Scene files allow you to save the following types of data.

- Values set in the Paint menu
- Shutter speeds set in standard mode or ECS mode
- White balance data

The data that is saved and loaded depends on the setting of File > Scene File > Scene White Data in the setup menu.

Scene files can be stored in internal memory on the camcorder or on an SD card. Scene files can also be loaded into the camcorder.

Reference Files

Reference files save the scene file standard settings (when File ID is Standard). You can save one file in the camcorder's internal memory and one file on an SD card.

Lens Files

You can set the following data for correcting for the lens characteristics, and save the data as a lens file. You can save up to 32 lens files in the camcorder's internal memory and up to 64 lens files on an SD card.

Configuration data		Sub-items
V modulation shading correction values		M V Modulation
Center marker position		Lens Center H Lens Center V
Flare level		R Flare G Flare B Flare
White balance correction value		White Offset R White Offset B
White shading correction value		Shading Ch Select Shading H SAW Shading H PARA Shading V SAW Shading V PARA

Gamma Files

You can save up to five user-defined gamma table data files (User Gamma Data File) in internal memory.

User Files

Saving a User File

- 1 Select File > User File > Save SD Card in the setup menu.
A screen for selecting a user file save destination appears.
- 2 Turn the MENU knob to select a destination, then press the knob.
You can save files in rows with a File ID of "No File." Selecting a row with a specified File ID name will overwrite the selected file.
The File ID is generated automatically, but you can modify it.
- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Changing the File ID

- 1 Select File > User File > File ID in the setup menu.
A screen for editing the File ID appears.
- 2 Select characters and enter the File ID.
- 3 Turn the MENU knob to select [Done], then press the knob.
The File ID is updated.

Loading a User File

- 1 Select File > User File > Load SD Card in the setup menu.
A user file list screen appears.
- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.
[Note]
The camcorder will reboot automatically after loading configuration data.

ALL Files

Saving Configuration Data as an ALL File

- 1 Select File >All File >Save SD Card in the setup menu.
A screen for selecting an ALL file save destination appears.
- 2 Turn the MENU knob to select a destination, then press the knob.
You can save files in rows with a File ID of “No File.” Selecting a row with a specified File ID name will overwrite the selected file.
The File ID is generated automatically, but you can modify it.

- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

If an error message appears

One of the following error messages may appear during execution of the save, or as soon as you select [Execute]. In this case, the file is not saved.

Error message	Problem	Solution
File Access NG	No recordable media is inserted.	Insert recordable media.

- 1 Select File >All File >File ID in the setup menu.
A screen for editing the File ID appears.
- 2 Select characters and enter the File ID.

Changing the File ID

- 3 Turn the MENU knob to select [Done], then press the knob.
The File ID is updated.

Loading Configuration Data

- 1 Select File >All File >Load SD Card in the setup menu.
An ALL file list screen appears.
- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.

- 3 Turn the MENU knob to select [Execute], then press the knob.

[Notes]

- When you load a file from an SD card, the data saved in the camcorder’s internal memory is overwritten.
- When loading files from one device to another, if the firmware versions on the two devices do not match, the setting values for functions that are not supported on the destination device are not loaded.
- The camcorder will reboot automatically after loading configuration data.

If an error message appears

One of the following error messages may appear during execution of the load, or as soon as you select [Execute]. In this case, the file is not loaded.

Error message	Problem	Solution
File Access NG	There is no readable media The specified file does not exist on the media	Insert the media that contains the file you want.

Restoring All Current Settings to Preset Values

In this document, initial setup menu settings configured/saved by the user are referred to as “preset values.”
Even after loading files to set up the camcorder, and overwriting original files with new settings, you can reset the contents of the files by recovering the preset values.

- 1 Select File >All File >All Preset in the setup menu.
A confirmation screen appears.

- 2 Turn the MENU knob to select [Execute], then press the knob.

Saving All Current Settings as Preset Values

- 1 Select File >All File >Store All Preset in the setup menu.
A confirmation screen appears.

- 2 Turn the MENU knob to select [Execute], then press the knob.

[Note]

The camcorder will reboot automatically after executing.

Resetting Current Settings and Preset Values to Factory Default Settings

- 1 Select File >All File >Clear All Preset in the setup menu.
A confirmation screen appears.

- 2 Turn the MENU knob to select [Execute], then press the knob.

[Note]

The camcorder will reboot automatically after executing.

Scene Files

Saving a Scene File in Internal Memory

- 1 Select File >Scene File >Store Internal Memory in the setup menu.
A scene file list screen appears.
If the File ID is set to "Standard" destination, preconfigured standard settings are saved.
- 2 Turn the MENU knob to select a destination, then press the knob.
The scene file is saved, overwriting any existing file, in the selected destination.
- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Saving a Scene File on an SD Card

- 1 Select File >Scene File >Save SD Card in the setup menu.
A scene file save destination screen appears.
- 2 Turn the MENU knob to select a destination, then press the knob.
You can save files in rows with a File ID of "No File." Selecting a row with a specified File ID name will overwrite the selected file.
The File ID is generated automatically, but you can modify it.
- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Changing the File ID

- 1 Select File >Scene File >File ID in the setup menu.
A screen for editing the File ID appears.
- 2 Select characters and enter the File ID.
- 3 Turn the MENU knob to select [Done], then press the knob.
The File ID is updated.

Loading a Scene File from Internal Memory

- 1 Select File >Scene File >Recall Internal Memory in the setup menu.
A scene file list screen appears.
- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Load a Scene File from an SD Card

- 1 Select File >Scene File >Load SD Card in the setup menu.
A scene file list screen appears.

- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Reference Files

Saving Current Settings as Preset Values

- 1

Select File >Reference File >Store Reference in the setup menu.
A confirmation screen appears.
- 2

Turn the MENU knob to select [Execute], then press the knob.

Loading a Reference File from an SD Card

- 1

Select File >Reference File >Load Reference(SD Card) in the setup menu.
A confirmation screen appears.
- 2

Turn the MENU knob to select [Execute], then press the knob.

Saving Current Settings as Preset Values on an SD Card

- 1

Select File >Reference File >Save Reference(SD Card) in the setup menu.
A confirmation screen appears.
- 2

Turn the MENU knob to select [Execute], then press the knob.

Resetting Current Settings and Preset Values to Factory Default Settings

- 1

Select File >Reference File >Clear Reference in the setup menu.
A confirmation screen appears.
- 2

Turn the MENU knob to select [Execute], then press the knob.

Changing the File ID

- 1

Select File >Reference File >File ID in the setup menu.
A screen for editing the File ID appears.
- 2

Select characters and enter the File ID.
- 3

Turn the MENU knob to select [Done], then press the knob.
The File ID is updated.

Lens Files

Saving a Lens File in Internal Memory

- 1 Select File >Lens File >Store Internal Memory in the setup menu.
A lens file list screen appears.
- 2 Turn the MENU knob to select a destination, then press the knob.
You can save files in rows with File ID of "No offset." Selecting a row with a specified File ID name will overwrite the selected file.
The File ID is generated automatically, but you can modify it.
- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Saving a Lens File on an SD Card

- 1 Select File >Lens File >Save SD Card in the setup menu.
A lens file save destination screen appears.
- 2 Turn the MENU knob to select a destination, then press the knob.
You can save files in rows with a File ID of "No File." Selecting a row with a specified File ID name will overwrite the selected file.
The File ID is generated automatically, but you can modify it.
- 3 Turn the MENU knob to select [Execute] on the confirmation message screen, then press the knob.

Changing the File ID

- 1 Select File >Lens File >File ID in the setup menu.
A screen for editing the File ID appears.
- 2 Select characters and enter the File ID.
- 3 Turn the MENU knob to select [Done], then press the knob.
The File ID is updated.

Loading a Lens File from Internal Memory

- 1 Select File >Lens File >Recall Internal Memory in the setup menu.
A lens file list screen appears.
- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Loading a Lens File from an SD Card

- 1 Select File >Lens File >Load SD Card in the setup menu.
A lens file list screen appears.

- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Loading a Lens File Automatically

When you are using a lens that supports serial communication, you can set up the camcorder by automatically loading the lens file that corresponds to the lens settings (Lens Auto Recall function).

To use the Lens Auto Recall function, set File >Lens File >Lens Auto Recall in the setup menu to one of the following.

- Off: Do not use the Lens Auto Recall function.
 - On (Lens Name): Load the lens file that corresponds to the lens model name.
 - On (Serial Number): Load the lens file that corresponds to the lens model name and serial number (when the lens supports communication of the serial number).
- If the lens does not support communication of the serial number, even when set to On (Serial Number), load the lens file that corresponds to the lens model name.

Gamma Files

Checking the Current Gamma File Settings (File Names)

Select File > User Gamma > Current Settings in the setup menu to display a list of the currently configured user gamma files.

Using User Gamma Files Created Using CvpFileEditorTM V4.3

Save created user gamma files to be loaded in the "PRIVATE/SONY/PRO/CAMERA/HD_CAM" directory of the SD card.

Loading a User Gamma File from an SD Card

- 1 Select File > User Gamma > Load SD Card in the setup menu.
A user gamma file list screen appears.
- 2 Turn the MENU knob to select a file to load, then press the knob.
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Resetting a User Gamma File to Initial State

- 1 Select File > User Gamma > Reset in the setup menu.
A gamma file number reset screen appears.
- 2 Turn the MENU knob to select the number of the gamma file to reset (1 to 5).
To reset all gamma files, select [All].
A confirmation screen appears.
- 3 Turn the MENU knob to select [Execute], then press the knob.

Connecting a Remote Control Unit

When an RM-B170 Remote Control Unit, RCP1001/1501 Remote Control Panel, or other control unit is connected, some camcorder functions can be controlled from that unit. You can use the display on the RM-B170 or a video monitor connected to the MONITOR connector of the remote control unit to perform camcorder menu operations and monitor the camcorder picture.

Connecting a Remote Control Unit

Using the remote control cable, connect between the REMOTE connector (8-pin) of the camcorder and the camera connector of the remote control unit.

When you turn on the camcorder after making the connection, the camcorder enters remote control mode, enabling menu operations and shooting operations.

[Notes]

- Remote control operation is not supported if USB connection to the camcorder is enabled.
- If a USB connection to the camcorder is enabled during remote control, remote control mode is released.
- Do not connect or disconnect the remote control unit when the camcorder is on.
- A remote control cable is not supplied with the RCP-1001/1501 Remote Control Unit.

The following switches of the camcorder are disabled when a remote control unit is connected.

- GAIN switch
- WHITE BAL switch
- AUTO W/B BAL switch
- SHUTTER switch
- OUTPUT/DCC switch
- ASSIGN. 1/3 switches, ASSIGNABLE 4/5 switches, and the ONLINE button to which the Turbo Gain or ATW function has been assigned

Releasing Remote Control Mode

Turn off the camcorder and disconnect the remote control unit.

The switch settings on the camcorder become enabled.

Connecting a Monitor to an RM-B170

The MONITOR connector (BNC type) of the RM-B170 outputs the same signal as the output from the VIDEO OUT connector.

To connect a monitor to the MONITOR connector on the RM-B170, use the black cable supplied with the RM-B170.

Image Quality Adjustment when an RM-B170 is Connected

When the RM-B170 is connected, the parameters for camera image quality adjustment items (paint data) are set to the parameters that were specified the last time that the RM-B170 was connected.

Function of Recording Start/Stop Buttons when an RM-B170 is Connected


Set the function of the buttons using Maintenance > Camera Config > RM Rec Start in the setup menu.

The functions of the buttons for the RM Rec Start settings are given below.

Button	RM Rec Start setting		
	RM	Camera	PARA
Camcorder REC START button	Disabled	Enabled	Enabled
Lens VTR button	Disabled	Enabled	Enabled
ASSIGN. 1/3 switches, ASSIGNABLE 4/5 switches, and ONLINE button assigned with recording start/stop function	Disabled	Enabled	Enabled
RM-B170 VTR button	Enabled	Disabled	Enabled

Data Structure of Image Quality Adjustment Data

The non-volatile memory of the camcorder used for storing camera image quality adjustment data (paint data) consists of the two regions shown below: a "main data block" that is used when a remote control unit is not connected, and a "remote control data block" that is used when a remote control unit is connected. Paint adjustment data is automatically selected and output to the camera section depending on whether or not a remote control unit, such as the RM-B170, is connected.



When a remote control unit is connected, the "remote control data block" is selected as the current paint data block, and the paint adjustment parameters that were in effect the last time the remote control unit was used are loaded.

However, when the settings of absolute value controls¹⁾ and absolute value switches²⁾ are set on the remote control unit, the settings on the remote control unit override the settings on the camcorder.

When the remote control unit is disconnected from the camcorder, the "main data block" is re-enabled, and the camcorder returns to the settings that were in effect before the remote control unit was connected.

- 1) Absolute value controls: Data corresponding to the angular position of the control is output. Controls for which data corresponding to the amount of rotation is output are called relative value controls.
- 2) Absolute value switches: Switches (or knobs), such as toggle switches or slide switches (except most momentary switches) whose positions must coincide with their functions are called absolute value switches.

When Maintenance > Camera Config > RM Common Memory in the setup menu is set to [On], you can use settings of the paint adjustment

data stored in the main data block even if a remote control unit is connected. In this case, the settings stored in the main data block will be updated when you change the settings on the remote control unit. Thus, the settings of the paint data made with the remote control unit will be retained even after the remote control unit is removed. However, if the switch position on the remote control unit differs from the one on the camcorder, the switch position on the camcorder takes precedence.

Also, it is possible to keep the settings that are in effect before you connect the remote control unit. In this case, you must set the control knobs to relative value mode on the remote control unit.

For details, refer to the operation manual supplied with the remote control unit.


Operating the Menu from the RM-B170

- 1 Set the DISPLAY switch to the MENU position. The menu is displayed on the monitor connected to the MONITOR connector of the RM-B170.
- 2 Select and set menu items using the MENU SELECT knob and CANCEL/ENTER switch.
- 3 When finished, set the DISPLAY switch to the ON or OFF position to exit the menu.

For details about RM-B170 operation, refer to the operation manual of the RM-B170.

Connecting an External Monitor

Select the output signal and use an appropriate cable for the monitor to be connected.



Regardless of whether the signal is HD or SD, the same status information and menus can be displayed on the external monitor as those on the viewfinder screen.

[Note]
The SD signal down-converted output is enabled when Operation >Input/Output >Output Format in the setup menu is set to 720X486i or 720X576i.

SDI OUT Connector (BNC)

The SDI OUT connector can be used to connect a device that supports SDI. The device type can be a monitor, switcher, VTR, or other recording device. The output signal from this connector can be turned on and off using Operation >Input/Output

>SDI Out1 Output/SDI Out2 Output in the setup menu (page 91).
For connection, use a BNC cable (not supplied).

VIDEO OUT Connector

The VIDEO OUT connector can be used to connect a device that supports analog composite signals. The device type can be a monitor, VTR, or other recording device. The output signal changes in conjunction with the setting of Operation >Input/Output >Output Format in the setup menu. To input the VIDEO OUT connector output signal to an external analog composite device, it may be necessary to change the input signal setting

of that external device to match the analog composite signal setting for the VIDEO OUT connector.

To input camcorder output audio to an external device such as a monitor, VTR, or other recording device, connect the audio output of the AUDIO OUT connector to the audio input of that external device.

For connection, use a BNC cable (not supplied).

HDMI OUT Connector (Type A Connector)

You can turn the output signal from the camcorder on/off using Operation >Input/Output >HDMI Output in the setup menu. The output signal format is set using Operation >Input/Output >Output Format in the setup menu. Use a commercially available HDMI cable for connection.


Managing/Editing Clips with a Computer

The clips recorded on SxS memory cards with this camcorder can be controlled on a computer or edited using optional nonlinear editing software. You can copy clips on SxS memory cards to portable storage or other USB media if portable media/USB media is connected to the external device connection connector.

USB Connection with a Computer

When you connect the camcorder to a computer using a USB cable (not supplied), the memory card in the slot is recognized as an extended drive by the computer.

When two memory cards are mounted in the camcorder, they are recognized as two independent extended drives by the computer.



- [Notes]
- Turn the camcorder on and wait until the image and information are displayed on the screen, then connect the USB cable to the camcorder.
 - When connecting the USB cable to the computer, be careful to check the form and direction of the USB connector.
 - The camcorder does not work on the bus power from the computer.

To start USB connection

When you connect a computer to the PC connector with a USB cable (not supplied), the message "Connect USB Now?" is displayed to prompt you to confirm that you wish to enable the USB connection.

If you select "Cancel" or push the MENU CANCEL/PRST/ESCAPE switch down to the ESCAPE position, or if you disconnect the USB cable, the message "Connect USB Now?" disappears.

If you select "Execute" and press the MENU knob, the USB connection is enabled and the camcorder is recognized as an extension drive.

If the USB connection is enabled during recording/playback operation, the operation is stopped and the message "USB Connecting" appears on the viewfinder screen.

At this time, the output signal from the VIDEO OUT connector and SDI OUT 1/2 connectors changes to a black signal.

- [Notes]
- The camcorder cannot be operated for recording, playback, and so on while the message "USB Connecting" is displayed.
 - When the computer accesses the media loaded in the camcorder, do not try to carry out the following operations.
 - Operating the camcorder (turning the power on/off, switching the operating mode, etc.)
 - Removing or loading a media from an active slot (being accessed from the computer)
 - Removing or connecting the USB cable

Releasing the USB connection

To release the USB connection, follow the same procedure as that for removing a device from the computer.

To enable the USB connection again, first disconnect the USB cable and then reconnect it. The message "Connect USB Now?" appears again.

To remove an SxS memory card

On Windows

- 1 Click on the "Safely Remove Hardware" icon on the task bar of the computer.
- 2 Select "Safely remove SxS Memory Card - Drive(X:)" from the displayed menu.
- 3 Check that the "Safe To Remove Hardware" message appears, then remove the card.

On Macintosh

Drag the SxS memory card icon on the desktop to the Trash.

If the SxS memory card icon is displayed in the Finder, click on the eject icon.

To use the application software

To copy clips to the local disk of your computer, the dedicated application software must be downloaded and installed on your computer. For details about downloading software, see "Software Downloads" (page 147).

Although the data regarding recorded materials are stored over multiple files and folders, you can easily handle the clips without considering such data and directory structure by using the dedicated application software.

[Note]

If you perform operations on clips, such as copying the clips on the SxS memory card using Explorer (Windows) or Finder (Macintosh), the subsidiary data contained by the clips may not be maintained.

To use a nonlinear editing system

In a nonlinear editing system, editing software (option) that supports the formats recorded by the camcorder is required.

Store the clips to be edited on the HDD of your computer in advance, using the supplied application software.

Some editing software may not operate properly. Be sure to confirm before use that it conforms to the recording formats used with this camcorder.

Connecting Portable Storage/USB Media

When portable storage, USB HDD, or similar media is connected to the external device connection connector, you can copy clips from the recording media inserted in an SxS card slot of the camcorder to USB media.

- 1 Specify the destination folder for copying clips in Operation > USB > Select Folder in the setup menu.
- You can also select [New] on the screen to create a new folder.
- [Note]
- If a folder is not specified, a folder is automatically created with a folder name the same as the creation date of the first clip to be copied, and clips are copied to that folder.

- 2 Select Operation > USB > Copy to USB in the setup menu.
 - 3 Select the slot in which the target recording media is inserted.
- Media(A) to USB: Copy all clips from the recording media inserted in slot A.
- Media(B) to USB: Copy all clips from the recording media inserted in slot B.
- Media(A)(B) to USB: Copy all clips from the recording media inserted in slot A and slot B.

[Note]

When a copy destination folder is specified in step 1 and Media(A)/(B) to USB is selected, slot A clips are copied to the specified destination folder. Slot B clips are copied to a folder that is automatically created with a folder name the same as the creation date of the first clip.

- 4 Turn the MENU knob to select [Execute], then press the knob.
All clips on the target recording media are copied to the USB media.

[Note]

If a clip with the same file name as the clip to copy already exists in the destination folder, the clip is not copied.

Displaying a list of clips on portable storage/USB media

You can display a list of the clips on portable storage/USB media using Operation > USB > View Clip List in the setup menu.

Renaming a folder on portable storage/USB media

You can rename a folder using Operation > USB > Rename Folder in the setup menu.

- 1 Select Operation > USB > Rename Folder in the setup menu.
- 2 Select the folder to rename, and press the SET button.
A file name input screen appears.
- 3 Enter a folder name, and select [Done] on the screen.
The folder is renamed.

Checking for copy read errors

You can check for read errors after writing clips by setting Operation > USB > Error Check in the setup menu to On.

Formatting portable storage/USB media

You can format portable storage/USB media in exFAT format using Operation > USB > Format USB in the setup menu.

- 1 Select Operation > USB > Format USB in the setup menu.
- 2 Turn the MENU knob to select [Execute], then press the knob.
Initialization (formatting) begins.
- 3 When the formatting is completed, a message appears on the screen. Select [OK].

Checking free space on portable storage/USB media

The free space on portable storage/USB media is displayed in the Media Remain row on the screen displayed when Operation > USB in the setup menu is selected.

About power supply to portable storage/USB media

Power is supplied to portable storage/USB media from the external device connector automatically when performing an operation in Operation > USB in the setup menu.
However, power supply is not started under the following conditions, even when performing an operation in Operation > USB in the setup menu.
To start the supply of power, perform the solution shown in the table.

State	Solution
During clip recording, playback, thumbnail display, proxy recording, streaming, proxy transfer, or live transfer mode	Terminate the previous operation.
Network Client Mode is On	Set Network Client Mode to Off.
Media adaptor is connected	Unmount the media adaptor connection.

[Notes]

- Clips on portable storage or other USB media cannot be copied to recording media inserted in an SxS card slot.
- Clips cannot be recorded while power is supplied to the external device connector. To start recording clips, terminate the Operation > USB operation in the setup menu.

Configuring a Shooting and Recording System

You can mount a CA-FB70/TX70 HD Camera Adaptor to the camcorder and connect a Camera Control Unit (CCU).

This allows you to configure a shooting and recording system consisting of multiple camcorders with camera extension units connected to a remote control unit.

For more information about the CA-FB70 and CA-TX70, refer to their respective operation manuals.

[Notes]

- When using the camcorder in this system, do not connect a video light to the camcorder.
- Supported only for XAVC and MPEG HD recording.
- Not supported for proxy recording and wireless LAN connection function.

Tally and Call Indicators

The tally and call indicators for a system are as follows.

Data received from system				HDVF LED indicators		Text display on viewfinder screen	
Tally	Green Tally	CA call	Non-CA call	REC/ TALLY LED	GREEN TALLY LED		 CALL
OFF	OFF	OFF	OFF	Not lit	Not lit	No display	No display
OFF	OFF	OFF	ON	Lit	Not lit		No display CALL
OFF	OFF	ON	OFF	Not lit	Not lit	No display	No display CALL
OFF	OFF	ON	ON	Lit	Not lit		No display CALL
OFF	ON	OFF	OFF	Not lit	Lit	No display	 No display
OFF	ON	OFF	ON	Lit	Lit		 CALL
OFF	ON	ON	OFF	Not lit	Lit	No display	 CALL
OFF	ON	ON	ON	Lit	Lit		 CALL
ON	OFF	OFF	OFF	Lit	Not lit		No display
ON	OFF	OFF	ON	Not lit	Not lit	No display	No display CALL
ON	OFF	ON	OFF	Lit	Not lit		No display CALL
ON	OFF	ON	ON	Not lit	Not lit	No display	No display CALL
ON	ON	OFF	OFF	Lit	Lit		No display
ON	ON	OFF	ON	Not lit	Lit	No display	 CALL
ON	ON	ON	OFF	Lit	Lit		 CALL
ON	ON	ON	ON	Not lit	Lit	No display	 CALL

[Note]
Alarm indications using the tally indicator in the warning display are not displayed while a CA-FB70/TX70 Camera Adaptor is connected.

Supported Formats and Limitations of Shooting/Recording Systems

The supported formats and operation limitations of a shooting/recording system comprising the camcorder, camera adaptor, and camera control unit are shown in the following table.

Operation menu		System format of camera adaptor / camera control unit		Camcorder limitation
Format		Input/Output		Return video display
Frequency	Rec Format	Output Format		
		SDI		
59.94	XAVC-I 1920×1080P	1920×1080i	1920×1080 59.94i	No
	XAVC-L 50 1920×1080P			
	XAVC-L 35 1080P			
	XAVC-I 1920×1080i	1920×1080i	1920×1080 59.94i	Yes
	XAVC-L 50 1920×1080i			
	XAVC-L 35 1080i			
	XAVC-L 25 1080i			
	HD422 50 1080i			
	HQ 1920×1080i			
	HQ 1440×1080i			
29.97	XAVC-I 1280×720P	1280×720P	1280×720 59.94P	Yes
	XAVC-L 50 1280×720P			
	HD422 50 720P			
	HQ 1280×720P			
	XAVC-I 1920×1080P	1920×1080PsF	1920×1080 29.97PsF ^{a)}	Yes
	XAVC-L 50 1920×1080P		1920×1080 59.94i	
	XAVC-L 35 1080P			
	HD422 50 1080P			
	HQ 1920×1080P			
	HD422 50 720P	1280×720P	1280×720 59.94P	No
23.98	XAVC-I 1920×1080P	1920×1080i	1920×1080 59.94i	No
	XAVC-L 50 1920×1080P	(2-3PD)		
	XAVC-L 35 1080P			
	HD422 50 1080P			
	HQ 1920×1080P			
	HD422 50 720P	1280×720P	1280×720 59.94P	No
		(2-3PD)		

Operation menu		System format of camera adaptor / camera control unit	Camcorder limitation
Format		Input/Output	Return video display
Frequency	Rec Format	Output Format	
SDI			

50	XAVC-I 1920×1080P	1920×1080i	1920×1080 50i	No
	XAVC-L 50 1920×1080P			
	XAVC-L 35 1080P			
	XAVC-I 1920×1080i	1920×1080i	1920×1080 50i	Yes
	XAVC-L 50 1920×1080i			
	XAVC-L 35 1080i			
	XAVC-L 25 1080i			
	HD422 50 1080i			
	HQ 1920×1080i			
	HQ 1440×1080i			
25	XAVC-I 1280×720P	1280×720P	1280×720 50P	Yes
	XAVC-L 50 1280×720P			
	HD422 50 720P			
	HQ 1280×720P			
	XAVC-I 1920×1080P	1920×1080PsF	1920×1080 25PsF ^{a)}	Yes
	XAVC-L 50 1920×1080P		1920×1080 50i	
	XAVC-L 35 1080P			
	HD422 50 1080P			
	HQ 1920×1080P			
	HD422 50 720P	1280×720P	1280×720 50P	No

a) A PsF setting is recommended when a CA-TX70 Camera Adaptor is connected.

[Note]
In a shooting/recording system, special recording functions, such as wireless LAN connection function or Slow & Quick Motion, cannot be used simultaneously.

Recording External Input Signals

You can record SDI signals from devices connected to the SDI IN connector of the camcorder.

To output and record input signals instead of the camera picture, set Operation >Input/Output >Source Select in the setup menu to [External].

[Notes]

- External input signals cannot be recorded in Slow & Quick Motion mode. When a special recording mode, such as Slow & Quick Motion mode, is selected, the recording mode is canceled when you set Operation >Input/Output >Source Select in the setup menu to [External].
- Execution of automatic adjustment functions, such as automatic black balance, and operations, such as playback, Rec Review, and thumbnail display, will end when Operation >Input/Output >Source Select in the setup menu is set to [External]. The camcorder enters stop mode and then the camera picture switches to external input.
- Recording may stop if the input signal is disturbed while recording external input. Recording automatically resumes when the input signal returns to normal.
- Not supported for proxy recording and wireless LAN connection function.

Supported External Input Signal Formats and Camcorder Recording Formats

HD/SD	Operation >Format >Rec Format in the setup menu	Operation >Format >Frequency in the setup menu	Supported external input signal formats
HD	XAVC-I 1920×1080i	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	XAVC-I 1280×720P	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	XAVC-L 50 1920×1080i	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	XAVC-L 50 1280×720P	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i

HD/SD	Operation >Format >Rec Format in the setup menu	Operation >Format >Frequency in the setup menu	Supported external input signal formats
HD	HD422 50 720P	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	HQ 1920×1080i	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	HQ 1440×1080i	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
	HQ 1280×720P	59.94	HD 1920×1080 29.97PsF/59.94i
			HD 1280×720 59.94P
		50	HD 1920×1080 25PsF/50i
SD	MPEG IMX 50	59.94	SD 486 59.94i
			SD 576 50i
		50	SD 486 59.94i
	DV/CAM	59.94	SD 486 59.94i
			SD 576 50i
		50	SD 576 50i

Maintenance

Cleaning the Viewfinder

Use a dust blower to clean the CRT screen and mirror inside the viewfinder barrel.
Clean the lens and protecting filter with a commercially available lens cleaner.

[Note]

Never use organic solvents such as thinners.

Note about the Battery Terminals

The battery terminal of this unit (the connector for battery packs and AC adaptors) is a consumable part.

Power may not be supplied to the unit properly if the pins of the battery terminal are bent or deformed by shock or vibrations, or if they become corroded due to prolonged outdoor use.

Periodic inspections are recommended to keep the unit working properly and to prolong its usable lifetime.

Contact a Sony service or sales representative for more information about inspections.

Exchanging the Battery of the Internal Clock

The camcorder's internal clock is powered by a lithium battery. If the message "Backup Battery End" appears in the viewfinder, this battery must be exchanged. Contact a Sony service representative.

Error/Warning System

If a warning, caution, or operating condition that requires confirmation occurs on the camcorder, a message is displayed in the viewfinder, the corresponding indicators start flashing, and a warning sound is emitted. You can adjust the volume of the warning sound using the ALARM knob. If the ALARM knob is set to minimum, the warning sound will not be audible.

Error Display

The camcorder will stop operation when the following kind of display occurs.

Error message	Warning sound	WARNING indicator	Tally/REC indicator	Cause and Solution
E + error code	Continuous	—	High-speed flashing	Indicates an abnormality in the camcorder. Turn off the camcorder, and check for any problem with connected devices, cables, or media. (If the camcorder does not turn off when the POWER switch is set to OFF, remove the battery or disconnect the AC supply.) If the error persists when the camcorder is turned on again, contact your Sony service representative.

Warning Display

Follow the instructions provided if the following display occurs.

Warning message	Warning sound	WARNING indicator	Tally/REC indicator	Cause and Solution
Media Near Full	Intermittent	Flashing	Flashing	The remaining capacity on the SxS memory card is getting low. Replace at the earliest convenience.
Media Full	Continuous	On	High-speed flashing	Clips could not be recorded, copied, or split because there is no remaining capacity on the SxS memory card. Replace immediately.
Battery Near End	Intermittent	Flashing	Flashing	The remaining capacity of the battery pack is getting low. Recharge at the earliest convenience. (The battery indicator flashes in the viewfinder.)
Battery End	Continuous	On	High-speed flashing	The battery pack is dead. Recording is disabled. Connect a power source to DC IN and allow the battery pack to recharge without attempting to operate the camcorder. (The battery indicator flashes in the viewfinder.)
Temperature High	Intermittent	Flashing	Flashing	The internal temperature is high. Turn off the camcorder and allow it to cool down before operating it again.
Voltage Low	Intermittent	Flashing	Flashing	The DC IN voltage is low (level 1). Check the power source.
Insufficient Voltage	Continuous	On	High-speed flashing	The DC IN voltage is too low (level 2). Recording is disabled. Connect a different power source. (The battery indicator flashes in the viewfinder.)

Warning message	Warning sound	WARNING indicator	Tally/REC indicator	Cause and Solution
Clips Full	Continuous	On	High-speed flashing	The maximum number of clips that can be recorded on an SxS memory card has been reached. Recording or copying more clips is not possible. Replace immediately.
Last Clip Recording	Intermittent	Flashing	Flashing	The clip currently recording is the last clip that can be recorded, as the maximum number of clips has been reached. Prepare a new SxS memory card.
Clips Near Full	Intermittent	Flashing	Flashing	The number of additional clips that can be recorded on the SxS memory card is getting low. Replace at the earliest convenience.
Media(A) ¹⁾ Full	Continuous	On	High-speed flashing	Proxy data cannot be recorded because there is no remaining free space on the proxy data SD card. Replace immediately.
Clips(Proxy) Full	Continuous	On	High-speed flashing	The maximum number of clips that can be recorded on the proxy data SD card has been reached. Recording more clips is not possible. Replace immediately.
Media(Proxy) Near Full	Intermittent	Flashing	Flashing	The remaining free space on the proxy data SD card is getting low. Replace at the earliest convenience.
Last Clip(Proxy) Rec	Intermittent	Flashing	Flashing	The proxy data currently recording is the last clip that can be recorded, as the maximum number of clips has been reached. Prepare a new proxy data SD card.
Clips(Proxy) Near Full	Intermittent	Flashing	Flashing	The number of additional clips that can be recorded on the proxy data SD card is getting low. Replace at the earliest convenience.
Media(A) ¹⁾ Full	Continuous	On	High-speed flashing	When using the simultaneous recording function
Media(A) ¹⁾ Clips Full	Continuous	On	High-speed flashing	When using the simultaneous recording function
Media(A) ¹⁾ Near Full	Intermittent	Flashing	Flashing	When using the simultaneous recording function
Media(A) ¹⁾ Last Clip Rec	Intermittent	Flashing	Flashing	When using the simultaneous recording function

1) "(B)" is displayed for cards in slot B.

Caution and Operation Confirmation Display

The following caution and operation messages may appear in the center of the screen. Follow the instructions provided to resolve the issue.

Display indication	Cause and Solution
Battery Error Please Change Battery	An error was detected in the battery pack. Replace with a normal battery pack.
Backup Battery End Please Change	The remaining capacity of the backup battery is insufficient. Replace the backup battery.
Unknown Media(A) ¹⁾ Please Change	A memory card that has been partitioned or a memory card containing more clips that can be handled by the camcorder was inserted. The card cannot be used in the camcorder, and must be replaced.
Media Error Media(A) ¹⁾ Needs to be Restored	An error occurred on the memory card, and the card must be restored. Eject and then re-insert the card, then repair the card.
Media Error Cannot Record to Media(A) ¹⁾	The memory card may be damaged, and can no longer be used for recording. Playback may be possible, so making a copy and replacing the memory card is recommended.
Media Error Cannot Use Media(A) ¹⁾	The memory card may be damaged, and can no longer be used for recording or playback. The card cannot be used in the camcorder, and must be replaced.
Cannot Use Media(A) ¹⁾ Unsupported File System	A card using a different file system or an unformatted card was inserted. The card cannot be used in the camcorder, and must be replaced or formatted using the camcorder.
Media(A) ¹⁾ Error Playback Halted	Cannot continue playback because an error occurred while reading from the memory card. If the problem persists, make a copy and replace the memory card.
Media(A) ¹⁾ Error	Recording is stopped because an error occurred on the memory card. If the problem persists, replace the memory card.
Different Media is Inserted Cannot Use Media(A) ¹⁾	Different media was inserted. Eject the inserted card, and insert a card of the same type as the previously inserted card.

1) “(B)” is displayed for cards in slot B.

Messages Displayed During Operation

This section describes the meaning of messages that may be displayed in response to button, switch, or knob operation.

[Notes]

- Covers only the messages displayed about possible causes in response to an operation.
- Messages displayed when an operation is attempted while a menu item cannot be selected (grayed out) are not described.

Operation	Message	Meaning and possible cause
REC button was pressed	Media not exist	Cannot record because there is no recording media in an SxS card slot.
	Media(Proxy)	Proxy data recording mode is set to On, but cannot record proxy data because the proxy SD card is not inserted.
	Cannot Record	
	No Media in Slot(Proxy)	
	Media(Proxy)	Cannot record proxy data because cannot write to the proxy SD card due to a media error.
	Cannot Record	
	Media(Proxy) Error	Cannot record proxy data because the proxy SD card is write-protected.
	Media(Proxy)	
	Cannot Record	
	Media(Proxy): Write Protected	
Assignable switch assigned with Proxy Rec Start/Stop was operated	Media(Proxy)	Cannot record proxy data because the proxy data recording circuitry initialization is not completed.
	Cannot Record	
	NG: Preparing	
	Media(Proxy)	Cannot record proxy data because the proxy SD card is not inserted.
	Cannot Record	
	No Media in Slot(Proxy)	
	Media(Proxy)	Cannot record proxy data because cannot write to the proxy SD card due to a media error.
	Cannot Record	
	Media(Proxy) Error	
	Media(Proxy)	Cannot record proxy data because the proxy SD card is write-protected.
	Cannot Record	
	Media(Proxy): Write Protected	
	Media(Proxy)	Cannot record proxy data because the proxy data recording circuitry initialization is not completed.
	Cannot Record	
	NG: Preparing	
	First Clip Top!	Cannot execute because the playback position is at the first frame of the first clip.
	First Clip Top!	Cannot execute because the playback position is at the first frame of the first clip.
	First Clip Top!	Cannot execute because the playback position is at the first frame of the first clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
	Last Clip End!	Cannot execute because the playback position is at the last frame of the last clip.
Media slot was changed	Cannot Switch Slots	Cannot change slots during playback.
Recording media was removed	Media removed	Media was removing while reading from recording media or while writing to recording media (ACCESS indicator is lit).

Operation	Message	Meaning and possible cause
GAIN switch was operated	Gain: xxxxxdB (where "xxxx" is the gain value)	Gain setting was changed.
	DCC: On	DCC was set to On.
	DCC: Off	DCC was set to Off.
DCC switch was operated	Fixed By Hyper Gamma I	Cannot set DCC to On because Gamma Category is set to HG or User.
White balance switch was operated	White: Preset xxxxx (where "xxxx" is the color temperature value)	White balance was changed to the preset value.
	White: A xxxxx (where "xxxx" is the color temperature value)	White balance was changed to the memory A value.
	White: B xxxxx (where "xxxx" is the color temperature value)	White balance was changed to the memory B value.
	White: ATW xxxxx (where "xxxx" is the color temperature value)	White balance mode was changed to ATW.
	SHUTTER switch was operated	
	Shutter: 1/xxxx (where "xxxx" is the shutter value)	Shutter speed was changed (standard, Speed mode settings).
Menu knob was turned	Shutter: xxxxx (where "xxxx" is the shutter value)	Shutter speed was changed (standard, Angle mode settings).
	ECS: xxxxxHz (where "xxxx" is the frequency value)	Shutter speed was changed (ECS mode).
	ECS: xxxxxHz (where "xxxx" is the frequency value)	Shutter speed was changed (ECS mode).
	Iris Override: +xxxx (where "x.xx" is a numeric value)	Iris override level was changed.
	Color Bars Cannot Proceed	Cannot execute because a color bar signal is being output.
Auto black switch was operated	Test Saw Cannot Proceed	Cannot execute because a test signal is being output.
	Not Available Recording	Cannot execute because recording is in progress.
	Not Available Playing back	Cannot execute because playback is in progress.
	Not Available Displaying Thumbnails	Cannot execute because the thumbnail screen is displayed.

Operation	Message	Meaning and possible cause
Auto white switch was operated	Color Bars	Cannot execute because a color bar signal is being output.
	Cannot Proceed	
	Not Available	Cannot execute because playback is in progress.
	Playing back	
	Not Available	Cannot execute because the thumbnail screen is displayed.
	Displaying Thumbnails	
	White Balance Preset	Cannot execute because the white balance is set to the preset value.
	ATW Hold	ATW Hold function was enabled.
Assignable switch assigned with ATW Hold function was operated	ATW Hold Off	ATW Hold function was disabled.
Assignable switch assigned with Clip Continuous Rec was operated	Cannot Proceed Recording	Cannot execute because recording is in progress.
	Cannot Proceed	Cannot execute because a CA-FB70/TX70 Camera Adaptor is connected to the CCU.
Assignable switch assigned with Picture Cache Rec was operated	Cannot Proceed Recording	Cannot execute because recording is in progress.
	Cannot Proceed	Cannot execute because of the following conditions. • Playback is in progress • Thumbnail screen is displayed • CA-FB70/TX70 Camera Adaptor is connected to the CCU.
Assignable switch assigned with Streaming was operated	Cannot Proceed	Cannot execute because network client mode is enabled.
	Network Client Mode Setting is "On"	
	Cannot Proceed	Cannot execute because network connection setting is set to Off.
	Network Function is Disabled	
	Cannot Proceed	Network client mode is set to On, but cannot execute because network connection is unavailable.
	Network Client Mode Setting is "On"	
	Network Function is Disabled	
	Cannot Start Streaming	Cannot execute because of the following conditions. • Proxy data playback is in progress • 1280×720 clip playback is in progress with recording format set to 1920×1080 • 1920×1080 clip playback is in progress with recording format set to 1280×720
	Streaming Disabled Temporarily	
	Cannot Start Streaming	Cannot execute because recording/playback was started while wireless function circuitry was initializing (including thumbnail display).
	Please stop Recording or Playback	Stop recording/playback (including thumbnail display) to enable execution.

Operation	Message	Meaning and possible cause
Assignable switch assigned with Streaming was operated while network client mode is enabled	Cannot Proceed Streaming Setting is "On"	Cannot configure because streaming is in progress.
	Cannot Connect to CCM Network Function is Disabled	Cannot connect to Connection Control Manager because network connection is unavailable.
	Cannot Record Proxy	Cannot record proxy data, when proxy data recording is started, because Maintenance >Network Client Mode >Detail Settings >NCM with Proxy in the setup menu is set to Disable.
	Proxy Recording will be Stopped	Proxy data recording will stop because Maintenance >Network Client Mode >Detail Settings >NCM with Proxy in the setup menu is set to Disable.
	Cannot Connect to CCM Cannot Record Proxy	• Cannot connect to Connection Control Manager because network connection is unavailable. • Cannot record proxy data, when proxy data recording is started, because Maintenance >Network Client Mode >Detail Settings >NCM with Proxy in the setup menu is set to Disable.
	Cannot Connect to CCM Proxy Recording will be Stopped	• Cannot connect to Connection Control Manager because network connection is unavailable. • Proxy data recording will stop because Maintenance >Network Client Mode >Detail Settings >NCM with Proxy in the setup menu is set to Disable.
	Cannot Connect to CCM Invalid User Name or Password	Connection Control Manager authentication error occurred.
	Cannot Connect to CCM Invalid Address or Port Number	Cannot connect to Connection Control Manager because the Connection Control Manager address or port number settings is incorrect.
	Assignable switch assigned with Auto Upload(Proxy) was operated	Cannot execute because proxy data recording circuitry and wireless function circuitry initialization are not completed.
	Cannot Proceed Network Function is Disabled	Cannot execute because wireless function circuitry is switching mode or power supply is switching off.
ONLINE button was pressed and held	Cannot Proceed	Cannot execute because wireless function circuitry is switching mode or power supply is switching off.
	Zebra: On	Zebra was set to On.
	Zebra: Off	Zebra was set to Off.
Assignable switch assigned with Zebra was operated or ZEBRA switch on viewfinder was changed	Zebra: On	Zebra was set to On.
	Zebra: Off	Zebra was set to Off.
ZEBRA switch on viewfinder was operated	Zebra: On	Zebra was set to On.
	Zebra: Off	Zebra was set to Off.
Assignable switch assigned with Master was operated	Marker: On	Marker was set to On.
	Marker: Off	Marker was set to Off.
Assignable switch assigned with Peaking was operated	Peaking: On	Peaking was set to On.
	Peaking: Off	Peaking was set to Off.
Assignable switch assigned with Video Signal Monitor was operated	Cannot Proceed	Cannot execute because of the following conditions. • Operation >Input/Output >SDI Out1 Select in the setup menu are both set to Off • Operation >Input/Output >Output Format in the setup menu is set to 720x480P or 720x576P
OUTPUT switch was moved to the BARS position (color bar display)	Not Available S&Q Motion: On	Cannot execute because S&Q motion recording mode is enabled.
Assignable switch assigned with digital extender was operated	Cannot Proceed	Cannot execute because of the following conditions. • Playback is in progress • Thumbnail screen is displayed • External input state • Color bars or test signal output is in progress

Operation	Message	Meaning and possible cause
ND filter was changed	2: 1/4ND xxxxx (where "2: 1/4ND" is the ND filter type and "xxxx" is the color temperature value)	ND filter was changed.
	ND3 CC: x xxxx (where "ND: 3" is the selected ND filter type and "CC: x xxx" is the selected CC filter and color temperature value after electrical color temperature conversion)	ND filter was changed with ND Filter C.Temp set to Off and Electrical CC assigned to an assignable switch.
Assignable switch assigned with Color Temp SW 3200K was operated	Color Temp SW 3200K Cannot Proceed ND Filter C.Temp: On	Color Temp SW 3200K was enabled. Cannot change because ND Filter C.Temp is set to On.
Assignable switch assigned with Color Temp SW 4300K was operated	Color Temp SW 4300K Cannot Proceed ND Filter C.Temp: On	Color Temp SW 4300K was enabled. Cannot change because ND Filter C.Temp is set to On.
Assignable switch assigned with Color Temp SW 5600K was operated	Color Temp SW 5600K Cannot Proceed ND Filter C.Temp: On	Color Temp SW 5600K was enabled. Cannot change because ND Filter C.Temp is set to On.
Assignable switch assigned with Color Temp SW 6300K was operated	Color Temp SW 6300K Cannot Proceed ND Filter C.Temp: On	Color Temp SW 6300K was enabled. Cannot change because ND Filter C.Temp is set to On.
Assignable switch assigned with Electrical CC was operated	ND3 CC: x xxxx (where "ND: 3" is the selected ND filter type and "CC: x xxx" is the selected CC filter and color temperature value after electrical color temperature conversion)	Electrical CC filter was changed.
	Cannot Proceed	Cannot change because ND Filter C.Temp is set to On.
Assignable switch assigned with CC5600K was operated	CC 5600K Cannot Proceed	5600K setting was selected. Cannot execute because of the following conditions: • ND Filter C.Temp is set to On • Electrical CC is assigned to an assignable switch, but 5600K is not assigned to Electrical CC.
Assignable switch assigned with Shot Mark1 was operated	Shot Mark1 (arbitrary character string when defining planning metadata)	Shot mark 1 was added.
	Cannot Record Essence Mark Reached Essence Mark Limit Cannot Proceed	Cannot add because the maximum number of essence marks has been reached. Cannot add because of the following conditions: • Cannot write because the media on which to record clips is write-protected • Picture Cache Rec function is set to On • Interval Rec recording is in progress • Media is write-protected • Target clip is recorded on an SDXC card

Operation	Message	Meaning and possible cause
Assignable switch assigned with Shot Mark2 was operated	Shot Mark2 (arbitrary character string when defining planning metadata)	Shot mark 2 was added.
	Cannot Record Essence Mark Reached Essence Mark Limit	Cannot add because the maximum number of essence marks has been reached.
	Cannot Proceed	Cannot add because of the following conditions. • Cannot write because the media on which to record clips is write-protected • Picture Cache Rec function is set to On • Interval Rec recording is in progress • Media is write-protected • Target clip is recorded on an SDXC card
Assignable switch assigned with Clip Flag OK was operated	OK Clip Flag	Clip flag (OK mark) was added.
	Delete Clip Flag	Clip flag (OK mark) was deleted (by pressing the switch twice).
Assignable switch assigned with Clip Flag NG was operated	Cannot Proceed	Cannot execute because of the following conditions. • Media is write-protected • Target clip is recorded on an SDXC card
	NG Clip Flag	Clip flag (NG mark) was added.
	Delete Clip Flag	Clip flag (NG mark) was deleted (by pressing the switch twice).
Assignable switch assigned with Clip Flag Keep was operated	Cannot Proceed	Cannot execute because of the following conditions. • Media is write-protected • Target clip is recorded on an SDXC card
	KEEP Clip Flag	Clip flag (KEEP mark) was added.
	Delete Clip Flag	Clip flag (KEEP mark) was deleted (by pressing the switch twice).
Assignable switch assigned with Flash Band Reduce was operated	Flash Band Reduce: On	Flash Band Reduce was set to On.
	Flash Band Reduce: Off	Flash Band Reduce was set to Off.
SLOT SELECT button was operated	Switched Slot	Recording media to use was changed.

Usage Precautions

The fan and battery are consumable parts that will need periodic replacement.

When operating at room temperature, a normal replacement cycle will be about 5 years.

However, this replacement cycle represents only a general guideline and does not imply that the life expectancy of these parts is guaranteed. For details on parts replacement, contact your dealer.

The life expectancy of the AC adaptor and the electrolytic capacitor is about 5 years under normal operating temperatures and normal usage (8 hours per day; 25 days per month). If usage exceeds the above normal usage frequency, the life expectancy may be reduced correspondingly.

Use and storage

Do not subject the camcorder to severe shocks

- The internal mechanism may be damaged or the body warped.
- If an accessory mounted on the accessory shoe is subjected to severe shock, the accessory shoe may be damaged. In such a case, stop using it and contact your dealer or a Sony service representative.

Do not cover the camcorder while operating

Putting a cloth, for example, over the camcorder can cause excessive internal heat build-up.

After use

Always turn off the POWER switch.

Before storing the camcorder for a long period

Remove the battery pack.

Shipping

- Remove the media before transporting the camcorder.

- If sending the camcorder by truck, ship, air, or other transportation service, pack it in the shipping carton of the camcorder.

Care of the camcorder

Remove dust and dirt from the surfaces of the lenses or optical filters using a blower.

Do not attempt to clean the interior of the camera using a blower. Any dust particles in the air that enter components may cause a malfunction.

If the body of the camcorder is dirty, clean it with a soft, dry cloth. In extreme cases, use a cloth moistened in a little neutral detergent, then wipe dry. Do not use organic solvents such as alcohol or thinners, as these may cause discoloration or other damage to the finish of the camcorder.

In the event of operating problems

If you should experience problems with the camcorder, contact a Sony service representative.

Use and storage locations

Store in a level, ventilated place. Avoid using or storing the camcorder in the following places.

- In excessive heat or cold (operating temperature range: -5 °C to +40 °C (23 °F to 104 °F)) Remember that in summer in warm climates the temperature inside a car with the windows closed can easily exceed 50 °C (122 °F).
- In damp or dusty locations
- Locations where the camcorder may be exposed to rain
- Locations subject to violent vibration
- Near strong magnetic fields
- Close to radio or TV transmitters producing strong electromagnetic fields.
- In direct sunlight or close to heaters for extended periods

To prevent electromagnetic interference from portable communications devices

The use of portable telephones and other communications devices near this camcorder can result in malfunction and interference with audio and video signals.

It is recommended that the portable communications devices near this camcorder be powered off.

Condensation

If the unit is suddenly taken from a cold to a warm location, or if ambient temperature suddenly rises, moisture may form on the outer surface of the unit and/or inside of the unit. This is known as condensation. If condensation occurs, turn off the unit and wait until the condensation clears before operating the unit. Operating the unit while condensation is present may damage the unit.

Fitting the zoom lens

It is important to fit the lens correctly, as otherwise damage may result. Be sure to refer to the section "Mounting and Adjusting the Lens" (page 26).

Viewfinder

Do not leave the camcorder with the eyepiece lens pointing directly at the sun. The eyepiece lens can concentrate the sun's rays and melt the interior of the viewfinder.

About the LCD panels

The LCD panel fitted to this unit is manufactured with high precision technology, giving a functioning pixel ratio of at least 99.99%. Thus a very small proportion of pixels may be "stuck", either always off (black), always on (red, green, or blue), or flashing. In addition, over a long period of use, because of the physical characteristics of the liquid crystal display, such "stuck" pixels may

appear spontaneously. These problems are not a malfunction. Note that any such problems have no effect on recorded data.

Phenomena specific to CMOS image sensors

The following phenomena that may appear in images are specific to CMOS (Complementary Metal Oxide Semiconductor) image sensors. They do not indicate malfunctions.

White flecks

Although the CMOS image sensors are produced with high-precision technologies, fine white flecks may be generated on the screen in rare cases, caused by cosmic rays, etc. This is related to the principle of CMOS image sensors and is not a malfunction.

The white flecks especially tend to be seen in the following cases:

- when operating at a high environmental temperature
 - when you have raised the master gain (sensitivity)
 - when operating in Slow-Shutter mode
- The problem may be alleviated by executing automatic black balance adjustment.

Aliasing

When fine patterns, stripes, or lines are shot, they may appear jagged or flicker.

Flicker

If recording is made under lighting produced by discharge tubes, such as fluorescent, sodium, or mercury-vapor lamps, the screen may flicker, colors may vary, or horizontal stripes may appear distorted.



In such cases, set the flicker-reduction function to auto mode (page 108).

If the frame rate selected for recording is close to the power-supply frequency, flicker may not be reduced sufficiently even if you activate the Flicker-Reduction function. In such cases, use the electronic shutter.

Focal plane

Owing to the characteristics of the pickup elements (CMOS image sensors) for reading video signals, subjects that quickly move across the screen may appear slightly skewed.

Flashband

The luminance at the top and bottom of the screen may change when shooting a flashlight beam or a light source that quickly flashes. You can use the supplied application software to correct clips that contain frames with flash bands.

Fragmentation

If pictures cannot be recorded/reproduced properly, try formatting the recording media. While repeating picture recording/playback with a certain recording media for an extended period, files in the media may be fragmented, disabling proper recording/storage. In such a case, make a backup of clips in the media then perform formatting of the media using Operation >Format Media (page 91) in the setup menu.

Notes on security

- SONY WILL NOT BE LIABLE FOR DAMAGES OF ANY KIND RESULTING FROM A FAILURE TO IMPLEMENT PROPER SECURITY MEASURES ON TRANSMISSION DEVICES, UNAVOIDABLE DATA LEAKS RESULTING FROM TRANSMISSION SPECIFICATIONS, OR SECURITY PROBLEMS OF ANY KIND.
- Depending on the operating environment, unauthorized third parties on the network may be able to access the unit. When connecting the unit to the network, be sure to confirm that the network is protected securely.
- Communication content may be unknowingly intercepted by unauthorized third parties in the vicinity of the signals. When using wireless LAN communication, implement security measures properly to protect the communication content.
- From a safety standpoint, when using the unit connected with the network, it is strongly recommended to access the Control window via a Web browser and change the access limitation settings from the factory preset values (page 72).
- Changing the password regularly is also recommended.
- Do not browse any other website in the Web browser while making settings or after making settings. Since the login status remains in the Web browser, close the Web browser when you complete the settings to prevent unauthorized third parties from using the unit or harmful programs from running.

About GPS

The GPS (Global Positioning System) is a system that calculates geographical location from highly accurate US space satellites. This system allows you to pinpoint your exact location on the earth. The GPS satellites are located in 6 orbits, 20,000 km above the earth. The GPS system consists of 24 or more GPS satellites.

A GPS receiver receives radio signals from the satellites, and calculates the current location (almanac data) and travel time of the signals, etc. Determining a location is called "triangulating." A GPS receiver can determine the location's latitude and longitude by receiving signals from 3 or more satellites.

- As the positions of GPS satellites vary constantly, it may take longer to determine the location or the receiver may not be able to determine the location at all, depending on the location and time you use the camcorder.
- "GPS" is a system for determining geographic location by triangulating radio signals from GPS satellites. Avoid using the camcorder in places where radio signals are blocked or reflected, such as a shadowy place surrounded by buildings or trees, etc. Use the camcorder in open sky environments.
- You may not be able to record location information at locations or in situations where radio signals from the GPS satellites do not reach the camcorder as follows:
 - In tunnels, indoors or under the shade of buildings.
 - Between tall buildings or at narrow streets surrounded by buildings.
 - In underground locations, locations surrounded by dense trees, under an elevated bridge, or in locations where magnetic fields are generated, such as near high voltage cables.
 - Near devices that generate radio signals of the same frequency band as the camcorder: near 1.5 GHz band mobile telephones, etc.
- If you upload and share the images which are recorded when the setting "GPS" is "On," the record location may be exposed on the internet even if you do not intend to do so. If you do not want to record location information, select "Off" for "GPS" (page 97).

On triangulating errors

- If you move to another location right after setting "GPS" to "On" in the menu, it may take a longer time for the camcorder to start triangulating, compared to when you stay in the same place.
- Error caused by the position of GPS satellites
The camcorder automatically triangulates your current location when the camcorder receives radio signals from 3 or more GPS satellites. The triangulating error allowed by the GPS satellites is about 10 m (33 feet). Depending on the environment of the location, the triangulating error can be greater. In this case, your actual location may not match the location on the map based on the GPS information. Meanwhile, the GPS satellites are controlled by the United States Department of Defense, and the degree of accuracy may be changed intentionally.
- Error during the triangulating process
The camcorder acquires location information periodically during triangulating.

On the restriction of use of GPS

Use GPS in accordance with the regulations of the situation, the countries/regions of use.



On the geographic coordinate system

The "WGS-84" geographic coordinate system is used.

Specifications

General

Mass Approx. 3.6 kg (7 lb 15 oz) (body only)
Dimensions (Unit: mm (inch), excluding protrusions, body only) ¹⁾



1) The values for dimensions are approximate.

Power requirements

12 V (11 V to 17.0 V) DC

Power consumption

Approx. 22 W (body only, when recording in XAVC, with LCD monitor on)

Approx. 24 W (CBK-VF02 viewfinder, manual lens, microphone, when recording in XAVC, with LCD monitor on)

[Notes]

- Do not connect video lights with power consumption of 50 W or greater.
- When using a battery, do not allow the total power consumption of connected peripherals to exceed 40 W.
- When using the AC-DN10, do not allow the total power consumption of connected peripherals to exceed 50 W.
- When using the AC-DN2B, do not allow the total power consumption of connected peripherals to exceed 85 W.
- Connect only devices with current consumption of 1.8 A or lower to the DC OUT connector.

Operating temperature

0 °C to 40 °C (32 °F to 104 °F)

Storage temperature

–20 °C to +60 °C (–4 °F to +140 °F)

File system

exFAT, UDF

Continuous operating time

Approx. 170 minutes (using BP-FLX75)

Recording format (video)

XAVC Intra

XAVC-I mode: CBG, 223 Mbps (max),

MPEG-4 AVC/H.264

XAVC Long

XAVC-L 50 mode: VBR, 50 Mbps (max),

MPEG-4 AVC/H.264

XAVC-L 35 mode: VBR, 35 Mbps (max),

MPEG-4 AVC/H.264

XAVC-L 25 mode: VBR, 25 Mbps (max),

MPEG-4 AVC/H.264

MPEG-2 Long GOP

MPEG-HD422 mode: CBR, 50 Mbps,

MPEG-2 422P@HL

MPEG-HD420 HQ mode: VBR, 35 Mbps

(max), MPEG-2 MP@HL

MPEG IMX

CBR, 50 Mbps

DVCAM

CBR, 25 Mbps

Proxy

AVC/H.264 Main Profile 4.2.0 Long GOP

1280×720/9 Mbps, 6 Mbps

640×360/3 Mbps,

480×270/1 Mbps, 500 Kbps (VBR)

Recording format (audio)

XAVC Intra

LPCM 24-bit, 48 kHz, 4-channel

XAVC Long

LPCM 24-bit, 48 kHz, 4-channel

MPEG-2 Long GOP

MPEG-HD422 mode: LPCM 24-bit,

48 kHz, 4-channel

MPEG-HD420 HQ mode: LPCM 16-bit,

48 kHz, 4-channel

MPEG IMX

LPCM 16/24-bit, 48 kHz, 4-channel

DVCAM

LPCM 16-bit, 48 kHz, 2-channel

Proxy

AAC-LC, 128 Kbps, 2-channel

Recording/playback time

XAVC Intra

XAVC-I mode

Approx. 30 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

XAVC Long

XAVC-L 50 mode

Approx. 120 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

XAVC-L 35 mode

Approx. 170 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

XAVC-L 25 mode

Approx. 220 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

MPEG-2 Long GOP

MPEG-HD422 mode

Approx. 120 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

MPEG-HD420 HQ mode

Approx. 180 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

MPEG IMX

Approx. 120 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

DVCAM

Approx. 220 minutes: Using SBP-64D/

SBS-64G1B (64 GB)

[Note]

The recording and playback times are for a continuous recording as a single clip. The actual times may be shorter, depending on the number of clips recorded.

Recording frame rate

XAVC Intra

XAVC-I mode

1920×1080/59.94P, 50P, 59.94i, 50i,

29.97P, 23.98P, 25P

1280×720/59.94P, 50P

XAVC Long

XAVC-L 50 mode

1920×1080/59.94P, 50P, 59.94i, 50i,

29.97P, 23.98P, 25P

1280×720/59.94P, 50P

XAVC-L 35 mode

1920×1080/59.94P, 50P, 59.94i, 50i,

29.97P, 23.98P, 25P

XAVC-L 25 mode

1920×1080/59.94i, 50i

MPEG-2 Long GOP

MPEG-HD422 mode

1920×1080/59.94i, 50i, 29.97P, 23.98P,

25P

1280×720/59.94P, 50P, 29.97P, 23.98P,

25P

MPEG-HD420 HQ mode

1920×1080/59.94i, 50i, 29.97P, 23.98P,

25P

1440×1080/59.94i, 50i

1280×720/59.94P, 50P

MPEG IMX

720×486/59.94i

720×576/50i

DVCAM

720×480/59.94i

720×576/50i

Proxy

Main line 1920×1080: 29.97P, 25P,

23.98P

Main line 1280×720: 59.94P, 50P,

29.97P, 25P, 23.98P

Input/Output Section

Inputs

GENLOCK IN:

BNC type, 1.0 Vp-p, 75 ohms, unbalanced

TC IN:

BNC type, 0.5 V to 18 Vp-p, 10 kilohms

AUDIO IN CH1/CH2:	XLR type, 3-pin, female
	LINE / AES/EBU / MIC / MIC+48V switchable
	LINE: +4, 0, -3 dBu
	AES/EBU: AES3 compliant
	MIC: -70 dBu to -30 dBu
MIC IN:	XLR type, 5-pin, female, -70 dBu to -30 dBu
WRR:	D-sub 15-pin
SDI IN:	Analog CH1: -40 dBu
	Digital CH1/CH2: -40 dBFS
	SMPT-E ST7292-1/259 standard compliant
4-channel audio	

Outputs

VIDEO OUT:

BNC type, SD analog composite/HD-V switchable

SDI OUT 1/2:

BNC type, 0.8 Vp-p, unbalanced (3G HD/1.5G HD/SD switchable)
SMPT-E ST424/425 Level-A/B,
ST7292-1/259 standard compliant
4-channel audio

AUDIO OUT:

XLR type, 5-pin, male, +4/0/-3 dBu (balanced)

TC OUT: BNC type, 1.0 Vp-p, 75 ohms
EARPHONE (stereo, minijack):
-11 dBu (reference level output, maximum monitor volume, 16-ohm load)

HDMI: Type A, 19-pin

Other

DC IN: XLR type, 4-pin, male, 11 V to 17 V DC
DC OUT: Round type 4-pin, 11 V to 17 V DC, 1.8 A maximum rated current
LENS: 12-pin, lens power source (11 V to 17 V DC, 1.0 A maximum rated current)
REMOTE: 8-pin
LIGHT: 2-pin

USB: 4-pin (type A) (2), 4-pin (type B)
VF: Rectangular type 26-pin, round type 20-pin
Network connector: RJ45 type, 100BASE-TX (IEEE 802.3u), 10BASE-T (IEEE 802.3)

Camera Section

Imaging element 2/3-inch type, “Exmor” Full HD CMOS
Type image sensor 1920 (H) × 1080 (V)
Optical system 3-chip RGB
ND filters F1.4 prism system

1: Clear
2: 1/4ND
3: 1/16ND
4: 1/64ND
Sensitivity F1.2 (system frequency: 59.94) (Typical)
(2000 lx, 89.9% reflectance, 3200K)
Minimum illumination 0.013 lx (F1.4, +42 dB, 16-frame accumulation)
Image S/N ratio 62 dB (Noise Suppression On) (Typical)
Horizontal resolution 1000 TVL (TV lines) or higher
Black level 3 ±1% (Black set to [±0] in the setup menu)
Shutter speed 59.94/P, 50/P, 1/60 to 1/2000 sec.
29.97P, 1/40 to 1/2000 sec.
25P, 1/33 to 1/2000 sec.
23.94P, 1/32 to 1/2000 sec.
Slow shutter 2 to 8, 16 frames
Dynamic range 2 to 8, 16 frames
600%
Smear -135 dB

Audio Section

Sampling frequency 48 kHz
Quantization 16/24-bit
Headroom 20 dB (factory default) (20, 18, 16, 12 dB), EBUL
Frequency response 20 Hz to 20 kHz (±3 dB or less)
Dynamic range 90 dB (typical)
Distortion 0.08% or lower (-40 dBu input level)
Built-in speaker Monaural, 300 mW output

Display Section

LCD monitor
Screen size 8.8 cm (3.5 inch) diagonal
Aspect ratio 16:9
Number of pixels 960 (H) × 540 (V)

Media Section

SxS card slots
Form factor: Express Card/34
Number of slots: 2
Connector: PCMCIA Express Card compliant
Write rate: 50 Mbps or higher
Read rate: 50 Mbps or higher

SD card slots
Proxy (1), Utility (1)

Lens Section (PXW-X400K)

Lens mount Sony 2/3-inch bayonet mount
Focal length 8.2 mm to 164 mm
Zoom Manual
Zoom factor 20
Maximum aperture ratio 1:1.9
Iris Auto/Manual switchable
F1.9 to F1.6 and C (Close)
Focus range Auto/Manual switchable
Range 900 mm to ∞ (macro OFF)
10 mm to ∞ (macro ON, wide angle)
Filter diameter M82 mm, 0.75 mm pitch
Macro ON/OFF selectable

Lens Section (PXW-X400KF)

Lens mount Sony 2/3-inch bayonet mount
Focal length 8 mm to 128 mm
(35 mm equivalent: 31.5 mm to 503 mm)
Zoom Power/Manual switchable
Zoom factor 16
Maximum aperture ratio 1:1.9

Iris	Auto/Manual switchable F1.9 to F16 and C (Close)
Focus range	Auto/Manual switchable Range 800 mm to ∞ (macro OFF) 50 mm to ∞ (macro ON, wide angle) 732 mm to ∞ (macro ON, telephoto)
Filter diameter	M82 mm, 0.75 mm pitch
Macro	ON/OFF selectable

Supplied Accessories

Shoulder belt (1)
Cold shoe kit (1)
Lens mount cap
USB wireless LAN module (IFU-WLM3)
Protective cap (1)
Guard (1)
Before Using This Unit (1)
Operating instructions (CD-ROM) (1)
Lens (supplied with PXW-X400K) (1)
Autofocus lens (supplied with PXW-X400KF) (1)
Flange focal length (flange back) adjustment chart (1)
Stereo microphone (supplied with PXW-X400K/ PXW-X400KF) (1)
Viewfinder (supplied with PXW-X400K/PXW- X400KF) (1)
Stereo microphone windscreen (supplied with PXW-X400K/PXW-X400KF) (1)

Related Equipment

Power supply and related equipment

AC adaptor	AC-DN10/DN2B
Battery pack	BP-FLX75
Battery charger	BC-L70/L90/L70A

Lens, viewfinder and related equipment

Lens	2/3-inch bayonet mount lens only
Viewfinder	HDFV-20A/L750/EL20/EL30
Viewfinder rotation bracket	BKW-401

Equipment for remote control

Remote control unit	RM-B170/B750
	RCP-1000/1500/1530
	RCP-1001/1501

[Note]
Command network unit (CNU) is not supported.

HD camera adaptor

CA-FB70/TX70

[Note]
If SDI OUT2 is used when the CA-FB70 is attached, use an L-shaped adaptor.

Media adaptor

MEAD-SD02 (for SDXC cards)

XQD ExpressCard adaptor

QDA-EX1 (for XQD memory cards)

Recording media

SxS memory cards
SxS PRO+ series
SxS PRO series
SxS-1 series

Audio equipment

Microphone	ECM-678/674/673/680S
Microphone holder	CAC-12
Digital wireless receiver	DWR-S02D
UHF synthesized tuner unit	WRR-855S URX-S03D

Other peripheral devices

Tripod attachment	VCT-14/U14
Video light	UC-D200A (Nippon Video System - NIPROS) Ultralight (Anton Bauer)
Pad	CBK-SP01 soft-type shoulder pad
Wireless LAN adaptor	CBK-WA02
Network adaptor kit	CBK-NA1

Products for maintenance, ease of use/handling

Attachment bracket
A-2092-367-

Design and specifications are subject to change without notice.

Notes

- Always make a test recording, and verify that it was recorded successfully.
SONY WILL NOT BE LIABLE FOR DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION OR REIMBURSEMENT ON ACCOUNT OF FAILURE OF THIS UNIT OR ITS RECORDING MEDIA, EXTERNAL STORAGE SYSTEMS OR ANY OTHER MEDIA OR STORAGE SYSTEMS TO RECORD CONTENT OF ANY TYPE.
- Always verify that the unit is operating properly before use. SONY WILL NOT BE LIABLE FOR DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION OR REIMBURSEMENT ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS DUE TO FAILURE OF THIS UNIT, EITHER DURING THE WARRANTY PERIOD OR AFTER EXPIRATION OF THE WARRANTY, OR FOR ANY OTHER REASON WHATSOEVER.
- SONY WILL NOT BE LIABLE FOR CLAIMS OF ANY KIND MADE BY USERS OF THIS UNIT OR MADE BY THIRD PARTIES.
- SONY WILL NOT BE LIABLE FOR THE LOSS, REPAIR, OR REPRODUCTION OF ANY DATA RECORDED ON THE INTERNAL STORAGE SYSTEM, RECORDING MEDIA, EXTERNAL STORAGE SYSTEMS OR ANY OTHER MEDIA OR STORAGE SYSTEMS.
- SONY WILL NOT BE LIABLE FOR THE TERMINATION OR DISCONTINUATION OF ANY SERVICES RELATED TO THIS UNIT THAT MAY RESULT DUE TO CIRCUMSTANCES OF ANY KIND.

Software Downloads


When the unit is used with a PC connection, download any device drivers, plug-ins, and application software you require from the following websites.

Sony Professional products website:

U.S.A.	http://pro.sony.com
Canada	http://www.sonybiz.ca
Latin America	http://sonypro-latn.com
Europe	http://www.pro.sony.eu/pro
Middle East, Africa	http://sony-psmea.com
Russia	http://sony.ru/pro/
Brazil	http://sonypro.com.br
Australia	http://pro.sony.com.au
New Zealand	http://pro.sony.co.nz
Japan	http://www.sonybsc.com
Asia Pacific	http://pro.sony-asia.com
Korea	http://bp.sony.co.kr
China	http://pro.sony.com.cn
India	http://pro.sony.co.in

Sony Creative Software, software download page:
[http://www.sonycreativesoftware.com/download/](http://www.sonycreativesoftware.com/download/software_for_sony_equipment)
[software_for_sony_equipment](http://www.sonycreativesoftware.com/download/software_for_sony_equipment)

Chart of Peripheral Devices and Accessories



MPEG-4 AVC Patent Portfolio License

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO

- (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR
- (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO.

NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.MPEGLA.COM)

END USER LICENSE AGREEMENT

IMPORTANT:

BEFORE USING THE SOFTWARE CONTAINED IN THE CAMCORDER, PLEASE READ THIS END USER LICENSE AGREEMENT ("EULA") CAREFULLY. BY USING THE SOFTWARE YOU ARE ACCEPTING THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THE TERMS OF THIS EULA, YOU MAY NOT USE THE SOFTWARE.

This EULA is a legal agreement between you and Sony Corporation ("SONY"). This EULA governs your rights and obligations regarding the software of SONY and/or its third party licensors (including SONY's affiliates) and their respective affiliates (collectively, the "THIRD-PARTY SUPPLIERS") contained in the camcorder, together with any updates/ upgrades provided by SONY, any printed, on-line or other electronic documentation for such software, and any data files created by operation of such software (collectively, the "SOFTWARE").

Notwithstanding the foregoing, any software in the SOFTWARE having a separate end user license agreement (including, but not limited to, GNU General Public License and Lesser/Library General Public License) shall be covered by such applicable separate end user license agreement in lieu of the terms of this EULA to the extent required by such separate end user license agreement ("EXCLUDED SOFTWARE").

SOFTWARE LICENSE

The SOFTWARE is licensed, not sold. The SOFTWARE is protected by copyright and other intellectual property laws and international treaties.

COPYRIGHT

All right and title in and to the SOFTWARE (including, but not limited to, any images, photographs, animation, video, audio, music, text and "apps") incorporated into the SOFTWARE) is owned by SONY or one or more of the THIRD-PARTY SUPPLIERS.

GRANT OF LICENSE

SONY grants you a limited license to use the SOFTWARE solely in connection with the camcorder and only for your individual use. SONY and the THIRD-PARTY SUPPLIERS expressly reserve all rights, title and interest (including, but not limited to, all intellectual property rights) in and to the SOFTWARE that this EULA does not specifically grant to you.

REQUIREMENTS AND LIMITATIONS

You may not copy, publish, adapt, redistribute, attempt to derive source code, modify, reverse engineer, decompile, or disassemble any of the SOFTWARE, whether in whole or in part, or create any derivative works from or of the SOFTWARE unless such derivative works are intentionally facilitated by the SOFTWARE. You may not modify or tamper with any digital rights management functionality of the SOFTWARE. You may not bypass, modify, defeat or circumvent any of the functions or protections of the SOFTWARE or any mechanisms operatively linked to the SOFTWARE. You may not separate any individual component of the SOFTWARE for use on more than one camcorder unless expressly authorized to do so by SONY. You may not remove, alter, cover or deface any trademarks or notices on the SOFTWARE. You may not share, distribute, rent, lease, sublicense, assign, transfer or sell the SOFTWARE. The software, network services or other products other than SOFTWARE upon which the SOFTWARE'S performance depends might be interrupted or discontinued at the discretion of the suppliers (software suppliers, service suppliers, or SONY). SONY and such suppliers do not warrant that the SOFTWARE, network services, contents or other products will continue to be available, or will operate without interruption or modification.

EXCLUDED SOFTWARE AND OPEN SOURCE COMPONENTS

Notwithstanding the foregoing limited license grant, you acknowledge that the SOFTWARE may include EXCLUDED SOFTWARE. Certain EXCLUDED SOFTWARE may be covered by open source software licenses ("Open Source Components"), which means any software licenses approved as open source licenses by the Open Source Initiative or any substantially similar licenses, including but not limited to any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format. If and to the extent disclosure is required, please visit www.sony.com/linux or other SONY-designated web site for a list of applicable OPEN SOURCE COMPONENTS included in the SOFTWARE from time to time, and the applicable terms and conditions governing its use. Such terms and conditions may be changed by the applicable third party at any time without liability to you. To the extent required by the licenses covering EXCLUDED SOFTWARE, the terms of such licenses will apply in lieu of the terms of this EULA. To the extent the terms of the licenses applicable to EXCLUDED SOFTWARE prohibit any of the restrictions in this EULA with respect to such EXCLUDED SOFTWARE, such restrictions will not apply to such EXCLUDED SOFTWARE. To the extent the terms of the licenses applicable to Open Source Components require SONY to make an offer to provide source code in connection with the SOFTWARE, such offer is hereby made.

USE OF SOFTWARE WITH COPYRIGHTED MATERIALS

The SOFTWARE may be capable of being used by you to view, store, process and/or use content created by you and/or third parties. Such content may be protected by copyright, other intellectual property laws, and/or agreements. You agree to use the SOFTWARE only in compliance with all such laws and agreements that apply to such content. You acknowledge and agree that SONY may take appropriate measures to protect the copyright of content stored, processed or used by the SOFTWARE. Such measures include, but are not limited to, counting the frequency of your backup and restoration through certain SOFTWARE features, refusal to accept your request to enable restoration of data, and termination of this EULA in the event of your illegitimate use of the SOFTWARE.

CONTENT SERVICE

PLEASE ALSO NOTE THAT THE SOFTWARE MAY BE DESIGNED TO BE USED WITH CONTENT AVAILABLE THROUGH ONE OR MORE CONTENT SERVICES ("CONTENT SERVICE"). USE OF THE SERVICE AND THAT CONTENT IS SUBJECT TO THE TERMS OF SERVICE OF THAT CONTENT SERVICE. IF YOU DECLINE TO ACCEPT THOSE TERMS, YOUR USE OF THE SOFTWARE WILL BE LIMITED. You acknowledge and agree that certain content and services available through the SOFTWARE may be provided by third parties over which SONY has no control. USE OF THE CONTENT SERVICE REQUIRES AN INTERNET CONNECTION. THE CONTENT SERVICE MAY BE DISCONTINUED AT ANY TIME.

INTERNET CONNECTIVITY AND THIRD PARTY SERVICES

You acknowledge and agree that access to certain SOFTWARE features may require an Internet connection for which you are solely responsible. Further, you are solely responsible for payment of any third party fees associated with your Internet connection, including but not limited to Internet service provider or airline charges. Operation of the SOFTWARE may be limited or restricted depending on the capabilities, bandwidth or technical limitations of your Internet connection and service. The provision, quality and security of such Internet connectivity are the sole responsibility of the third party providing such service.

EXPORT AND OTHER REGULATIONS

You agree to comply with all applicable export and re-export restrictions and regulations of the area or country in which you reside, and not to transfer, or authorize the transfer, of the SOFTWARE to a prohibited country or otherwise in violation of any such restrictions or regulations.

HIGH RISK ACTIVITIES

The SOFTWARE is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the SOFTWARE could lead to death, personal injury, or severe physical or environmental damage ("HIGH RISK ACTIVITIES"). SONY, each of the THIRD-PARTY SUPPLIERS, and each of their respective affiliates specifically disclaim any express or implied warranty, duty or condition of fitness for HIGH RISK ACTIVITIES.

EXCLUSION OF WARRANTY ON SOFTWARE

You acknowledge and agree that use of the SOFTWARE is at your sole risk and that you are responsible for use of the SOFTWARE. The SOFTWARE is provided "AS IS," without warranty, duty or condition of any kind.

SONY AND EACH OF THE THIRD-PARTY SUPPLIERS (for purposes of this Section, SONY and each of the THIRD-PARTY SUPPLIERS shall be collectively referred to as "SONY") EXPRESSLY DISCLAIM ALL WARRANTIES, DUTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE. SONY DOES NOT WARRANT OR MAKE ANY CONDITIONS OR REPRESENTATIONS (A) THAT THE FUNCTIONS CONTAINED IN ANY OF THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THEY WILL BE UPDATED, (B) THAT THE OPERATION OF ANY OF THE SOFTWARE WILL BE CORRECT OR ERROR-FREE OR THAT ANY DEFECTS WILL BE CORRECTED, (C) THAT THE SOFTWARE WILL NOT DAMAGE ANY OTHER SOFTWARE, HARDWARE OR DATA, (D) THAT ANY SOFTWARE, NETWORK SERVICES (INCLUDING THE INTERNET) OR PRODUCTS (OTHER THAN THE SOFTWARE) UPON WHICH THE SOFTWARE'S PERFORMANCE DEPENDS WILL CONTINUE TO BE AVAILABLE, UNINTERRUPTED OR UNMODIFIED, AND (E) REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SONY OR AN AUTHORIZED REPRESENTATIVE OF SONY SHALL CREATE A WARRANTY, DUTY OR CONDITION OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. SHOULD THE SOFTWARE PROVE DEFECTIVE YOU ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THESE EXCLUSIONS MAY NOT APPLY TO YOU.

LIMITATION OF LIABILITY

SONY AND EACH OF THE THIRD-PARTY SUPPLIERS (for purposes of this section, SONY and each of the THIRD-PARTY SUPPLIERS shall be collectively referred to as "SONY") SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR UNDER ANY OTHER LEGAL THEORY RELATED TO THE SOFTWARE, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES ARISING OUT OF LOSS OF PROFITS, LOSS OF REVENUE, LOSS OF DATA, LOSS OF USE OF THE SOFTWARE OR ANY ASSOCIATED HARDWARE, DOWNTIME AND USERS' TIME, EVEN IF ANY OF THEM HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, EACH AND ALL OF THEIR AGGREGATE LIABILITY UNDER ANY PROVISION OF THIS EULA SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID FOR THE PRODUCT. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.

CONSENT TO USE OF NON-PERSONAL INFORMATION, LOCATION DATA, DATA SECURITY

You acknowledge and agree that SONY and its affiliates, partners and agents may read, collect, transfer, process and store certain information collected from the SOFTWARE, including but not limited to information about (i) the SOFTWARE and (ii) the software applications, contents and peripheral devices that interact with your camcorder and the SOFTWARE ("Information"). Information includes, but is not limited to: (1) unique identifiers relating to your camcorder and its components; (2) performance of the camcorder, the SOFTWARE and their components; (3) configurations of your camcorder, the SOFTWARE and the software applications, contents and peripheral devices that interact with the camcorder and the SOFTWARE; (4) use and frequency of use of the functions of (x) the SOFTWARE, and (y) the software applications, contents and peripheral devices that interact with the SOFTWARE; and (5) location data, as indicated below. SONY and its affiliates, partners and agents may use and disclose information subject to applicable laws in order to improve its products and services or to provide products or services to you. Such uses include, but are not limited to: (a) administering the functionalities of the SOFTWARE; (b) to improve, service, update or upgrade the SOFTWARE; (c) improving, developing and enhancing the current and future products and services of SONY and other parties; (d) to provide you with information about the products and services offered by SONY and other parties; (e) complying with applicable laws or regulations; and (f) to the extent offered, providing you with location-based services of SONY and other parties, as indicated below. In addition, SONY retains the right to use information to protect itself and third parties from illegal, criminal or harmful conduct.

Certain services available through the SOFTWARE may rely upon location information, including, but not limited to, the geographic location of the camcorder. You acknowledge that for the purpose of providing such services, SONY, the THIRD-PARTY SUPPLIERS or their partners may collect, archive, process and use such location data, and that such services are governed by the privacy policies of SONY or such third party. By using any such services, you agree that you have reviewed the privacy policies applicable to such services and consent to such activities.

SONY, its affiliates, partners and agents will not intentionally use information to personally identify the owner or user of the SOFTWARE without your knowledge or consent. Any use of information will be in accordance with the privacy policies of SONY or such third party. Please contact applicable contact address of each area or country for SONY's current privacy policy.

Please contact applicable third parties for privacy policies relating to personally identifiable and other information you provide when you use or access third party software or services.

Information may be processed, stored or transferred to SONY, its affiliates or agents which are located in countries outside of your country of residence. Data protection and information privacy laws in certain countries may not offer the same level of protection as your country of residence and you may have fewer legal rights in relation to information processed and stored in, or transferred to, such countries. SONY will use reasonable efforts to take appropriate technical and organizational steps to prevent unauthorized access to or disclosure of information, but does not warrant it will eliminate all risk of misuse of such information.

AUTOMATIC UPDATE FEATURE

From time to time, SONY or the THIRD-PARTY SUPPLIERS may automatically update or otherwise modify the SOFTWARE, including, but not limited to, for purposes of enhancement of security functions, error correction and improvement of functions, at such time as you interact with SONY's or third parties' servers, or otherwise. Such updates or modifications may delete or change the nature of features or other aspects of the SOFTWARE, including, but not limited to, functions you may rely upon. You acknowledge and agree that such activities may occur at SONY's sole discretion and that SONY may condition continued use of the SOFTWARE upon your complete installation or acceptance of such update or modifications. Any updates/modifications shall be deemed to be, and shall constitute part of, the SOFTWARE for purposes of this EULA. By acceptance of this EULA, you consent to such update/ modification.

ENTIRE AGREEMENT, WAIVER, SEVERABILITY

This EULA and SONY's privacy policy, each as amended and modified from time to time, together constitute the entire agreement between you and SONY with respect to the SOFTWARE. The failure of SONY to exercise or enforce any right or provision of this EULA shall not constitute a waiver of such right or provision. If any part of this EULA is held invalid, illegal, or unenforceable, that provision shall be enforced to the maximum extent permissible so as to maintain the intent of this EULA, and the other parts will remain in full force and effect.

GOVERNING LAW AND JURISDICTION

The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this EULA. This EULA shall be governed by the laws of Japan, without regards to conflict of laws provisions. Any dispute arising out of this EULA shall be subject to the exclusive venue of the Tokyo District Court in Japan, and the parties hereby consent to the venue and jurisdiction of such courts.

EQUITABLE REMEDIES

Notwithstanding anything contained in this EULA to the contrary, you acknowledge and agree that any violation of or non-compliance with this EULA by you will cause irreparable harm to SONY, for which monetary damages would be inadequate, and you consent to SONY obtaining any injunctive or equitable relief that SONY deems necessary or appropriate in such circumstances. SONY may also take any legal and technical remedies to prevent violation of and/or to enforce this EULA, including, but not limited to, immediate termination of your use of the SOFTWARE, if SONY believes in its sole discretion that you are violating or intend to violate this EULA. These remedies are in addition to any other remedies SONY may have at law, in equity or under contract.

TERMINATION

Without prejudice to any of its other rights, SONY may terminate this EULA if you fail to comply with any of its terms. In case of such termination, you must: (i) cease all use, and destroy any copies, of the SOFTWARE; (ii) comply with the requirements in the section below entitled "Your Account Responsibilities".

AMENDMENT

SONY RESERVES THE RIGHT TO AMEND ANY OF THE TERMS OF THIS EULA AT ITS SOLE DISCRETION BY POSTING NOTICE ON A SONY DESIGNATED WEB SITE, BY EMAIL NOTIFICATION TO AN EMAIL ADDRESS PROVIDED BY YOU, BY PROVIDING NOTICE AS PART OF THE PROCESS IN WHICH YOU OBTAIN UPGRADES/ UPDATES OR BY ANY OTHER LEGALLY RECOGNIZABLE FORM OF NOTICE. If you do not agree to

the amendment, you should promptly contact SONY for instructions. Your continued use of the SOFTWARE after the effective date of any such notice shall be deemed your agreement to be bound by such amendment.

THIRD-PARTY BENEFICIARIES

Each THIRD-PARTY SUPPLIER is an express intended third-party beneficiary of, and shall have the right to enforce, each provision of this EULA with respect to the SOFTWARE of such party.

Should you have any questions concerning this EULA, you may contact SONY by writing to SONY at applicable contact address of each area or country.

Copyright © 2012 Sony Corporation.

Open Software Licenses

On the basis of license contracts between Sony and the software copyright holders, this product uses open software.

To meet the requirements of the software copyright holders, Sony is obligated to inform you of the content of these licenses.

For the content of these licenses, see "License 1. pdf" in the "License" folder of the supplied CD-ROM.

Trademarks

- XDCAM is a trademark of Sony Corporation.
- XAVC and **XAVC** are registered trademarks of Sony Corporation.
- Android and Google Chrome are trademarks or registered trademarks of Google, Inc.
- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Apple, Macintosh, Safari, and iPhone and their logos are trademarks or registered trademarks of Apple Inc. registered in the US and other countries.
- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- Wi-Fi, the Wi-Fi logo, and Wi-Fi Protected Setup are trademarks or registered trademarks of Wi-Fi Alliance.
- The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
- All system names and product names are registered trademarks or trademarks of their respective owners. Trademarked items are not indicated by ® or ™ symbols in this document.