

MOZA Air and AirCross	Joystick	
	one click	roll follow/wake up
	2X click	pitch follow
	3X click	all lock
	4X click	yaw & roll follow
	long press	sport gear mode
	power button	
	one click	start/stop recording
	2X click	photo taking
	3X click	re-center
	4X click	roll control
	long press	power on/off
	combination operation (keep pressing the joystick, then click the power button)	
	one click	sleeping mode
	2X click	auto tuning
	3X click	inception mode

MOZA Mini-MI	power button	
	long press	power on/off
	one click	standby/wake up
	2X click	start/stop wireless charging
	center button	
	one click	start/stop recording
	2X click	photo taking
	dial wheel upper button	
	one click	wake up the menu
	2X click	switch video/photo mode
	3X click	inception mode
	long press	switch front/rear camera
	dial wheel lower button	
	one click	auto zoom
	2X click	re-center
	3X click	selfie
	dial wheel left button	
	one click	select an item
	2X click	pitch lock/follow
	3X click	yaw lock/follow
	long press	roll follow
	dial wheel right button	
	one click	quick playback
	2X click	sport gear mode